

VE

VFD-VE

User Manual

Field Oriented Control AC Motor Drives



Voltage Range:

3-phase 230V series: 0.75~37kW(1.0~50HP)

3-phase 460V series: 0.75~75kW(1.0~100HP)



DELTA ELECTRONICS, INC.

www.delta.com.tw/industrialautomation

ASIA

Delta Electronics, Inc.

Taoyuan1

31-1, Xingbang Road, Guishan Industrial Zone,
Taoyuan County 33370, Taiwan, R.O.C.
TEL: 886-3-362-6301 / FAX: 886-3-362-7267

Delta Electronics (Jiang Su) Ltd.

Wujiang Plant3

1688 Jiangxing East Road,
Wujiang Economy Development Zone,
Wujiang City, Jiang Su Province,
People's Republic of China (Post code: 215200)
TEL: 86-512-6340-3008 / FAX: 86-769-6340-7290

Delta Electronics (Japan), Inc.

Tokyo Office

Delta Shibadaimon Building, 2-1-14 Shibadaimon,
Minato-Ku, Tokyo, 105-0012, Japan
TEL: 81-3-5733-1111 / FAX: 81-3-5733-1211

Delta Electronics (Korea), Inc.

Donghwa B/D 3F, 235-6, Nonhyun-dong,
Kangnam-gu, Seoul 135-010, Korea
TEL: 82-2-515-5303/5 / FAX: 82-2-515-5302

Delta Electronics (Singapore) Pte. Ltd.

8 Kaki Bukit Road 2, #04-18 Ruby Warehouse Complex,
Singapore 417841
TEL: 65-6747-5155 / FAX: 65-6744-9228

AMERICA

Delta Products Corporation (USA)

Raleigh Office

P.O. Box 12173, 5101 Davis Drive,
Research Triangle Park, NC 27709, U.S.A.
TEL: 1-919-767-3813 / FAX: 1-919-767-3969

EUROPE

Deltronics (The Netherlands) B.V.

Eindhoven Office

De Witbogt 15, 5652 AG Eindhoven, The Netherlands
TEL: 31-40-2592850 / FAX: 31-40-2592851

5011653101
200702-15



01VE



VFD-VE

User Manual

Field Oriented Control AC Motor Drives

Preface

Thank you for choosing DELTA's high-performance VFD-VE Series. The VFD-VE Series is manufactured with high-quality components and materials and incorporates the latest microprocessor technology available.

This manual is to be used for the installation, parameter setting, troubleshooting, and daily maintenance of the AC motor drive. To guarantee safe operation of the equipment, read the following safety guidelines before connecting power to the AC motor drive. Keep this operating manual at hand and distribute to all users for reference.

To ensure the safety of operators and equipment, only qualified personnel familiar with AC motor drive are to do installation, start-up and maintenance. Always read this manual thoroughly before using VFD-VE series AC Motor Drive, especially the WARNING, DANGER and CAUTION notes. Failure to comply may result in personal injury and equipment damage. If you have any questions, please contact your dealer.

PLEASE READ PRIOR TO INSTALLATION FOR SAFETY.



DANGER!

1. AC input power must be disconnected before any wiring to the AC motor drive is made.
2. A charge may still remain in the DC-link capacitors with hazardous voltages, even if the power has been turned off. To prevent personal injury, please ensure that power has turned off before opening the AC motor drive and wait ten minutes for the capacitors to discharge to safe voltage levels.
3. Never reassemble internal components or wiring.
4. The AC motor drive may be destroyed beyond repair if incorrect cables are connected to the input/output terminals. Never connect the AC motor drive output terminals U/T1, V/T2, and W/T3 directly to the AC mains circuit power supply.
5. Ground the VFD-VE using the ground terminal. The grounding method must comply with the laws of the country where the AC motor drive is to be installed. Refer to the Basic Wiring Diagram.
6. VFD-VE series is used only to control variable speed of 3-phase induction motors, NOT for 1-phase motors or other purpose.
7. VFD-VE series shall NOT be used for life support equipment or any life safety situation.

**WARNING!**

1. DO NOT use Hi-pot test for internal components. The semi-conductor used in AC motor drive easily damage by high-voltage.
2. There are highly sensitive MOS components on the printed circuit boards. These components are especially sensitive to static electricity. To prevent damage to these components, do not touch these components or the circuit boards with metal objects or your bare hands.
3. Only qualified persons are allowed to install, wire and maintain AC motor drives.

**CAUTION!**

1. Some parameters settings can cause the motor to run immediately after applying power.
2. DO NOT install the AC motor drive in a place subjected to high temperature, direct sunlight, high humidity, excessive vibration, corrosive gases or liquids, or airborne dust or metallic particles.
3. Only use AC motor drives within specification. Failure to comply may result in fire, explosion or electric shock.
4. To prevent personal injury, please keep children and unqualified people away from the equipment.
5. When the motor cable between AC motor drive and motor is too long, the layer insulation of the motor may be damaged. Please use a frequency inverter duty motor or add an AC output reactor to prevent damage to the motor. Refer to appendix B Reactor for details.
6. The rated voltage for AC motor drive must be $\leq 240V$ ($\leq 480V$ for 460V models) and the mains supply current capacity must be $\leq 5000A$ RMS ($\leq 10000A$ RMS for the $\geq 40hp$ (30kW) models).

Table of Contents

Preface	i
Table of Contents	iii
Chapter 1 Introduction	1-1
1.1 Receiving and Inspection	1-2
1.1.1 Nameplate Information	1-2
1.1.2 Model Explanation	1-2
1.1.3 Series Number Explanation	1-3
1.1.4 Drive Frames and Appearances	1-3
1.2 Preparation for Installation and Wiring	1-4
1.2.1 Ambient Conditions	1-4
1.2.2 Remove Keypad	1-6
1.2.3 Remove Front Cover	1-7
1.2.4 Lifting	1-8
1.3 Dimensions	1-9
Chapter 2 Installation and Wiring	2-1
2.1 Wiring	2-2
2.2 External Wiring	2-5
2.3 Main Circuit	2-6
2.3.1 Main Circuit Connection	2-6
2.3.2 Main Circuit Terminals	2-9

2.4 Control Terminals	2-12
Chapter 3 Digital Keypad Operation and Start Up	3-1
3.1 Digital Keypad KPV-CE01	3-1
3.1.1 Description of the Digital Keypad KPV-CE01	3-1
3.1.2 How to Operate the Digital Keypad KPV-CE01	3-3
3.1.3 Dimension of the Digital Keypad	3-5
3.1.4 Reference Table for the LCD Display of the Digital Keypad	3-5
3.1.5 Operation Method.....	3-6
3.2 Start-up	3-7
3.2.1 Preparations before Start-up	3-7
3.2.2 Trial Run.....	3-8
Chapter 4 Parameters.....	4-1
4.1 Summary of Parameter Settings	4-2
4.2 Description of Parameter Settings	4-22
Chapter 5 Troubleshooting	5-1
5.1 Over Current (OC)	5-1
5.2 Ground Fault.....	5-2
5.3 Over Voltage (OV)	5-2
5.4 Low Voltage (Lv).....	5-3
5.5 Over Heat (OH).....	5-4
5.6 Overload	5-4
5.7 Display of KPV-CE01 is Abnormal.....	5-5
5.8 Phase Loss (PHL).....	5-5
5.9 Motor cannot Run	5-6
5.10 Motor Speed cannot be Changed	5-7

5.11 Motor Stalls during Acceleration	5-8
5.12 The Motor does not Run as Expected	5-8
5.13 Electromagnetic/Induction Noise	5-9
5.14 Environmental Condition	5-9
5.15 Affecting Other Machines	5-10
Chapter 6 Fault Code Information and Maintenance.....	6-1
6.1 Fault Code Information	6-1
6.1.1 Common Problems and Solutions.....	6-1
6.1.2 Reset	6-5
6.2 Maintenance and Inspections.....	6-6
Appendix A Specifications	A-1
Appendix B Accessories	B-1
B.1 All Braking Resistors & Braking Units Used in AC Motor Drives	B-1
B.1.1 Dimensions and Weights for Braking Resistors.....	B-3
B.1.2 Specifications for Braking Unit.....	B-5
B.1.3 Dimensions for Braking Unit	B-6
B.2 Non-fuse Circuit Breaker Chart	B-7
B.3 Fuse Specification Chart.....	B-8
B.4 AC Reactor	B-9
B.4.1 AC Input Reactor Recommended Value.....	B-9
B.4.2 AC Output Reactor Recommended Value	B-9
B.4.3 Applications for AC Reactor	B-10
B.5 Zero Phase Reactor (RF220X00A)	B-13
B.6 DC Choke Recommended Values	B-35

B.7 Remote Controller RC-01	B-36
B.8 PG Card (for Encoder)	B-37
B.8.1 EMV-PG01X	B-37
B.8.2 EMV-PG01O	B-40
B.8.3 EMV-PG01L	B-43
B.9 AMD-EMI Filter Cross Reference	B-48
B.9.1 Dimensions	B-52
Appendix C How to Select the Right AC Motor Drive	C-1
C.1 Capacity Formulas	C-2
C.2 General Precaution	C-4
C.3 How to Choose a Suitable Motor	C-5

Chapter 1 Introduction

The AC motor drive should be kept in the shipping carton or crate before installation. In order to retain the warranty coverage, the AC motor drive should be stored properly when it is not to be used for an extended period of time. Storage conditions are:



CAUTION!

1. Store in a clean and dry location free from direct sunlight or corrosive fumes.
2. Store within an ambient temperature range of -20°C to $+60^{\circ}\text{C}$.
3. Store within a relative humidity range of 0% to 90% and non-condensing environment.
4. Store within an air pressure range of 86 kPa to 106kPa.
5. DO NOT place on the ground directly. It should be stored properly. Moreover, if the surrounding environment is humid, you should put exsiccator in the package.
6. DO NOT store in an area with rapid changes in temperature. It may cause condensation and frost.
7. If the AC motor drive is stored for more than 3 months, the temperature should not be higher than 30°C . Storage longer than one year is not recommended, it could result in the degradation of the electrolytic capacitors.
8. When the AC motor drive is not used for longer time after installation on building sites or places with humidity and dust, it's best to move the AC motor drive to an environment as stated above.


1.1 Receiving and Inspection

This VFD-VE AC motor drive has gone through rigorous quality control tests at the factory before shipment. After receiving the AC motor drive, please check for the following:


- Check to make sure that the package includes an AC motor drive, the User Manual/Quick Start and CD, dust covers and rubber bushings.
- Inspect the unit to assure it was not damaged during shipment.
- Make sure that the part number indicated on the nameplate corresponds with the part number of your order.

1.1.1 Nameplate Information

Example for 5HP/3.7kW 3-phase 230V AC motor drive




1.1.2 Model Explanation



1.1.3 Series Number Explanation


037V23A2 T 7 36 0001




If the nameplate information does not correspond to your purchase order or if there are any problems, please contact your distributor.



1.1.4 Drive Frames and Appearances

1-5HP/0.75-3.7kW (Frame B)



7.5-15HP/5.5-11kW (Frame C)



15-30HP/11-22kW (Frame D)**40-100HP/30-75kW (Frame E, E1)**

Frame	Power range	Models
B	1-5hp (0.75-3.7kW)	VFD007V23A/43A-2, VFD015V23A/43A-2, VFD022V23A/43A-2, VFD037V23A/43A-2
C	7.5-15hp (5.5-11kW)	VFD055V23A/43A-2, VFD075V23A/43A-2, VFD110V43B-2
D	15-30hp (11-22kW)	VFD110V23A/43A-2, VFD150V23A/43A-2, VFD185V23A/43A-2, VFD220V23A/43A-2
E	40-60hp (30-45kW)	VFD300V43A-2, VFD370V43A-2, VFD450V43A-2
E1	40-100hp (30-75kW)	VFD300V23A-2, VFD370V23A-2, VFD550V43C-2, VFD750V43C-2

Please refer to Chapter 1.3 for exact dimensions.


1.2 Preparation for Installation and Wiring

1.2.1 Ambient Conditions

Install the AC motor drive in an environment with the following conditions:

Operation	Air Temperature:	-10 ~ +50°C (14 ~ 122°F) for UL & cUL -10 ~ +40°C (14 ~ 104°F) for side-by-side mounting
	Relative Humidity:	<90%, no condensation allowed
	Atmosphere pressure:	86 ~ 106 kPa
	Installation Site Altitude:	<1000m
	Vibration:	<20Hz: 9.80 m/s ² (1G) max 20 ~ 50Hz: 5.88 m/s ² (0.6G) max
Storage Transportation	Temperature:	-20°C ~ +60°C (-4°F ~ 140°F)
	Relative Humidity:	<90%, no condensation allowed
	Atmosphere pressure:	86 ~ 106 kPa
	Vibration:	<20Hz: 9.80 m/s ² (1G) max 20 ~ 50Hz: 5.88 m/s ² (0.6G) max
Pollution Degree	2: good for a factory type environment.	

Minimum Mounting Clearances





HP	W mm (inch)	H mm (inch)
1-5HP	50 (2)	150 (6)
7.5-20HP	75 (3)	175 (7)
25-75HP	75 (3)	200 (8)
100HP and above	75 (3)	250 (10)

**CAUTION!**



1. Operating, storing or transporting the AC motor drive outside these conditions may cause damage to the AC motor drive.
2. Failure to observe these precautions may void the warranty!
3. Mount the AC motor drive vertically on a flat vertical surface object by screws. Other directions are not allowed.
4. The AC motor drive will generate heat during operation. Allow sufficient space around the unit for heat dissipation.
5. The heat sink temperature may rise to 90°C when running. The material on which the AC motor drive is mounted must be noncombustible and be able to withstand this high temperature.
6. When AC motor drive is installed in a confined space (e.g. cabinet), the surrounding temperature must be within 10 ~ 40°C with good ventilation. DO NOT install the AC motor drive in a space with bad ventilation.
7. When installing multiple AC more drives in the same cabinet, they should be adjacent in a row with enough space in-between. When installing one AC motor drive below another one, use a metal separation between the AC motor drives to prevent mutual heating.
8. Prevent fiber particles, scraps of paper, saw dust, metal particles, etc. from adhering to the heatsink.

1.2.2 Remove Keypad

1-5HP/0.75-3.7kW (Frame B)	7.5-15HP/5.5-11kW (Frame C)
	

15-30HP/11-22kW (Frame D)



40-100HP/30-75kW (Frame E, E1)



1.2.3 Remove Front Cover



1-5HP/0.75-3.7kW (Frame B)

7.5-15HP/5.5-11kW (Frame C)



15-30HP/11-22kW (Frame D)

40-100HP/30-75kW (Frame E, E1)




1.2.4 Lifting


Please carry only fully assembled AC motor drives as shown in the following.

For 40-100HP (Frame E and E1)


Step 1




Step 2



Step 3




Step 4




1.3 Dimensions

It can be divided into two types, type A and type B, from the appearance. Type A is for frame B, frame C and frame D. Type B is for frame E and frame E1.

Type A



Type B



Frame	B	B*	C	D	E1	E
W	150.0 [5.91]	150.0 [5.91]	200.0 [7.88]	250.0 [9.84]	370.0 [14.57]	370.0 [14.57]
W1	135.0 [5.32]	135.0 [5.32]	185.6 [7.31]	226.0 [8.90]	335.0 [13.19]	335.0 [13.19]
H	-	272.1 [10.72]	-	-	595.0 [23.43]	-
H1	260.0 [10.24]	-	323.0 [12.73]	403.8 [15.90]	589.0 [23.19]	589.0 [23.19]
H2	244.3 [9.63]	244.3 [9.63]	303.0 [11.94]	384.0 [15.12]	560.0 [22.05]	560.0 [22.05]
D	160.2 [6.31]	183.7 [7.24]	183.2 [7.22]	205.4 [8.08]	260.0 [10.24]	260.0 [10.24]
D1	-	-	-	-	132.5 [5.22]	132.5 [5.22]
Ø	6.5 [0.26]	6.5 [0.26]	7.0 [0.28]	10.0 [0.39]	13.0 [0.51]	13.0 [0.51]
R	3.25 [0.13]	3.25 [0.13]	-	3.25 [0.13]	6.5 [0.25]	6.5 [0.25]
ØD	11.3 [0.44]	11.3 [0.44]	13.5 [0.53]	13.5 [0.53]	21.0 [0.83]	21.0 [0.83]
ØD1	-	-	-	-	18.0 [0.71]	18.0 [0.71]
Ø1	22.0 [0.87]	28.0 [1.10]	22.0 [0.87]	28.0 [1.10]	22.0 [0.87]	22.0 [0.87]
Ø2	28.0 [1.10]	34.0 [1.34]	42.6 [1.68]	42.0 [1.65]	62.0 [2.44]	62.0 [2.44]
Ø3	-	-	-	-	18.0 [0.71]	18.0 [0.71]

**NOTE**

Frame B: VFD007V23A/43A-2, VFD015V23A/43A-2, VFD022V23A/43A-2

Frame B*: VFD037V23A/43A-2

Frame C: VFD055V23A/43A-2, VFD075V23A/43A-2, VFD110V43B-2

Frame D: VFD110V23A/43A-2, VFD150V23A/43A-2, VFD185V23A/43A-2, VFD220V23A/43A-2

Frame E1: VFD300V23A-2, VFD370V23A-2, VFD550V43C-2, VFD750V43C-2

Frame E: VFD300V43A-2, VFD370V43A-2, VFD450V43A-2

This page intentionally left blank

Chapter 2 Installation and Wiring

After removing the front cover (see chapter 1.2.3 for details), check if the power and control terminals are clear. Be sure to observe the following precautions when wiring.

■ General Wiring Information

Applicable Codes

All VFD-VE series are Underwriters Laboratories, Inc. (UL) and Canadian Underwriters Laboratories (cUL) listed, and therefore comply with the requirements of the National Electrical Code (NEC) and the Canadian Electrical Code (CEC).

Installation intended to meet the UL and cUL requirements must follow the instructions provided in "Wiring Notes" as a minimum standard. Follow all local codes that exceed UL and cUL requirements. Refer to the technical data label affixed to the AC motor drive and the motor nameplate for electrical data.

The "Line Fuse Specification" in Appendix B, lists the recommended fuse part number for each VFD-VE Series part number. These fuses (or equivalent) must be used on all installations where compliance with U.L. standards is a requirement.



CAUTION!

1. Make sure that power is only applied to the R/L1, S/L2, T/L3 terminals. Failure to comply may result in damage to the equipment. The voltage and current should lie within the range as indicated on the nameplate.
2. Check following items after finishing the wiring:
 - A. Are all connections correct?
 - B. No loose wires?
 - C. No short-circuits between terminals or to ground?



DANGER!


1. A charge may still remain in the DC bus capacitors with hazardous voltages even if the power has been turned off. To prevent personal injury, please ensure that the power is turned off and wait ten minutes for the capacitors to discharge to safe voltage levels before opening the AC motor drive.
2. All the units must be grounded directly to a common ground terminal to prevent lightning strike or electric shock.

- Only qualified personnel familiar with AC motor drives is allowed to perform installation, wiring and commissioning.
- Make sure that the power is off before doing any wiring to prevent electric shock.

2.1 Wiring

Users must connect wires according to the circuit diagrams on the following pages. Do not plug a modem or telephone line to the RS-485 communication port or permanent damage may result. Terminals 1 & 2 are the power supply for the optional copy keypad KPV-CE01 only and should not be used for RS-485 communication.


Figure 1 for models of VFD-VE Series (15 HP/11kW and below)
VFD007V23A/43A-2, VFD015V23A/43A-2, VFD022V23A/43A-2, VFD037V23A/43A-2,
VFD055V23A/43A-2, VFD075V23A/43A-2, VFD110V43B-2, VFD110V23A/43A-2



NOTE

- Please turn off the power when J4/J5/J8 is inserted/removed.
- For communication, it needs to use VFD-USB01/IFD8500 to connect to PC.


Figure 2 for models of VFD-VE Series (20HP/15kW and above)
 VFD150V23A/43A-2, VFD185V23A/43A-2, VFD220V23A/43A-2, VFD300V43A-2, VFD370V43A-2,
 VFD450V43A-2, VFD300V23A-2, VFD370V23A-2, VFD550V43C-2, VFD750V43C-2

**NOTE**


1. Please turn off the power when J4/J5/J8 is inserted/removed.
2. For communication, it needs to use VFD-USB01/IFD8500 to connect to PC.

Figure 3 Wiring for SINK(NPN) mode and SOURCE(PNP) mode

SINK/NPN Mode




SOURCE/PNP Mode



CAUTION!

1. The wiring of main circuit and control circuit should be separated to prevent erroneous actions.
2. Please use shield wire for the control wiring and not to expose the peeled-off net in front of the terminal.
3. Please use the shield wire or tube for the power wiring and ground the two ends of the shield wire or tube.

2.2 External Wiring



Items	Explanations
Power supply	Please follow the specific power supply requirements shown in Appendix A.
Fuse/NFB (Optional)	There may be an inrush current during power up. Please check the chart of Appendix B and select the correct fuse with rated current. Use of an NFB is optional.
Magnetic contactor (Optional)	Please do not use a Magnetic contactor as the I/O switch of the AC motor drive, as it will reduce the operating life cycle of the AC drive.
Input AC Line Reactor (Optional)	Used to improve the input power factor, to reduce harmonics and provide protection from AC line disturbances (surges, switching spikes, short interruptions, etc.). AC line reactor should be installed when the power supply capacity is 500kVA or more and exceeds 6 times the inverter capacity, or the mains wiring distance $\leq 10m$.
Zero-phase Reactor (Ferrite Core Common Choke) (Optional)	Zero phase reactors are used to reduce radio noise especially when audio equipment is installed near the inverter. Effective for noise reduction on both the input and output sides. Attenuation quality is good for a wide range from AM band to 10MHz. Appendix B specifies the zero phase reactor. (RF220X00A)
EMI filter (Optional)	To reduce electromagnetic interference, please refer to Appendix B for more details.
Braking Resistor (Optional)	Used to reduce the deceleration time of the motor. Please refer to the chart in Appendix B for specific Braking Resistors.
Output AC Line Reactor (Optional)	Motor surge voltage amplitude depends on motor cable length. For applications with long motor cable ($>20m$), it is necessary to install a reactor at the inverter output side.

2.3 Main Circuit

2.3.1 Main Circuit Connection

Figure 1 for the main terminals





Figure 2 for the main terminals




Terminal Symbol	Explanation of Terminal Function
R/L1, S/L2, T/L3	AC line input terminals (1-phase/3-phase)
U/T1, V/T2, W/T3	AC drive output terminals for connecting 3-phase induction motor
+1, +2	Connections for DC Choke (optional)
+2/B1, B2	Connections for Braking Resistor (optional)
+2~(-), +2/B1~(-)	Connections for External Braking Unit (VFDB series)
	Earth connection, please comply with local regulations.

Mains power terminals (R/L1, S/L2, T/L3)

- Connect these terminals (R/L1, S/L2, T/L3) via a non-fuse breaker or earth leakage breaker to 3-phase AC power (some models to 1-phase AC power) for circuit protection. It is unnecessary to consider phase-sequence.
- It is recommended to add a magnetic contactor (MC) in the power input wiring to cut off power quickly and reduce malfunction when activating the protection function of AC motor drives. Both ends of the MC should have an R-C surge absorber.
- Please make sure to fasten the screw of the main circuit terminals to prevent sparks which is made by the loose screws due to vibration.
- Please use voltage and current within the regulation shown in Appendix A.
- When using leakage-current breaker to prevent leakage current,
- Do NOT run/stop AC motor drives by turning the power ON/OFF. Run/stop AC motor drives by RUN/STOP command via control terminals or keypad. If you still need to run/stop AC drives by turning power ON/OFF, it is recommended to do so only ONCE per hour.
- Do NOT connect 3-phase models to a 1-phase power source.


Output terminals for main circuit (U, V, W)

- When the AC drive output terminals U/T1, V/T2, and W/T3 are connected to the motor terminals U/T1, V/T2, and W/T3, respectively, the motor will rotate counterclockwise (as viewed on the shaft end of the motor) when a forward operation command is received. To permanently reverse the direction of motor rotation, switch over any of the two motor leads.



- DO NOT connect phase-compensation capacitors or surge absorbers at the output terminals of AC motor drives.
- With long motor cables, high capacitive switching current peaks can cause over-current, high leakage current or lower current readout accuracy. To prevent this, the motor cable should be less than 20m for 3.7kW models and below. And the cable should be less than 50m for 5.5kW models and above. For longer motor cables use an AC output reactor.
- Use well-insulated motor, suitable for inverter operation.


Terminals [+1, +2] for connecting DC reactor



- To improve power factor and reduce harmonics connect a DC reactor between terminals [+1, +2]. Please remove the jumper before connecting the DC reactor.

 **NOTE** Models of 15kW and above have a built-in DC reactor.

Terminals [+2/B1, B2] for connecting brake resistor and terminals [+1, +2/B1] for connecting external brake unit



- Connect a brake resistor or brake unit in applications with frequent deceleration ramps, short deceleration time, too low braking torque or requiring increased braking torque.
- If the AC motor drive has a built-in brake chopper (all models of 11kW and below), connect the external brake resistor to the terminals [+2/B1, B2].
- Models of 15kW and above don't have a built-in brake chopper. Please connect an external optional brake unit (VFDB-series) and brake resistor. Refer to VFDB series user manual for details.
- Connect the terminals [+ (P), - (N)] of the brake unit to the AC motor drive terminals [+2(+2/B1), (-)]. The length of wiring should be less than 5m with twisted cable.
- When not used, please leave the terminals [+2/B1, -] open.




WARNING!

1. Short-circuiting [B2] or [-] to [+2/B1] can damage the AC motor drive.


Grounding terminals (⊕)

- Make sure that the leads are connected correctly and the AC drive is properly grounded. (Ground resistance should not exceed 0.1Ω .)
- Use ground leads that comply with local regulations and keep them as short as possible.
- Multiple VFD-VE units can be installed in one location. All the units should be grounded directly to a common ground terminal, as shown in the figure below. **Ensure there are no ground loops.**



2.3.2 Main Circuit Terminals

Frame B




Main circuit terminals

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, $\oplus$, +1, +2/B1, -, B2

Models	Wire	Torque	Wire Type
VFD007V23A-2	14-10 AWG (2.1-5.3mm ²)	18kgf-cm (15.6in-lbf)	Stranded copper only, 75°C
VFD007V43A-2			
VFD015V23A-2			
VFD015V43A-2			
VFD022V23A-2	12-10 AWG (3.3-5.3mm ²)		
VFD022V43A-2	14-10 AWG (2.1-5.3mm ²)		
VFD037V23A-2	10 AWG (5.3mm ²)		
VFD037V43A-2	14-10 AWG (2.1-5.3mm ²)		

Frame C




Main circuit terminals

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, $\oplus$, +1, +2/B1, -, B2

Models	Wire	Torque	Wire Type
VFD055V23A-2	8 AWG (8.4mm ²)	30kgf-cm (26in-lbf)	Stranded copper only, 75 °C
VFD075V23A-2			
VFD110V43B-2			
VFD055V43A-2	12-10 AWG (3.3-5.3mm ²)	30kgf-cm (26in-lbf)	Stranded copper only, 75 °C
VFD075V43A-2	10 AWG (5.3mm ²)		

Frame D




Main circuit terminals

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, $\oplus$, +1, +2, -

Models	Wire	Torque	Wire Type
VFD110V23A-2	6-2 AWG (13.3-33.6mm ²)	30kgf-cm (26in-lbf)	Stranded copper only, 75 °C
VFD110V43A-2	8-2 AWG (8.4-33.6mm ²)		
VFD150V43A-2			
VFD150V23A-2	3-2 AWG (26.7-33.6mm ²)		
VFD185V23A-2	2 AWG (33.6mm ²)		
VFD185V43A-2	4-2 AWG (21.2-33.6mm ²)		
VFD220V43A-2			
VFD220V23A-2	2 AWG # (33.6mm ²)		

Frame E




Main circuit terminals

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, , +1, +2, -

Models	Wire	Torque	Wire Type
VFD300V43A-2	4-2 AWG (21.2-33.6mm ²)	57kgf-cm (49in-lbf)	Stranded copper only, 75°C
VFD370V43A-2	3-2 AWG (26.7-33.6mm ²)		
VFD450V43A-2	2 AWG # (33.6mm ²)		

Frame E1



Main circuit terminals

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, , +1, +2, -


Models	Wire	Torque	Wire Type
VFD300V23A-2	1/0-4/0 AWG (53.5-107.2mm ²)	200kgf-cm (173in-lbf)	Stranded copper only, 75 °C
VFD370V23A-2			
VFD550V43C-2	3/0-4/0 AWG (85-107.2mm ²)		
VFD750V43C-2			

**NOTE**


To connect 6 AWG (13.3 mm²) wires, use Recognized Ring Terminals

2.4 Control Terminals

Circuit diagram for digital inputs (SINK current 16mA.)









The Position of the Control Terminals



Terminal symbols and functions

Terminal Symbol	Terminal Function	Factory Settings (SINK) ON: Connect to DCM
FWD	Forward-Stop Command	ON: Run in FWD direction OFF: Stop acc. to Stop Method
REV	Reverse-Stop Command	ON: Run in REV direction OFF: Stop acc. to Stop Method
+24V	DC Voltage Source	+24VDC, 20mA, used for SOURCE mode.
MI1	Multi-function Input 1	Refer to Pr.02-01 to Pr.02-06 for programming the Multi-function Inputs.
MI2	Multi-function Input 2	
MI3	Multi-function Input 3	
MI4	Multi-function Input 4	
MI5	Multi-function Input 5	
MI6	Multi-function Input 6	


Terminal Symbol	Terminal Function	Factory Settings (SINK) ON: Connect to DCM
DFM	Digital Frequency Meter (Open Collector Output) DFM-DCM 	Pulse voltage output monitor signal, proportional to output frequency Duty-cycle: 50% Ratio: Pr.02-18 Min. load: 10KΩ Max. current: 50mA Max. voltage: 48Vdc
DCM	Digital Signal Common	Common for digital inputs and used for SINK mode.
RA	Multi-function Relay Output 1 (N.O.) a	Resistive Load: 5A(N.O.)/3A(N.C.) 240VAC 5A(N.O.)/3A(N.C.) 24VDC Inductive Load: 1.5A(N.O.)/0.5A(N.C.) 240VAC 1.5A(N.O.)/0.5A(N.C.) 24VDC To output monitor signal, including in operation, frequency arrival, overload and etc. Refer to Pr.02-11~02-12 for programming
RB	Multi-function Relay Output 1 (N.C.) b	
RC	Multi-function Relay Common	
MRA	Multi-function Relay Output 2 (N.O.) a	
MRC	Multi-function Relay Common	
+10V	Potentiometer Power Supply	+10VDC 20mA (variable resistor 3-5kohm)
MCM	Multi-function Output Common (Photocoupler)	Max. 48VDC 50mA
MO1	Multi-function Output 1 (Photocoupler)	Maximum 48VDC, 50mA Refer to Pr.02-13 to Pr.02-14 for programming
MO2	Multi-function Output 2 (Photocoupler)	MO1~MO2-DCM 

Terminal Symbol	Terminal Function	Factory Settings (SINK) ON: Connect to DCM
AVI	Analog voltage Input 	Impedance: 2M Ω Resolution: 10 bits Range: 0 ~ 10VDC = 0 ~ Max. Output Frequency (Pr.01-00) Set-up: Pr.03-00 ~ Pr.03-02
ACI	Analog current Input 	Impedance: 250 Ω Resolution: 10 bits Range: 4 ~ 20mA/0~10V = 0 ~ Max. Output Frequency (Pr.01-00) Set-up: Pr.03-00 ~ Pr.03-02 Jumper: J4, factory setting is 4-20mA
AUI	Auxiliary analog voltage input 	Impedance: 2M Ω Resolution: 10 bits Range: -10 ~ +10VDC = 0 ~ Max. Output Frequency (Pr.01-00) Set-up: Pr.03-00 ~ Pr.03-02
AFM	Analog output meter 	Impedance: 18.5k Ω Output current: 2mA max Resolution: output by PWM Range: 0 ~ 10V/0 ~ 20mA Function: Pr.03-18
ACM	Analog control signal (common)	Common for AVI, ACI, AUI, AFM

*Control signal wiring size: 18 AWG (0.75 mm²) with shielded wire.

Analog input terminals (AVI, ACI, AUI, ACM)

- Analog input signals are easily affected by external noise. Use shielded wiring and keep it as short as possible (<20m) with proper grounding. If the noise is inductive, connecting the shield to terminal ACM can bring improvement.
- If the analog input signals are affected by noise from the AC motor drive, please connect a capacitor and ferrite core as indicated in the following diagrams:



wind each wires 3 times or more around the core

Digital inputs (FWD, REV, MI1~MI6, DCM)

- When using contacts or switches to control the digital inputs, please use high quality components to avoid contact bounce.

Digital outputs (MO1, MO2, MCM)

- Make sure to connect the digital outputs to the right polarity, see wiring diagrams.
- When connecting a relay to the digital outputs, connect a surge absorber or fly-back diode across the coil and check the polarity.

General

- Keep control wiring as far as possible from the power wiring and in separate conduits to avoid interference. If necessary let them cross only at 90° angle.
- The AC motor drive control wiring should be properly installed and not touch any live power wiring or terminals.

**NOTE**


- If a filter is required for reducing EMI (Electro Magnetic Interference), install it as close as possible to AC drive. EMI can also be reduced by lowering the Carrier Frequency.
- When using a GFCI (Ground Fault Circuit Interrupter), select a current sensor with sensitivity of 200mA, and not less than 0.1-second detection time to avoid nuisance tripping.



Damaged insulation of wiring may cause personal injury or damage to circuits/equipment if it comes in contact with high voltage.

The specification for the control terminals

The Position of the Control Terminals



Frame	Torque	Wire
B, C, D, E, E1	8 kgf-cm (6.9 in-lbf)	22-14 AWG (0.3-2.1mm ²)




- Frame B: VFD007V23A/43A-2, VFD015V23A/43A-2, VFD022V23A/43A-2, VFD037V23A/43A-2;
Frame C: VFD055V23A/43A-2, VFD075V23A/43A-2, VFD110V43B-2,
Frame D: VFD110V23A/43A-2, VFD150V23A/43A-2, VFD185V23A/43A-2, VFD220V23A/43A-2
Frame E: VFD300V43A-2, VFD370V43A-2, VFD450V43A-2
Frame E1: VFD300V23A-2, VFD370V23A-2, VFD550V43C-2, VFD750V43C-2

Chapter 3 Digital Keypad Operation and Start Up

3.1 Digital Keypad KPV-CE01

3.1.1 Description of the Digital Keypad KPV-CE01



Display Message	Descriptions
	Displays the AC drive Master Frequency.
	Displays the actual output frequency present at terminals U/T1, V/T2, and W/T3.
	User defined unit (where $U = F \times \text{Pr.00-05}$)
	Displays the output current present at terminals U/T1, V/T2, and W/T3.
	The counter value (C).

Display Message	Descriptions
	Displays the selected parameter.
	Displays the actual stored value of the selected parameter.
	External Fault.
	Display "End" for approximately 1 second if input has been accepted by pressing  key. After a parameter value has been set, the new value is automatically stored in memory. To modify an entry, use the  ,  and  keys.
	Display "Err", if the input is invalid.

3.1.2 How to Operate the Digital Keypad KPV-CE01


Selection mode

START



NOTE: In the selection mode, press **PROG DATA** to set the parameters.

To set parameters



NOTE: In the parameter setting mode, you can press **MODE** to return to the selection mode.

To shift cursor

START




To modify data

START





To switch display mode

START




To copy parameters 1

Copy parameters from the AC Motor Drive to the KPV-CE01




To copy parameters 2

Copy parameters from the KPV-CE01 to the AC Motor Drive



3.1.3 Dimension of the Digital Keypad

Unit: mm [inch]



3.1.4 Reference Table for the LCD Display of the Digital Keypad

Digital	0	1	2	3	4	5	6	7	8	9
LCD	0	1	2	3	4	5	6	7	8	9


English alphabet	A	b	Cc	d	E	F	G	Hh	I	Jj
LCD	A	b	Cc	d	E	F	G	Hh	I	Jj

English alphabet	K	L	n	Oo	P	q	r	S	Tt	U
LCD	K	L	n	Oo	P	q	r	S	Tt	U

English alphabet	v	Y	Z							
LCD	v	Y	Z							

3.1.5 Operation Method

Refer to 3.1.2 How to operate the digital keypad KPV-CE01 and chapter 4 parameters for setting. Please choose a suitable method depending on application and operation rule. The operation is usually used as shown in the following table.


Operation Method	Frequency Source	Operation Command Source
KPV-CE01 keypad	 	 
Operate from external signal	Factory setting: SINK Mode Sink Sw1 Source  * Don't apply the mains voltage directly to above terminals. Power supply +10V 20mA Master Frequency 0 to 10V 47KΩ ACI current/voltage selection 0-10V 0-20mA AFM analog output selection 0-20mA 0-10V Legend:  Main circuit (power) terminals  Control circuit terminals  Shielded leads & Cable NOTE: Please turn off the power when setting J4, J5 and J8.	
Operate from communication	Please refer to the communication address 2000H and 2119H settings in the communication address definition.	

3.2 Start-up

3.2.1 Preparations before Start-up

Carefully check the following items before proceeding.

- Make sure that the wiring is correct. In particular, check that the output terminals U, V, W. are NOT connected to power and that the drive is well grounded.
- Verify that there are no short-circuits between terminals and from terminals to ground or mains power.
- Check for loose terminals, connectors or screws.
- Verify that no other equipment is connected to the AC motor
- Make sure that all switches are OFF before applying power to ensure that the AC motor drive doesn't start running and there is no abnormal operation after applying power.
- Make sure that the front cover is well installed before applying power.
- Do NOT operate the AC motor drive with humid hands.
- The keypad should light up as follows (normal status with no error)




- If the drive has built-in fan (2hp/1.5kW and above) it should run. The factory setting of Fan Control Pr.07-15=00 (Fan always on).

3.2.2 Trial Run

After finishing checking the items in “3.2.1 preparation before start-up”, you can perform a trial run. The factory setting of operation source is from keypad (Pr.00-20=00).

- After applying power, verify that LED “F” is on and the display shows 60.00Hz.
- Setting frequency to about 5Hz by using  key.
- Pressing  key for forward running.
And if you want to change to reverse running, you should press  key. The LED will display the status. And if you want to decelerate to stop, please press  key.
- Check following items:
 - Check if the motor direction of rotation is correct.
 - Check if the motor runs steadily without abnormal noise and vibration.
 - Check if acceleration and deceleration are smooth.

If the results of trial run are normal, please start formal run.



**NOTE**

1. Please stop running immediately if any fault occurs and refer to troubleshooting for solving the problem.
2. Please do NOT touch output terminals U, V, W when power is still applied to L1/R, L2/S, L3/T even when the AC motor drive has stopped. The DC-link capacitors may still be charged to hazardous voltage levels, even if the power has been turned off.
3. To avoid damage to components, do not touch them or the circuit boards with metal objects or your bare hands.

This page intentionally left blank.

Chapter 4 Parameters

The VFD-VE parameters are divided into 12 groups by property for easy setting. In most applications, the user can finish all parameter settings before start-up without the need for re-adjustment during operation.

The 12 groups are as follows:

Group 0: System Parameters

Group 1: Basic Parameters

Group 2: Digital Input/Output Parameters

Group 3: Analog Input/Output Parameters

Group 4: Multi-Step Speed Parameters

Group 5: Motor Parameters

Group 6: Protection Parameters

Group 7: Special Parameters

Group 8: High-function PID Parameters

Group 9: Communication Parameters

Group 10: Speed Feedback Control Parameters

Group 11: Advanced Parameters

4.1 Summary of Parameter Settings

↗: The parameter can be set during operation.

Group 0 System Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFG	SVC	FOCPG	TQRP
00-00	Identity Code of the AC motor drive	Read-only	0	○	○	○	○	○
00-01	Rated Current Display of the AC motor drive	Read-only	0	○	○	○	○	○
00-02	Parameter Reset	0: No function 1: Read only 2: Enable group 11 parameters setting 8: Keypad lock 9: All parameters are reset to factory settings (50Hz, 220V/380V) 10: All parameters are reset to factory settings (60Hz, 220V/440V)	0	○	○	○	○	○
↗00-03	Start-up Display Selection	0: Display the frequency command value (LED F) 1: Display the actual output frequency (LED H) 2: Display the output current (A) 3: Multifunction display, see Pr.00-04	0	○	○	○	○	○
↗00-04	Content of Multi Function Display	0: Display output current (A) 1: Display counter value (C) 2: Display output frequency (H) 3: Display DC-BUS voltage (V) 4: Display output voltage (E) 5: Output power factor angle (n) 6: Display output power (kW) 7: Display actual motor speed (HU) 8: Display estimate output torque (kg-m) 9: Display PG position 10: Display PID feedback 11: Display AVI (%) 12: Display ACI (%) 13: Display AUI (%) 14: Display the temperature of heat sink (°C) 15: Display the temperature of IGBT (°C) 16: The status of digital input (ON/OFF) 17: The status of digital output (ON/OFF) 18: Multi-step speed 19: The corresponding CPU pin status of digital input 20: The corresponding CPU pin status of digital output 21: Encoder position (PG1 of PG card) 22: Pulse input frequency (PG2 of PG card) 23: Pulse input position (PG2 of PG card)	0	○	○	○	○	○
↗00-05	User-Defined Coefficient K	Digit 4: decimal point number (0 to 3) Digit 0-3: 40 to 9999	0	○	○	○	○	○
00-06	Software Version	Read-only	##	○	○	○	○	○
↗00-07	Password Input	1 to 9998 and 10000 to 65535 0 to 2: times of wrong password	0	○	○	○	○	○
↗00-08	Password Set	1 to 9998 and 10000 to 65535 0: No password set or successful input in Pr.00-07 1: Password has been set	0	○	○	○	○	○
↗00-09	Energy Saving Gain	10~1000 %	100%				○	
00-10	Control Method	0: V/f Control 1: V/f Control + Encoder (VFG) 2: Sensorless vector control (SVC) 3: FOC vector control + Encoder (FOCPG) 4: Torque control + Encoder (TQRP)	0	○	○	○	○	○
00-11	V/f Curve Selection	0: V/f curve determined by group 01 1: 1.5 power curve 2: Square curve	0	○	○			
↗00-12	Constant/Variable Torque Selection	0: Constant Torque (100%) 1: Variable Torque (125%)	0	○	○	○	○	
↗00-13	Optimal Acceleration/Deceleration Setting	0: Linear accel./decel. I 1: Auto accel., linear decel. 2: Linear accel., auto decel. 3: Auto accel./decel. I 4: Stall prevention by auto accel./decel. (limited by 01-	0	○	○	○	○	

Pr.	Explanation	Settings	Factory Setting	VF	VFG	SVC	FOCPG	TQRP
		12 to 01-21)						
00-14	Time Unit for Acceleration/Deceleration and S Curve	0: Unit: 0.01 second 1: Unit: 0.1 second	0	☐	☐	☐	☐	
00-15	Reserved							
00-16	Reserved							
00-17	Carrier Frequency	1~15KHz	10	☐	☐	☐	☐	☐
00-18	Auto Voltage Regulation (AVR) Function	0: Enable AVR 1: Disable AVR 2: Disable AVR when deceleration stop	0	☐	☐	☐	☐	☐
00-19	Auto Energy-saving Operation	0: Disable 1: Enable	0	☐	☐	☐	☐	
00-20	Source of the Master Frequency Command	0: Digital keypad (KPV-CE01) 1: RS-485 serial communication 2: External analog input (Pr. 03-00) 3: External UP/DOWN terminal 4: Pulse input without direction command (Pr.10-15 without direction) 5: Pulse input with direction command (Pr.10-15)	0	☐	☐	☐	☐	
00-21	Source of the Operation Command	0: Digital keypad (KPV-CE01) 1: External terminals. Keypad STOP disabled. 2: RS-485 serial communication (RJ-11). Keypad STOP disabled.	0	☐	☐	☐	☐	☐
00-22	Stop Method	0: Ramp to stop 1: Coast to stop	0	☐	☐	☐	☐	☐
00-23	Reverse Operation	0: Enable reverse 1: Disable reverse 2: Disable forward	0	☐	☐	☐	☐	☐

Group 1 Basic Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFP	SVC	FOCPG	TQPRG
01-00	Maximum Output Frequency	50.00~600.00Hz	60.00/50.00	○	○	○	○	○
01-01	1st Output Frequency Setting 1	0.00~600.00Hz	60.00/50.00	○	○	○	○	○
01-02	1st Output Voltage Setting 1	230V: 0.1V~255.0V 460V: 0.1V~510.0V	220.0/440.0	○	○	○	○	○
01-03	2nd Output Frequency Setting 1	0.00~600.00Hz	0.50	○	○			
01-04	2nd Output Voltage Setting 1	230V: 0.1V~255.0V 460V: 0.1V~510.0V	5.0/10.0	○	○			
01-05	3rd Output Frequency Setting 1	0.00~600.00Hz	0.50	○	○			
01-06	3rd Output Voltage Setting 1	230V: 0.1V~255.0V 460V: 0.1V~510.0V	5.0/10.0	○	○			
01-07	4th Output Frequency Setting 1	0.00~600.00Hz	0.00	○	○	○	○	○
01-08	4th Output Voltage Setting 1	230V: 0.1V~255.0V 460V: 0.1V~510.0V	0.0/0.0	○	○			
01-09	Start Frequency	0.00~600.00Hz	0.50	○	○	○	○	
01-10	Output Frequency Upper Limit	0.00~600.00Hz	600.00	○	○	○	○	
01-11	Output Frequency Lower Limit	0.00~600.00Hz	0.00	○	○	○	○	
01-12	Accel Time 1	0.00~600.00 sec/0.00~6000.0 sec	10.00/10.0	○	○	○	○	
01-13	Decel Time 1	0.00~600.00 sec/0.00~6000.0 sec	10.00/10.0	○	○	○	○	
01-14	Accel Time 2	0.00~600.00 sec/0.00~6000.0 sec	10.00/10.0	○	○	○	○	
01-15	Decel Time 2	0.00~600.00 sec/0.00~6000.0 sec	10.00/10.0	○	○	○	○	
01-16	Accel Time 3	0.00~600.00 sec/0.00~6000.0 sec	10.00/10.0	○	○	○	○	
01-17	Decel Time 3	0.00~600.00 sec/0.00~6000.0 sec	10.00/10.0	○	○	○	○	
01-18	Accel Time 4	0.00~600.00 sec/0.00~6000.0 sec	10.00/10.0	○	○	○	○	
01-19	Decel Time 4	0.00~600.00 sec/0.00~6000.0 sec	10.00/10.0	○	○	○	○	
01-20	JOG Acceleration Time	0.00~600.00 sec/0.00~6000.0 sec	1.00/1.0	○	○	○	○	
01-21	JOG Deceleration Time	0.00~600.00 sec/0.00~6000.0 sec	1.00/1.0	○	○	○	○	
01-22	JOG Frequency	0.00~600.00Hz	6.00	○	○	○	○	○
01-23	1st/4th Accel/decel Frequency	0.00~600.00Hz	0.00	○	○	○	○	
01-24	S-curve for Acceleration Departure Time 1	0.00~25.00 sec/0.00~250.0 sec	0.2/0.0	○	○	○	○	
01-25	S-curve for Acceleration Arrival Time 2	0.00~25.00 sec /0.00~250.0 sec	0.2/0.0	○	○	○	○	
01-26	S-curve for Deceleration Departure Time 1	0.00~25.00 sec /0.00~250.0 sec	0.2/0.0	○	○	○	○	
01-27	S-curve for Deceleration Arrival Time 2	0.00~25.00 sec /0.00~250.0 sec	0.2/0.0	○	○	○	○	
01-28	Skip Frequency 1 (upper limit)	0.00~600.00Hz	0.00	○	○	○	○	
01-29	Skip Frequency 1 (lower limit)	0.00~600.00Hz	0.00	○	○	○	○	
01-30	Skip Frequency 2 (upper limit)	0.00~600.00Hz	0.00	○	○	○	○	
01-31	Skip Frequency 2 (lower limit)	0.00~600.00Hz	0.00	○	○	○	○	
01-32	Skip Frequency 3 (upper limit)	0.00~600.00Hz	0.00	○	○	○	○	
01-33	Skip Frequency 3 (lower limit)	0.00~600.00Hz	0.00	○	○	○	○	
01-34	Zero-speed Mode Selection	0: Output Waiting 1: Zero-speed operation 2: Fmin (4th output frequency setting)	0	○	○	○	○	
01-35	1st Output Frequency Setting 2	0.00~600.00Hz	60.00/50.00	○	○	○	○	○

Pr.	Explanation	Settings	Factory Setting	VF	VFPF	SVC	FOCPG	TQRP
01-36	1st Output Voltage Setting 2	230V: 0.1V~255.0V 460V: 0.1V~510.0V	220.0 440.0	☐	☐	☐	☐	☐
01-37	2nd Output Frequency Setting 2	0.00~600.00Hz	0.50	☐	☐	☐	☐	☐
01-38	2nd Output Voltage Setting 2	230V: 0.1V~255.0V 460V: 0.1V~510.0V	5.0/ 10.0	☐	☐	☐	☐	☐
01-39	3rd Output Frequency Setting 2	0.00~600.00Hz	0.50	☐	☐	☐	☐	☐
01-40	3rd Output Voltage Setting 2	230V: 0.1V~255.0V 460V: 0.1V~510.0V	5.0/ 10.0	☐	☐	☐	☐	☐
01-41	4th Output Frequency Setting 2	0.00~600.00Hz	0.00	☐	☐	☐	☐	☐
01-42	4th Output Voltage Setting 2	230V: 0.1V~255.0V 460V: 0.1V~510.0V	0.0/ 0.0	☐	☐	☐	☐	☐

Group 2 Digital Input/Output Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFP	SVC	FOCPG	TQRP
02-00	2-wire/3-wire Operation Control	0: FWD/STOP, REV/STOP 1: FWD/STOP, REV/STOP (Line Start Lockout) 2: RUN/STOP, REV/FWD 3: RUN/STOP, REV/FWD (Line Start Lockout) 4: 3-wire (momentary push button) 5: 3-wire (momentary push button and Line Start Lockout)	0	☐	☐	☐	☐	☐
02-01	Multi-Function Input Command 1 (MI1) (it is Stop terminal for 3-wire operation)	0: no function 1: multi-step speed command 1/multi-step position command 1 2: multi-step speed command 2/ multi-step position command 2	1	☐	☐	☐	☐	☐
02-02	Multi-Function Input Command 2 (MI2)	3: multi-step speed command 3/ multi-step position command 3 4: multi-step speed command 4/ multi-step position command 4	2	☐	☐	☐	☐	☐
02-03	Multi-Function Input Command 3 (MI3)	5: Reset 6: JOG command	3	☐	☐	☐	☐	☐
02-04	Multi-Function Input Command 4 (MI4)	7: acceleration/deceleration speed inhibit 8: the 1st, 2nd acceleration/deceleration time selection	4	☐	☐	☐	☐	☐
02-05	Multi-Function Input Command 5 (MI5)	9: the 3rd, 4th acceleration/deceleration time selection 10: EF input (07-36)	0	☐	☐	☐	☐	☐
02-06	Multi-Function Input Command 6 (MI6) (specific terminal for TRG)	11: B.B. input 12: Output stop	0	☐	☐	☐	☐	☐
02-23	Multi-Function Input Command 7 (MI7)	13: cancel the setting of the optimal acceleration/deceleration time	0	☐	☐	☐	☐	☐
02-24	Multi-Function Input Command 8 (MI8)	14: switch between drive settings 1 and 2	0	☐	☐	☐	☐	☐
02-25	Multi-Function Input Command 9 (MI9)	15: operation speed command form AVI	0	☐	☐	☐	☐	☐
02-26	Multi-Function Input Command 10 (MI10)	16: operation speed command form ACI	0	☐	☐	☐	☐	☐
02-27	Multi-Function Input Command 11 (MI11)	17: operation speed command form AUI	0	☐	☐	☐	☐	☐
02-28	Multi-Function Input Command 12 (MI12)	18: Emergency Stop (07-36)	0	☐	☐	☐	☐	☐
02-29	Multi-Function Input Command 13 (MI13)	19: Digital Up command	0	☐	☐	☐	☐	☐
02-30	Multi-Function Input Command 14 (MI14)	20: Digital Down command	0	☐	☐	☐	☐	☐
		21: PID function disabled		☐	☐	☐	☐	☐
		22: clear counter		☐	☐	☐	☐	☐
		23: input the counter value (multi-function input command 6)		☐	☐	☐	☐	☐
		24: FWD JOG command		☐	☐	☐	☐	☐
		25: REV JOG command		☐	☐	☐	☐	☐
		26: TQC+PG/FOC+PG model selection		☐	☐	☐	☐	☐
		27: ASR1/ASR2 selection		☐	☐	☐	☐	☐
		28: Emergency stop (EF1)		☐	☐	☐	☐	☐
		29: Signal confirmation for Y-connection		☐	☐	☐	☐	☐
		30: Signal confirmation for Δ-connection		☐	☐	☐	☐	☐
		31: High torque bias (by Pr.07-29)		☐	☐	☐	☐	☐
		32: Middle torque bias (by Pr.07-30)		☐	☐	☐	☐	☐
		33: Low torque bias (by Pr.07-31)		☐	☐	☐	☐	☐
		34: Enable multi-step position control		☐	☐	☐	☐	☐
		35: Enable position control		☐	☐	☐	☐	☐
		36: Enable multi-step position input		☐	☐	☐	☐	☐
		37: Enable pulse position input command		☐	☐	☐	☐	☐
		38: Disable write EEPROM function		☐	☐	☐	☐	☐
		39: Torque command direction		☐	☐	☐	☐	☐
		40: Force stop		☐	☐	☐	☐	☐
		41: Serial position clock		☐	☐	☐	☐	☐
		42: Serial position input		☐	☐	☐	☐	☐
		43: Analog input resolution selection		☐	☐	☐	☐	☐

Pr.	Explanation	Settings	Factory Setting	VF	VFP	SVC	FOCPG	TQPRG
02-07	UP/DOWN Key Mode	0: up/down by the accel/decel time 1: up/down constant speed (Pr.02-08)	0	☐	☐	☐	☐	
02-08	The Acceleration/Deceleration Speed of the UP/DOWN Key with Constant Speed	0.01 ~ 1.00Hz/ms	0.01	☐	☐	☐	☐	
02-09	Digital Input Response Time	0.001 ~ 30.000 sec	0.005	☐	☐	☐	☐	☐
02-10	Digital Input Operation Direction	0 ~ 65535	0	☐	☐	☐	☐	☐
02-11	Multi-function Output 1 RA, RB, RC(Relay1)	0: No function 1: Operation indication	11	☐	☐	☐	☐	☐
02-12	Multi-function Output 2 MRA, MRC (Relay2)	2: Operation speed attained 3: Desired frequency attained 1 (Pr.02-19)	1	☐	☐	☐	☐	☐
02-13	Multi-function Output 3 (MO1)	4: Desired frequency attained 2 (Pr.02-21) 5: Zero speed (frequency command) 6: Zero speed with stop (frequency command) 7: Over torque (OT1) (Pr.06-06-06-08) 8: Over torque (OT2) (Pr.06-09-06-11)	0	☐	☐	☐	☐	☐
02-14	Multi-function Output 4 (MO2)	9: Drive ready 10: User-defined Low-voltage Detection 11: Malfunction indication 12: Mechanical brake release (Pr.02-31) 13: Overheat 14: Software braking signal 15: PID feedback error 16: Slip error (oSL) 17: Terminal count value attained (Pr.02-16) 18: Preliminary count value attained (Pr.02-17) 19: Baseblock (B.B.) Indication 20: Warning output 21: Over voltage warning 22: Over-current stall prevention warning 23: Over-voltage stall prevention warning 24: Operation mode indication 25: Forward command 26: Reverse command 27: Output when current >= Pr.02-32 28: Output when current < Pr.02-32 29: Output when frequency >= Pr.02-33 30: Output when frequency < Pr.02-33 31: Y-connection for the motor coil 32: Δ connection for the motor coil 33: Zero speed (actual output frequency) 34: Zero speed with Stop (actual output frequency) 35: Error output selection 1 (Pr.06-23) 36: Error output selection 2 (Pr.06-24) 37: Error output selection 3 (Pr.06-25) 38: Error output selection 4 (Pr.06-26) 39: Position attained (Pr.10-19) 40: Speed attained (including zero speed)	0	☐	☐	☐	☐	☐
02-15	Multi-output Direction	0 ~ 65535	0	☐	☐	☐	☐	☐
02-16	Terminal Count Value	0 ~ 65535	0	☐	☐	☐	☐	☐
02-17	Preliminary Counter Value	0 ~ 65535	0	☐	☐	☐	☐	☐
02-18	Digital Output Gain	1 ~ 40	1	☐	☐	☐	☐	☐
02-19	Desired Frequency Attained 1	0.00 ~ 600.00Hz	60.00/50.00	☐	☐	☐	☐	☐
02-20	The Width of the Desired Frequency Attained 1	0.00 ~ 600.00Hz	2.00	☐	☐	☐	☐	☐
02-21	Desired Frequency Attained 2	0.00 ~ 600.00Hz	60.00/50.00	☐	☐	☐	☐	☐
02-22	The Width of the Desired Frequency Attained 2	0.00 ~ 600.00Hz	2.00	☐	☐	☐	☐	☐

Pr.	Explanation	Settings	Factory Setting	VF	VFP	SVC	FOCPG	TQRP
02-31	Brake Delay Time	0.000~65.000 Sec	0	☐	☐	☐	☐	☐
↗02-32	Output Current Level Setting for External Terminals	0~100%	0	☐	☐	☐	☐	☐
↗02-33	Output Boundary for External Terminals	0.00~+60.00Hz (it is motor speed when using PG)	0.00	☐	☐	☐	☐	☐
↗02-34	External Operation Control Selection after Reset	0: Disable 1: Drive runs if run command exists after reset	0	☐	☐	☐	☐	☐

Group 3 Analog Input/Output Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFP	SVC	FOCPG	TQRP
03-00	Analog Input 1 (AVI)	0: No function	1	☐	☐	☐	☐	☐
03-01	Analog Input 2 (ACI)	1: Frequency command (torque limit under TQR control mode)	0	☐	☐	☐	☐	☐
03-02	Analog Input 3 (AUI)	2: torque command (torque limit under speed mode)	0	☐	☐	☐	☐	☐
		3: Torque compensation command		☐	☐	☐	☐	☐
		4: PID target value (refer to group 8)		☐	☐	☐	☐	☐
		5: PID feedback signal (refer to group 8)		☐	☐	☐	☐	☐
		6: P.T.C.thermistor input value		☐	☐	☐	☐	☐
		7: Positive torque limit		☐	☐	☐	☐	☐
		8: Negative torque limit		☐	☐	☐	☐	☐
		9: Regenerative torque limit		☐	☐	☐	☐	☐
		10: Positive/negative torque limit		☐	☐	☐	☐	☐
03-03	Analog Input Bias 1 (AVI)	-100.0~100.0%	0	☐	☐	☐	☐	☐
03-04	Analog Input Bias 2 (ACI)	-100.0~100.0%	0	☐	☐	☐	☐	☐
03-05	Analog Input Bias 3 (AUI)	-100.0~100.0%	0	☐	☐	☐	☐	☐
03-06	Positive/negative Bias Mode (AVI)	0: Zero bias	0	☐	☐	☐	☐	☐
03-07	Positive/negative Bias Mode (ACI)	1: Lower than bias=bias	0	☐	☐	☐	☐	☐
03-08	Positive/negative Bias Mode (AUI)	2: Greater than bias=bias	0	☐	☐	☐	☐	☐
		3: The absolute value of the bias voltage while serving as the center		☐	☐	☐	☐	☐
		4: Serve bias as the center		☐	☐	☐	☐	☐
03-09	Analog Input Gain 1 (AVI)	-500.0~500.0%	100.0	☐	☐	☐	☐	☐
03-10	Analog Input Gain 2 (ACI)	-500.0~500.0%	100.0	☐	☐	☐	☐	☐
03-11	Analog Input Gain 3 (AUI)	-500.0~500.0%	100.0	☐	☐	☐	☐	☐
03-12	ACI/AVI2 Selection	0: ACI 1: AVI 2	0	☐	☐	☐	☐	☐
03-13	Analog Input Delay Time (AVI)	0.00~2.00 sec	0.01	☐	☐	☐	☐	☐
03-14	Analog Input Delay Time (ACI)	0.00~2.00 sec	0.01	☐	☐	☐	☐	☐
03-15	Analog Input Delay Time (AUI)	0.00~2.00 sec	0.01	☐	☐	☐	☐	☐
03-16	Addition Function of the Analog Input	0: Disable (AVI, ACI, AUI) 1: Enable		☐	☐	☐	☐	☐
03-17	Loss of the ACI Signal	0: Disable 1: Continue operation at the last frequency 2: Decelerate to stop 3: Stop immediately and display E.F.	0	☐	☐	☐	☐	☐
03-18	Analog Output Selection	0: Output frequency (Hz)	0	☐	☐	☐	☐	☐
		1: Frequency command (Hz)		☐	☐	☐	☐	☐
		2: Motor speed (Hz)		☐	☐	☐	☐	☐
		3: Output current (rms)		☐	☐	☐	☐	☐
		4: Output voltage		☐	☐	☐	☐	☐
		5: DC Bus Voltage		☐	☐	☐	☐	☐
		6: Power factor		☐	☐	☐	☐	☐
		7: Power		☐	☐	☐	☐	☐
		8: Output torque		☐	☐	☐	☐	☐
		9: AVI		☐	☐	☐	☐	☐
		10: ACI		☐	☐	☐	☐	☐
		11: AUI		☐	☐	☐	☐	☐
		12: q-axis current		☐	☐	☐	☐	☐
		13: q-axis feedback value		☐	☐	☐	☐	☐
		14: d-axis current		☐	☐	☐	☐	☐
		15: d-axis feedback value		☐	☐	☐	☐	☐
		16: q-axis voltage		☐	☐	☐	☐	☐
		17: d-axis voltage		☐	☐	☐	☐	☐
		18: Torque command		☐	☐	☐	☐	☐

Pr.	Explanation	Settings	Factory Setting	VF	VFP	SVC	FOCP	TQRP
		19: Pulse frequency command		☐	☐	☐	☐	☐
03-19	Analog Output Gain	0-200.0%	100.0	☐	☐	☐	☐	☐
03-20	Analog Output Value in REV Direction	0: Absolute value in REV direction 1: Output 0V in REV direction 2: Output negative voltage in REV direction	0	☐	☐	☐	☐	☐

Group 4 Multi-Step Speed Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFP	SVC	FOCPG	TQPRG
↗04-00	1st Step Speed Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗04-01	2nd Step Speed Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗04-02	3rd Step Speed Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗04-03	4th Step Speed Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗04-04	5th Step Speed Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗04-05	6th Step Speed Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗04-06	7th Step Speed Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗04-07	8th Step Speed Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗04-08	9th Step Speed Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗04-09	10th Step Speed Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗04-10	11th Step Speed Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗04-11	12th Step Speed Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗04-12	13th Step Speed Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗04-13	14th Step Speed Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗04-14	15th Step Speed Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗04-15	Multi-position 1	0~65535	0		☐		☐	
↗04-16	Multi-position 2	0~65535	0		☐		☐	
↗04-17	Multi-position 3	0~65535	0		☐		☐	
↗04-18	Multi-position 4	0~65535	0		☐		☐	
↗04-19	Multi-position 5	0~65535	0		☐		☐	
↗04-20	Multi-position 6	0~65535	0		☐		☐	
↗04-21	Multi-position 7	0~65535	0		☐		☐	
↗04-22	Multi-position 8	0~65535	0		☐		☐	
↗04-23	Multi-position 9	0~65535	0		☐		☐	
↗04-24	Multi-position 10	0~65535	0		☐		☐	
↗04-25	Multi-position 11	0~65535	0		☐		☐	
↗04-26	Multi-position 12	0~65535	0		☐		☐	
↗04-27	Multi-position 13	0~65535	0		☐		☐	
↗04-28	Multi-position 14	0~65535	0		☐		☐	
↗04-29	Multi-position 15	0~65535	0		☐		☐	

Group 5 Motor Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFP	SVC	FOCPG	TQRP
05-00	Motor Auto Tuning	0: No function 1: Rolling test 2: Static Test 3: Static Test (Shaft locked axis-3 phase)	0			○	○	○
05-01	Full-load Current of Motor 1	40-100%	90%	○	○	○	○	○
↗05-02	Rated power of Motor 1	0-655.35	#.##			○	○	○
↗05-03	Rated speed of Motor 1 (rpm)	0-65535	1710		○	○	○	○
05-04	Number of Motor Poles 1	2~20	4	○	○	○	○	○
05-05	No-load Current of Motor 1	0-100%	40%		○	○	○	○
05-06	Rotor Resistance R1 of Motor 1	0-65.535Ω	0.000			○	○	○
05-07	Rr of Motor 1	0-65.535Ω	0.000			○	○	○
05-08	Lm of Motor 1	0-6553.5mH	0.0			○	○	○
05-09	Lx of Motor 1	0-6553.5mH	0.0			○	○	○
05-10	Motor 1/Motor 2 Selection	1: Motor 1 2: Motor 2	1	○	○	○	○	○
↗05-11	Frequency for Y-connection/ Δ-connection Switch	0.00~600.00Hz	60.00	○	○	○	○	
05-12	Y-connection /Δ-connection Switch	0: Disable 1: Enable	0	○	○	○	○	
05-13	Full-load Current of Motor 2	40-100%	90%	○	○	○	○	○
↗05-14	Rated Power of Motor 2	0-655.35	#.##			○	○	○
↗05-15	Rated Speed of Motor 2 (rpm)	0-65535	1710		○	○	○	○
05-16	Number of Motor Poles 2	2~20	4	○	○	○	○	○
05-17	No-load Current of Motor 2	0-100%	40%		○	○	○	○
05-18	Rs of Motor 2	0-65.535Ω	0.000			○	○	○
05-19	Rr of Motor 2	0-65.535Ω	0.000			○	○	○
05-20	Lm of Motor 2	0-6553.5mH	0.0			○	○	○
05-21	Lx of Motor 2	0-6553.5mH	0.0			○	○	○
↗05-22	Torque Compensation Time Constant	0.001~10.000sec	0.020			○		
↗05-23	Slip Compensation Time Constant	0.001~10.000sec	0.100			○		
↗05-24	Torque Compensation Gain	0~10	0	○	○			
↗05-25	Slip Compensation Gain	0.00~10.00	0.00	○	○			
↗05-26	Slip Deviation Level	0~1000% (0: disable)	0		○	○	○	
↗05-27	Detection Time of Slip Deviation	0.0~10.0 sec	1.0		○	○	○	
↗05-28	Over Slip Treatment	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop	0		○	○	○	
↗05-29	Hunting Gain	0~10000 (0: disable)	2000	○	○	○		
↗05-30	Delay Time for Y-connection/Δ-connection	0~60.000 sec	0.200	○	○	○	○	
05-31	Accumulative Motor Operation Time (Min.)	00~1439	0	○	○	○	○	○
05-32	Accumulative Motor Operation Time (day)	00~65535	0	○	○	○	○	○

Group 6 Protection Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFP	SVC	FOCPG	TQRP
06-00	Low Voltage Level	160.0~220.0Vdc	180.0	☐	☐	☐	☐	☐
		320.0~440.0Vdc	360.0	☐	☐	☐	☐	☐
06-01	Over-voltage Stall Prevention	350.0~450.0Vdc	380.0	☐	☐	☐	☐	☐
		700.0~900.0Vdc	760.0	☐	☐	☐	☐	☐
06-02	Phase-loss Protection	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop	0	☐	☐	☐	☐	☐
06-03	Over-current Stall Prevention during Acceleration	00~250%	170	☐	☐	☐		
06-04	Over-current Stall Prevention during Operation	00~250%	170	☐	☐	☐		
06-05	Accel./Decel. Time Selection of Stall Prevention at constant speed	0: by current accel/decel time 1: by the 1st accel/decel time 2: by the 2nd accel/decel time 3: by the 3rd accel/decel time 4: by the 4th accel/decel time 5: by auto accel/decel time	0	☐	☐	☐		
06-06	Over-torque Detection Selection (OT1)	0: disable 1: over-torque detection during constant speed operation, continue to operate after detection 2: over-torque detection during constant speed operation, stop operation after detection 3: over-torque detection during operation, continue to operate after detection 4: over-torque detection during operation, stop operation after detection	0	☐	☐	☐	☐	☐
06-07	Over-torque Detection Level (OT1)	10~250%	150	☐	☐	☐	☐	☐
06-08	Over-torque Detection Time (OT1)	0.0~60.0 sec	0.1	☐	☐	☐	☐	☐
06-09	Over-torque Detection Selection (OT2)	0: disable 1: over-torque detection during constant speed operation, continue to operate after detection 2: over-torque detection during constant speed operation, stop operation after detection 3: over-torque detection during operation, continue to operate after detection 4: over-torque detection during operation, stop operation after detection	0	☐	☐	☐	☐	☐
06-10	Over-torque Detection Level (OT2)	10~250%	150	☐	☐	☐	☐	☐
06-11	Over-torque Detection Time (OT2)	0.0~60.0 sec	0.1	☐	☐	☐	☐	☐
06-12	Current Limit	0~250%	150				☐	☐
06-13	Electronic Thermal Relay Selection (Motor 1)	0: Inverter motor 1: Special motor 2: Disable	2	☐	☐	☐	☐	☐
06-14	Electronic Thermal Characteristic for Motor 1	30.0~600.0 sec	60.0	☐	☐	☐	☐	☐
06-15	Heat Sink Over-heat (OH) Warning	0.0~110.0℃	85.0	☐	☐	☐	☐	☐
06-16	Stall Prevention Limit Level	0~100% (refer to Pr.06-03, Pr.06-04)	50	☐	☐	☐		
06-17	Present Fault Record	0: No fault	0	☐	☐	☐	☐	☐
06-18	Second Most Recent Fault Record	1: Over-current during acceleration (ocA) 2: Over-current during deceleration (ocd)	0	☐	☐	☐	☐	☐
06-19	Third Most Recent Fault Record	3: Over-current during constant speed (ocn) 4: Ground fault (GFF)	0	☐	☐	☐	☐	☐
06-20	Fourth Most Recent Fault Record	5: IGBT short-circuit (occ) 6: Over-current at stop (ocS)	0	☐	☐	☐	☐	☐
06-21	Fifth Most Recent Fault Record	7: Over-voltage during acceleration (ovA) 8: Over-voltage during deceleration (ovd)	0	☐	☐	☐	☐	☐
06-22	Sixth Most Recent Fault Record	9: Over-voltage during constant speed (ovn) 10: Over-voltage at stop (ovS)	0	☐	☐	☐	☐	☐

Pr.	Explanation	Settings	Factory Setting	VF	VFP	SVC	FOCPG	TQRP
		11: Low-voltage during acceleration (LvA) 12: Low-voltage during deceleration (Lvd) 13: Low-voltage during constant speed (Lvn) 14: Low-voltage at stop (LvS) 15: Phase loss (PHL) 16: IGBT heat sink over-heat (oH1) 17: Heat sink over-heat (oH2)(for 40HP above) 18: TH1 open loop error (tH1o) 19: TH2 open loop error (tH2o) 20: Fan error signal output 21: over-load (oL) (150% 1Min) 22: Motor 1 over-load (EoL1) 23: Motor 2 over-load (EoL2) 24: Motor PTC overheat (oH3) 25: Fuse error (FuSE) 26: over-torque 1 (ot1) 27: over-torque 1 (ot2) 28: Insufficient torque 1 29: Insufficient torque 2 30: Memory write-in error (cF1) 31: Memory read-out error (cF2) 32: Isum current detection error (cd0) 33: U-phase current detection error (cd1) 34: V-phase current detection error (cd2) 35: W-phase current detection error (cd3) 36: Clamp current detection error (Hd0) 37: Over-current detection error (Hd1) 38: Over-voltage detection error (Hd2) 39: Ground current detection error (Hd3) 40: Auto tuning error (AuE) 41: PID feedback loss (AFE) 42: PG feedback error (PGF1) 43: PG feedback loss (PGF2) 44: PG feedback stall (PGF3) 45: PG slip error (PGF4) 46: PG ref input error (PGr1) 47: PG ref loss (PGr2) 48: Analog current input loss (ACE) 49: External fault input (EF) 50: Emergency stop (EF1) 51: External Base Block (B.B.) 52: Password error (PcodE) 53: Software error (ccodE) 54: Communication error (cE1) 55: Communication error (cE2) 56: Communication error (cE3) 57: Communication error (cE4) 58: Communication Time-out (cE10) 59: PU time-out (cP10) 60: Brake transistor error (bF) 61: Y-connection/Δ-connection switch error (ydc) 62: Decel. Energy Backup Error (dEb)						
✎06-23	Fault Output Option 1	0-65535 (refer to bit table for fault code)	0	○	○	○	○	○
✎06-24	Fault Output Option 2	0-65535 (refer to bit table for fault code)	0	○	○	○	○	○
✎06-25	Fault Output Option 3	0-65535 (refer to bit table for fault code)	0	○	○	○	○	○
✎06-26	Fault Output Option 4	0-65535 (refer to bit table for fault code)	0	○	○	○	○	○
✎06-27	Electronic Thermal Relay Selection (Motor 2)	0: Inverter motor 1: Special motor 2: Disable	2	○	○	○	○	○
✎06-28	Electronic Thermal Characteristic for Motor 2	30.0~600.0 sec	60.0	○	○	○	○	○
✎06-29	PTC (Positive Temperature Coefficient) Detection Selection	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop	0	○	○	○	○	○
✎06-30	PTC Level	0.0~100.0%	50.0	○	○	○	○	○
✎06-31	Filter Time for PTC Detection	0.00~10.00sec	0.20	○	○	○	○	○

Group 7 Special Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFP	SVC	FOCP	TORP
07-00	Software Braking Level	230V: 350.0~450.0Vdc 460V: 700.0~900.0Vdc	380.0 760.0	☐	☐	☐	☐	☐
07-01	DC Braking Current Level	0~100%	0	☐	☐	☐	☐	☐
07-02	DC Braking Time during Start-up	0.0~60.0 sec	0.0	☐	☐	☐	☐	☐
07-03	DC Braking Time during Stopping	0.0~60.0 sec	0.0	☐	☐	☐	☐	☐
07-04	Start-point for DC Braking	0.00~600.00Hz	0.00	☐	☐	☐	☐	☐
07-05	DC Braking Voltage Gain	1~500	50	☐	☐	☐	☐	☐
07-06	Momentary Power Loss Operation Selection	0: Operation stop after momentary power loss 1: Operation continues after momentary power loss, speed search starts with the Master Frequency reference value 2: Operation continues after momentary power loss, speed search starts with the minimum frequency	0	☐	☐	☐	☐	☐
07-07	Maximum Allowable Power Loss Time	0.1~5.0 sec	2.0	☐	☐	☐	☐	☐
07-08	B.B. Time for Speed Search	0.1~5.0 sec	0.5	☐	☐	☐	☐	☐
07-09	Current Limit for Speed Search	20~200%	150	☐	☐	☐	☐	☐
07-10	Base-block Speed Search	0: Stop operation 1: Speed search starts with last frequency command 2: Speed search starts with minimum output frequency	0	☐	☐	☐	☐	☐
07-11	Auto Restart after Fault	0~10	0	☐	☐	☐	☐	☐
07-12	Speed Search during Start-up	0: Disable 1: Speed search from maximum frequency 2: Speed search from start-up frequency 3: Speed search from minimum frequency	0	☐	☐	☐	☐	☐
07-13	Decel. Time Selection for Momentary Power Loss	0: Disable 1: 1 st decel. time 2: 2 nd decel. time 3: 3 rd decel. time 4: 4 th decel. time 5: Current decel. time 6: Auto decel. Time	0	☐	☐	☐	☐	☐
07-14	DEB Return Time	0.0~25.0 sec	0.0	☐	☐	☐	☐	☐
07-15	Dwell Time at Accel.	0.00~600.00sec	0.00	☐	☐	☐	☐	☐
07-16	Dwell Frequency at Accel.	0.00~600.00Hz	0.00	☐	☐	☐	☐	☐
07-17	Dwell Time at Decel.	0.00~600.00sec	0.00	☐	☐	☐	☐	☐
07-18	Dwell Frequency at Decel.	0.00~600.00Hz	0.00	☐	☐	☐	☐	☐
07-19	Fan Control	0: Fan always ON 1: 1 minute after AC motor drive stops, fan will be OFF 2: AC motor drive runs and fan ON, AC motor drive stops and fan OFF 3: Fan ON to run when preliminary heat sink temperature attained 4: Fan always OFF	0	☐	☐	☐	☐	☐
07-20	Torque Command	-100.0~100.0% (Pr. 07-22 setting=100%)	0.0	☐	☐	☐	☐	☐
07-21	Torque Command Source	0: Digital keypad 1: RS485 serial communication (RJ-11) 2: Analog signal (Pr.03-00)	0	☐	☐	☐	☐	☐
07-22	Maximum Torque Command	0~500%	100	☐	☐	☐	☐	☐
07-23	Filter Time of Torque Command	0.000~1.000 sec	0.000	☐	☐	☐	☐	☐
07-24	Speed Limit Selection	0: By Pr.07-25 and Pr.07-26 1: Frequency command source (Pr.00-20)	0	☐	☐	☐	☐	☐
07-25	Torque Mode +Speed Limit	0~120%	10	☐	☐	☐	☐	☐

Chapter 4 Parameters | **UFD-VE**

Pr.	Explanation	Settings	Factory Setting	VF	VFPF	SVC	FOCPG	TQRP
Pr. 07-26	Torque Mode-Speed Limit	0~120%	10					☐
Pr. 07-27	Source of Torque Offset	0: Disable 1: Analog input (Pr.03-00) 2: Torque offset setting 3: Control by external terminal (by Pr.07-29 to Pr.07-31)	0			☐	☐	☐
Pr. 07-28	Torque Offset Setting	0.0~100.0%	0.0			☐	☐	☐
Pr. 07-29	High Torque Offset	0.0~100.0%	30.0			☐	☐	☐
Pr. 07-30	Middle Torque Offset	0.0~100.0%	20.0			☐	☐	☐
Pr. 07-31	Low Torque Offset	0.0~100.0%	10.0			☐	☐	☐
Pr. 07-32	Forward Motor Torque Limit	0~500%	200				☐	☐
Pr. 07-33	Forward Regenerative Torque Limit	0~500%	200				☐	☐
Pr. 07-34	Reverse Motor Torque Limit	0~500%	200				☐	☐
Pr. 07-35	Reverse Regenerative Torque Limit	0~500%	200				☐	☐
Pr. 07-36	Emergency Stop (EF) & Forced Stop Selection	0: Coast stop 1: By deceleration Time 1 2: By deceleration Time 2 3: By deceleration Time 3 4: By deceleration Time 4 5: System Deceleration 6: Automatic Deceleration	0	☐	☐	☐	☐	☐

Group 8 High-function PID Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFP	SVC	FOCP	TORP
↗08-00	Input Terminal for PID Feedback	0: No function 1: Positive PID feedback from external terminal AVI (Pr.03-00) 2: Positive PID feedback from PG card (Pr.10-15, skip direction) 3: Positive PID feedback from PG card (Pr.10-15) 4: Negative PID feedback from external terminal AVI (Pr.03-00) 5: Negative PID feedback from PG card (Pr.10-15, skip direction) 6: Negative PID feedback from PG card (Pr.10-15)	0	☐	☐	☐	☐	
↗08-01	Proportional Gain (P)	0.0~500.0%	80.0	☐	☐	☐	☐	
↗08-02	Integral Gain (I)	0.00~100.00 sec	1.00	☐	☐	☐	☐	
↗08-03	Derivative Control (D)	0.00~1.00 sec	0.00	☐	☐	☐	☐	
↗08-04	Upper limit for Integral Control	0.0~100.0%	100.0	☐	☐	☐	☐	
↗08-05	PID Output Frequency Limit	0.0~110.0%	100.0	☐	☐	☐	☐	
↗08-06	PID Offset	-100.0~+100.0%	0.0	☐	☐	☐	☐	
↗08-07	PID Delay Time	0.0~2.5 sec	0.0	☐	☐	☐	☐	
↗08-08	Feedback Signal Detection Time	0.0~3600.0 sec	0.0	☐	☐	☐	☐	
↗08-09	Feedback Fault Treatment	0: Warn and keep operating 1: Warn and ramp to stop 2: Warn and coast to stop 3: Warn and keep at last frequency	0	☐	☐	☐	☐	
↗08-10	Sleep Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗08-11	Wake-up Frequency	0.00~600.00Hz	0.00	☐	☐	☐	☐	
↗08-12	Sleep Time	0.0~6000.0 sec	0.0	☐	☐	☐	☐	
↗08-13	PID Deviation Level	1.0~50.0%	10.0	☐	☐	☐	☐	
↗08-14	PID Deviation Time	0.1~300.0 sec	5.0	☐	☐	☐	☐	
↗08-15	Filter Time for PID Feedback	0.1~300.0 sec	5.0	☐	☐	☐	☐	

Chapter 4 Parameters | VFD-VE
Group 9 Communication Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFP	SVC	FOCP	TQRP
09-00	Communication Address	1~254	1	○	○	○	○	○
09-01	COM1 Transmission Speed	4.8~115.2Kbps	9.6	○	○	○	○	○
09-02	COM1 Transmission Fault Treatment	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop 3: No warning and keep operation	3	○	○	○	○	○
09-03	COM1 Time-out Detection	0.0~100.0 sec	0.0	○	○	○	○	○
09-04	COM1 Communication Protocol	0: 7N1 (ASCII) 1: 7N2 (ASCII) 2: 7E1 (ASCII) 3: 7O1 (ASCII) 4: 7E2 (ASCII) 5: 7O2 (ASCII) 6: 8N1 (ASCII) 7: 8N2 (ASCII) 8: 8E1 (ASCII) 9: 8O1 (ASCII) 10: 8E2 (ASCII) 11: 8O2 (ASCII) 12: 8N1 (RTU) 13: 8N2 (RTU) 14: 8E1 (RTU) 15: 8O1 (RTU) 16: 8E2 (RTU) 17: 8O2 (RTU)	1	○	○	○	○	○
09-05	COM2 Transmission Speed (Keypad)	4.8~115.2Kbps	9.6	○	○	○	○	○
09-06	COM2 Transmission Fault Treatment (Keypad)	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop 3: No warning and keep operation	0	○	○	○	○	○
09-07	COM2 Time-out Detection (Keypad)	0.0~100.0 sec	1.0	○	○	○	○	○
09-08	COM2 Communication Protocol (Keypad)	0: 7N1 (ASCII) 1: 7N2 (ASCII) 2: 7E1 (ASCII) 3: 7O1 (ASCII) 4: 7E2 (ASCII) 5: 7O2 (ASCII) 6: 8N1 (ASCII) 7: 8N2 (ASCII) 8: 8E1 (ASCII) 9: 8O1 (ASCII) 10: 8E2 (ASCII) 11: 8O2 (ASCII) 12: 8N1 (RTU) 13: 8N2 (RTU) 14: 8E1 (RTU) 15: 8O1 (RTU) 16: 8E2 (RTU) 17: 8O2 (RTU)	13	○	○	○	○	○
09-09	Response Delay Time	0.0~200.0ms	2.0	○	○	○	○	○
09-10	Transmission Master Frequency	0.00~600.00Hz	60.00	○	○	○	○	○
09-11	Block Transfer 1	0~65535	0	○	○	○	○	○
09-12	Block Transfer 2	0~65535	0	○	○	○	○	○
09-13	Block Transfer 3	0~65535	0	○	○	○	○	○
09-14	Block Transfer 4	0~65535	0	○	○	○	○	○
09-15	Block Transfer 5	0~65535	0	○	○	○	○	○
09-16	Block Transfer 6	0~65535	0	○	○	○	○	○
09-17	Block Transfer 7	0~65535	0	○	○	○	○	○
09-18	Block Transfer 8	0~65535	0	○	○	○	○	○
09-19	Block Transfer 9	0~65535	0	○	○	○	○	○
09-20	Block Transfer 10	0~65535	0	○	○	○	○	○

Group 10 Speed Feedback Control Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFPF	SVC	FOCPG	TQRP
10-00	Encoder Pulse	1~20000	600		○		○	○
10-01	Encoder Input Type Setting	0: Disable 1: Phase A leads in a forward run command and phase B leads in a reverse run command 2: Phase B leads in a forward run command and phase A leads in a reverse run command 3: Phase A is a pulse input and phase B is a direction input. (low input=reverse direction, high input=forward direction) 4: Phase A is a pulse input and phase B is a direction input. (low input=forward direction, high input=reverse direction) 5: Single-phase input	0		○		○	○
10-02	PG Feedback Fault Treatment	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop	2		○		○	○
10-03	Detection Time for PG Feedback Fault	0.00~10.0 sec	1.0		○		○	○
10-04	ASR (Auto Speed Regulation) Control (P) 1	0.0~1000.0%	100.0		○		○	○
10-05	ASR (Auto Speed Regulation) Control (I) 1	0.000~10.000 sec	0.100		○		○	○
10-06	ASR (Auto Speed Regulation) Control (P) 2	0.0~1000.0%	100.0		○		○	○
10-07	ASR (Auto Speed Regulation) Control (I) 2	0.000~10.000 sec	0.100		○		○	○
10-08	ASR 1/ASR2 Switch Frequency	0.00~600.00Hz (0: disable)	7.00				○	○
10-09	ASR Primary Low Pass Filter Gain	0.000~0.350 sec	0.008				○	○
10-10	PG Stall Level	0~120% (0: disable)	115		○	○	○	
10-11	PG Stall Detection Time	0.0~2.0 sec	0.1		○	○		
10-12	PG Slip Range	0~50% (0: disable)	10		○	○	○	
10-13	PG Slip Detection Time	0.0~10.0 sec	0.5		○	○	○	
10-14	PG Stall and Slip Error Treatment	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop	2		○	○	○	
10-15	Pulse Input Type Setting	0: Disable 1: Phase A leads in a forward run command and phase B leads in a reverse run command 2: Phase B leads in a forward run command and phase A leads in a reverse run command 3: Phase A is a pulse input and phase B is a direction input. (low input=reverse direction, high input=forward direction) 4: Phase A is a pulse input and phase B is a direction input. (low input=forward direction, high input=reverse direction)	0	○	○	○	○	○
10-16	Output Setting for Frequency Division (denominator)	1~255	1		○		○	○
10-17	PG Electrical Gear A (Channel 1 of PG card)	1~5000	100		○		○	
10-18	PG Electrical Gear B (Channel 2 of PG card)	1~5000	100		○		○	
10-19	PG Position Control Point (Home)	0~20000	0		○		○	
10-20	Range for PG Position Attained (Home range)	0~20000	10		○		○	
10-21	P Gain of Zero Speed	0.0~1000.0%	100.0		○		○	○

Chapter 4 Parameters | **UFD-VE**

Pr.	Explanation	Settings	Factory Setting	VF	VFP	SVC	FOCP	TQRP
10-22	I Gain of Zero Speed	0.000~10.000 sec	0.100		○		○	○
10-23	Feed Forward Gain of APR	0~100	30		○		○	
10-24	Decelerate Time of Position	0.00~600.00 sec/00~6000.0 sec	3.00 3.0		○		○	
10-25	Max. Frequency for Resolution Switch	50.00~600.00Hz	50.00	○	○	○	○	○
10-26	Reserved							
10-27	PG Mechanical Gear A	1~5000	100		○		○	
10-28	PG Mechanical Gear B	1~5000	100		○		○	

Group 11 Advanced Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFP	SVC	FOCPG	TQPRG
11-00	System Control	bit 0: ASR Auto tuning bit 1: Inertia estimate bit 2: Zero Servo bit 3: Invalid deadtime compensation	0				○	
11-01	Per Unit of System Inertia	1~65535 (256=1PU)	400				○	○
11-02	Low-speed Bandwidth	0~40Hz	10		○		○	○
11-03	High-speed Bandwidth	0~40Hz	10		○		○	○
11-04	PDF Gain Value	0~200%	30				○	
11-05	Gain Value of Flux Weakening Curve for Motor 1	0~200%	90				○	○
11-06	Gain Value of Flux Weakening Curve for Motor 2	0~200%	90				○	○
11-07	Detection Time for Phase-loss	0.00~600.00 sec	0.20	○	○	○	○	○
11-08	Reserved							
11-09	IGBT Overheat Level for 1-15hp	20.0~110.0°C	90.0	○	○	○	○	○
11-10	IGBT Overheat Level for 20-100hp	20.0~110.0°C	100.0	○	○	○	○	○
11-11	Zero-speed Bandwidth	0~40Hz	10		○		○	○
11-12	Speed Feed Forward	10~150%	65				○	
11-13	Notch Filter Depth	0~20db	0				○	
11-14	Notch Filter Frequency	0.00~200.00	0.00				○	
11-15	Gain Value of Slip Compensation	0.00~1.00	1.00			○		
11-16	Low-pass Filter Time of Keypad Display	0.001~65.535sec	0.100	○	○	○	○	○
11-17	Low-pass Filter Time of PG2 Pulse Input	0.000~65.535sec	0.100	○	○	○	○	
11-18 11-28	Reserved							
11-29	Accumulative Operation Time of Phase-loss	0~65535 (hour)	0	○	○	○	○	○
11-30	Reserved							

4.2 Description of Parameter Settings

Group 0 User Parameters

00-00	Identity Code of the AC motor drive	
Settings	Read Only	Factory setting: ##
00-01	Rated Current Display of the AC motor drive	
Settings	Read Only	Factory setting: ##

 Pr. 00-00 displays the identity code of the AC motor drive. The capacity, rated current, rated voltage and the max. carrier frequency relate to the identity code. Users can use the following table to check how the rated current, rated voltage and max. carrier frequency of the AC motor drive correspond to the identity code.

 Pr.00-01 displays the rated current of the AC motor drive. By reading this parameter the user can check if the AC motor drive is correct.

 The factory setting is rated current for the constant torque and can be set in Pr.00-12.

230V Series												
kW	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37
HP	1.0	2.0	3.0	5.0	7.5	10	15	20	25	30	40	50
Pr.00-00	4	6	8	10	12	14	16	18	20	22	24	26
Rated Current for Constant Torque (A)	5	7.5	11	17	25	33	49	65	75	90	120	146
Rated Current for Variable Torque (A)	6.3	9.4	13.8	21.3	31.3	41.3	61.3	81.3	93.8	113	150	183
Max. Carrier Frequency	15kHz									9kHz		

460V Series															
kW	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75
HP	1.0	2.0	3.0	5.0	7.5	10	15	20	25	30	40	50	60	75	100
Pr.00-00	5	7	9	11	13	15	17	19	21	23	25	27	29	31	33
Rated Current for Constant Torque (A)	3	4.2	6	8.5	13	18	24	32	38	45	60	73	91	110	150
Rated Current for Variable Torque (A)	3.8	5.3	7.5	10.6	16.3	22.5	30	40	47.5	56.3	75	91.3	113.8	138	188
Max. Carrier Frequency	15kHz									9kHz			6kHz		

00-02 Parameter Reset

Factory Setting: 00

- Settings
- 0 No Function
 - 1 Read Only
 - 2 Enable Group 11 Parameters Setting
 - 8 Keypad Lock
 - 9 All parameters are reset to factory settings (50Hz, 220V/380V)
 - 10 All parameters are reset to factory settings (60Hz, 220V/440V)

 When it is set to 1, all parameters are read only except Pr.00-00~00-07 and it can be used with password setting for password protection.

 This parameter allows the user to reset all parameters to the factory settings except the fault records (Pr.06-17 ~ Pr.06-22).

50Hz: Pr.01-01 is set to 50Hz and Pr.01-02 is set to 230V or 400V.

60Hz: Pr.01-01 is set to 60Hz and Pr.01-02 is set to 230V or 460V.

 When Pr.00-02=08, the KPV-CE01 keypad is locked and only Pr.00-02 can be set. To unlock the keypad, set Pr.00-02=00.

 When Pr.00-02 is set to 1 or 8, Pr.00-02 setting should be set to 0 before setting to other setting.

00-03 Start-up Display Selection

Factory Setting: 00

- Settings
- 0 Display the frequency command value. (LED F)
 - 1 Display the actual output frequency (LED H)
 - 2 Display the output current (A)
 - 3 Multifunction display, see Pr.00-04

 This parameter determines the start-up display page after power is applied to the drive.

00-04 Content of Multi-Function Display

Factory Setting: 00

- Settings
- 0 Display the output current in A supplied to the motor
 - 1 Display the counter value which counts the number of pulses on TRG terminal
 - 2 Display actual output frequency (H)



3	Display the actual DC BUS voltage in VDC of the AC motor drive	
4	Display the output voltage in VAC of terminals U, V, W to the motor.	
5	Display the power factor angle in ° of terminals U, V, W to the motor.	
6	Display the output power in kW of terminals U, V and W to the motor.	
7	Display the actual motor speed in rpm (enabled when using with PG card).	
8	Display the estimated value of torque in Nm as it relates to current.	
9	Display PG position	
10	Display analog feedback signal value in %.	
11	Display the signal of AVI analog input terminal in %. Range 0~10V corresponds to 0~100%. (1.)	
12	Display the signal of ACI analog input terminal in %. Range 4~20mA/0~10V corresponds to 0~100%. (2.)	
13	Display the signal of AUI analog input terminal in %. Range -10V~10V corresponds to 0~100%. (3.)	
14	Display the temperature of heat sink in °C.	
15	Display the temperature of IGBT in °C.	
16	Display digital input status ON/OFF (i)	
17	Display digital output status ON/OFF (o)	
18	Display multi-step speed	
19	The corresponding CPU pin status of digital input (i.)	
20	The corresponding CPU pin status of digital output (o.)	
21	Encoder position (PG1 of PG card) (Z)	
22	Pulse input frequency (PG2 of PG card) (4)	
23	Pulse input position (PG2 of PG card) (4.)	

 This parameter sets the display when Pr. 00-03 is set to 3.



It is used to display the content when LED U is ON. It is helpful for getting the AC motor drive's status by this parameter.

Terminal	MI14	MI13	MI12	MI11	MI10	MI9	MI8	MI7	MI6	MI5	MI4	MI3	MI2	MI1	REV	FWD
Status	0	0	0	0	0	0	0	0	1	0	0	0	0	1	1	0

0: OFF, 1: ON

MI1: Pr.02-01 is set to 1 (multi-step speed command 1/multi-step position command 1)

MI6: Pr.02-06 is set to 8 (the 1st, 2nd acceleration/deceleration time selection)

If REV, MI1 and MI6 are ON, the value is 0000 0000 1000 01102 in binary and 0086H in HEX.

At the meanwhile, if Pr.00-04 is set to "16" or "19", it will display "0086" with LED U is ON on the keypad KPV-CE01. The setting 16 is the status of digital input and the setting 19 is the corresponding CPU pin status of digital input. User can set to 16 to monitor digital input status and then set to 19 to check if the wire is normal.

Terminal	Reserved				Reserved				Reserved				MO2	MO1	RA	MRA
Status	0	0	0	0	0	0	0	0	1	0	0	0	0	1	1	0

MRA: Pr.02-11 is set to 9 (Drive ready).

After applying the power to the AC motor drive, if there is no other abnormal status, the contact will be ON. At the meanwhile, if Pr.00-04 is set to 17 or 20, it will display 0001 with LED U is ON on the keypad. The setting 17 is the status of digital output and the setting 20 is the corresponding CPU pin status of digital output. User can set 17 to monitor the digital output status and then set to 20 to check if the wire if normal.

00-05 User Defined Coefficient K

Factory Setting: 0


Settings Digit 4: decimal point number (0 to 3)
 Digit 0-3: 40 to 9999



It is used digital setting method

Digital 4: decimal point number (0: no decimal point, 1: 1 decimal point and so on.)

Digital 0-3: 40 to 9999 (the corresponding value for the max. frequency).



For example, if use uses rpm to display the motor speed and the corresponding value to the 4-pole motor 60Hz is 1800. This parameter can be set to 01800 to indicate that the corresponding value for 60Hz is 1800rpm. If the unit is rps, it can be set 10300 to indicate the corresponding value for 60Hz is 30.0 (a decimal point).

00-06 Software Version

Settings	Read Only
Display	#.##

00-07 Password Input

Unit: 1

Settings	1 to 9998 and 10000 to 65535	Factory Setting: 00
Display	00~02 (times of wrong password)	

The function of this parameter is to input the password that is set in Pr.00-08. Input the correct password here to enable changing parameters. You are limited to a maximum of 3 attempts. After 3 consecutive failed attempts, a blinking "PcodE" will show up to force the user to restart the AC motor drive in order to try again to input the correct password.

When forgetting password, you can decode by setting 9999 and press button  twice. Please note that all the settings will be set to factory setting.

00-08 Password Set

Unit: 1

Settings	1 to 9998 and 10000 to 65535	Factory Setting: 00
Display	00	No password set or successful input in Pr. 00-07
	01	Password has been set

To set a password to protect your parameter settings.

If the display shows 00, no password is set or password has been correctly entered in Pr.00-07. All parameters can then be changed, including Pr.00-08.

The first time you can set a password directly. After successful setting of password the display will show 01.

Be sure to record the password for later use.

To cancel the parameter lock, set the parameter to 00 after inputting correct password into Pr.00-07.
00-07.

The password consists of min. 2 digits and max. 5 digits.




How to make the password valid again after decoding by Pr.00-07:

Method 1: Re-input original password into Pr.00-08 (Or you can enter a new password if you want to use a changed or new one).


Method 2: After rebooting, password function will be recovered.

Password Decode Flow Chart



Password Setting



Decoding Flow Chart



Forgetting Password



00-09 $\swarrow$ Energy Saving Gain

Unit: 1

Settings 10~1000 %

Factory Setting: 100%



When Pr.00-19 is set to 1, this parameter can be used for energy saving. The setting should be decreased when the energy saving is not well. When the motor is vibrated, the setting should be increased.



00-10 Control Method

Factory Setting: 0

Settings	0	V/f control
	1	V/f + Encoder (VFPG)
	2	Sensorless vector control (SVC)
	3	FOC vector control + Encoder (FOCPG)
	4	Torque control + Encoder (TQRPG)

 This parameter determines the control method of the AC motor drive:

Setting 0: user can design V/f ratio by requirement and control multiple motors simultaneously.

Setting 1: User can use PG card with Encoder to do close-loop speed control.

Setting 2: To have optimal control characteristic by auto-tuning.

Setting 3: To increase torque and control speed precisely. (1:1000)

Setting 4: To increase accuracy for torque control.


00-11 V/f Curve Selection

Factory Setting: 0

Settings	0	V/f curve determined by group 01
	1	1.5 power curve
	2	Square curve

 When it is set to 0, the V/f curve setting for the motor 1 is according to Pr.01-01~Pr.01-08 and Pr. 01-35~01-42 are for the motor 2.

 When setting to 1 or 2, the settings of the 2nd voltage/frequency and the 3rd voltage/frequency are invalid.



00-12 *⚡* Constant/Variable Torque Selection

Factory Setting: 0

- | | | |
|----------|---|------------------------|
| Settings | 0 | Constant Torque (100%) |
| | 1 | Variable Torque (125%) |



When “1” is selected, the oL level is 125% of rated drive current. All other overload ratings will not change, example: 150% of rated drive current for 60 seconds.


00-13 *⚡* Optimal Acceleration/Deceleration Setting

Factory Setting: 0

- | | | |
|----------|---|--|
| Settings | 0 | Linear accel./decel. I |
| | 1 | Auto accel., linear decel. |
| | 2 | Linear accel., auto decel. |
| | 3 | Auto accel./decel. I |
| | 4 | Stall prevention by auto accel./decel. (limited by 01-12 to 01-21) |



It can decrease the drive's vibration during load starts and stops by setting this parameter. Also it will speed up to the setting frequency with the most fastest and smoothest start-up current when it detects small torque. At deceleration, it will auto stop the drive with the fastest and the smoothest deceleration time when the regenerated voltage of the load is detected.

**00-14** Time Unit for Acceleration/Deceleration and S Curve

Factory Setting: 0

- | | | |
|----------|---|-------------------|
| Settings | 0 | Unit: 0.01 second |
| | 1 | Unit: 0.1 second |

- ☞ This parameter determines the time unit for the Acceleration/Deceleration setting. Refer to Pr.01-12 ~ Pr.01-19 (accel./decel. Time 1 to 4), Pr. 01-20~Pr.01-21 (JOG accel./decel. Time) and Pr. 01-24~Pr.01-27 (S curve accel./decel. Time).

00-15 Reserved

00-16 Reserved

00-17 **Carrier Frequency** Unit: 1
 Settings 1~15KHz Factory Setting: 10

- ☞ This parameter determinates the PWM carrier frequency of the AC motor drive.

230V/460V Series				
Models	1-5HP 0.75-3.7kW	7.5-25HP 5.5-18.5kW	30-60HP 22-45kW	75-100HP 55-75Kw
Setting Range	01~15kHz	01~15kHz	01~09kHz	01~06kHz
Factory Setting	10kHz	9kHz	6kHz	6kHz

Carrier Frequency	Acoustic Noise	Electromagnetic Noise or Leakage Current	Heat Dissipation	Current Wave
1kHz	Significant ↑ ↓ Minimal	Minimal ↓ ↑ Significant	Minimal ↑ ↓ Significant	
8kHz				
15kHz				

- ☞ From the table, we see that the PWM carrier frequency has a significant influence on the electromagnetic noise, AC motor drive heat dissipation, and motor acoustic noise.

00-18 **Auto Voltage Regulation (AVR) Function** Factory Setting: 0
 Settings 0 Enable AVR
 1 Disable AVR
 2 Disable AVR when deceleration stop

- ☞ It is used to select the AVR mode. AVR is used to regulate the output voltage to the motor. For example, if V/f curve is set to AC200V/50Hz and the input voltage is from 200 to 264VAC, the output voltage won't excess AC200V/50Hz. If the input voltage is from 180 to 200V, the output voltage to the motor and the input voltage will be in direct proportion.



When setting Pr.00-18 to 1 during ramp to stop and used with auto accel./decel. function, the acceleration will be smoother and faster.

00-19 Auto Energy-saving Operation

Factory Setting: 0

Settings 0 Disable


 1 Enable



When the Auto Energy-saving function is enabled, the drive will operate with full voltage during acceleration and deceleration. At constant speed, the AC drive will calculate the optimal output voltage value for the load. It is possible for the output voltage to be 25% below Maximum Output Voltage during auto energy-saving operation. This function should not be used with variable loads or continuous rated output loads.



When output frequency is constant, i.e. constant operation, the output voltage will be auto decreased with load reduction. To make the AC motor drive runs under the energy-saving with the minimum value of the product of voltage and current.



00-20 Source of the Master Frequency Command

Factory Setting: 0

Settings 0 Digital keypad (KPV-CE01)

 1 RS-485 serial communication

 2 External analog input (Pr. 03-00)

 3 External UP/DOWN terminal

 4 Pulse input without direction command (Pr.10-15 without direction)

 5 Pulse input with direction command (Pr.10-15)

 This parameter determines the drive's master frequency source.

00-21 Source of the Operation Command

Factory Setting: 0

Settings	0	Digital keypad (KPV-CE01)
	1	External terminals. Keypad STOP disabled.
	2	RS-485 serial communication (RJ-11). Keypad STOP disabled.


 When the LED PU is light, the operation command can be controlled by the digital keypad.

00-22 Stop Method

Factory Setting: 0

Settings	0	Ramp to stop
	1	Coast to stop

 The parameter determines how the motor is stopped when the AC motor drive receives a valid stop command.



Ramp to Stop and Coast to Stop

- 1. Ramp to stop:** the AC motor drive decelerates from the maximum output frequency (Pr. 01-00) to minimum output frequency (Pr. 01-09) according to the deceleration time and then stop.
- 2. Coast to stop:** the AC motor drive stops the output instantly upon a STOP command and the motor free runs until it comes to a complete standstill.

(1) It is recommended to use "ramp to stop" for safety of personnel or to prevent material from being wasted in applications where the motor has to stop after the drive is stopped. The deceleration time has to be set accordingly.

(2) If the motor free running is allowed or the load inertia is large, it is recommended to select "coast to stop". For example, blowers, punching machines and pumps.



The stop method of the torque control is also set by Pr.00-22.

00-23**Reverse Operation**

Factory Setting: 0

Settings	0	Enable reverse
	1	Disable reverse
	2	Disable forward



This parameter enables the AC motor drives to run in the Reverse Direction. It may be used to prevent a motor from running in a direction that would consequently injure humans or damage the equipment.

Group 1 Basic Parameters

01-00	Maximum Output Frequency	Unit: 0.01
Settings	50.0 to 600.00Hz	Factory Setting: 60.00/50.00

 This parameter determines the AC motor drive's Maximum Output Frequency. All the AC motor drive frequency command sources (analog inputs 0 to +10V, 4 to 20mA and -10V to +10V) are scaled to correspond to the output frequency range.

01-01	1st Output Frequency Setting 1	
01-35	1st Output Frequency Setting 2	Unit: 0.01
Settings	0.00~600.00Hz	Factory Setting: 60.00/50.00

 These are for the base frequency and motor rated frequency.

 This value should be set according to the rated frequency of the motor as indicated on the motor nameplate. If the motor is 60Hz, the setting should be 60Hz. If the motor is 50Hz, it should be set to 50Hz.

 Pr.01-35 is used for the application occasion that uses double base motor.

01-02	1st Output Voltage Setting 1	
01-36	1st Output Voltage Setting 2	Unit: 0.1
Settings	230V series 0.1 to 255.0V	Factory Setting: 220.0
	460V series 0.1 to 510.0V	Factory Setting: 440.0

 These are for the base frequency and motor rated frequency.

 This value should be set according to the rated voltage of the motor as indicated on the motor nameplate. If the motor is 220V, the setting should be 220.0. If the motor is 200V, it should be set to 200.0.

 There are many motor types in the market and the power system for each country is also difference. The economic and convenience method to solve this problem is to install the AC motor drive. There is no problem to use with the different voltage and frequency and also can amplify the original characteristic and life of the motor.

01-03	2nd Output Frequency Setting 1	Unit: 0.01
Settings	0.00~600.00Hz	Factory Setting: 0.50
01-04	2nd Output Voltage Setting 1	Unit: 0.1
Settings	230V series 0.1 to 255.0V	Factory Setting: 5.0
	460V series 0.1 to 510.0V	Factory Setting: 10.0

Chapter 4 Parameters

01-37	2nd Output Frequency Setting 2			Unit: 0.01
	Settings	0.00~600.00Hz		Factory Setting: 0.50
01-38	2nd Output Voltage Setting 2			Unit: 0.1
	Settings	230V series	0.1 to 255.0V	Factory Setting: 5.0
		460V series	0.1 to 510.0V	Factory Setting: 10.0
01-05	3rd Output Frequency Setting 1			Unit: 0.01
	Settings	0.00~600.00Hz		Factory Setting: 0.50
01-06	3rd Output Voltage Setting 1			Unit: 0.1
	Settings	230V series	0.1 to 255.0V	Factory Setting: 5.0
		460V series	0.1 to 510.0V	Factory Setting: 10.0
01-39	3rd Output Frequency Setting 2			Unit: 0.01
	Settings	0.00~600.00Hz		Factory Setting: 0.50
01-40	3rd Output Voltage Setting 2			Unit: 0.1
	Settings	230V series	0.1 to 255.0V	Factory Setting: 5.0
		460V series	0.1 to 510.0V	Factory Setting: 10.0
01-07	4th Output Frequency Setting 1			Unit: 0.01
	Settings	0.00~600.00Hz		Factory Setting: 0.50
01-08	4th Output Voltage Setting 1			Unit: 0.1
	Settings	230V series	0.1 to 255.0V	Factory Setting: 5.0
		460V series	0.1 to 510.0V	Factory Setting: 10.0
01-41	4th Output Frequency Setting 2			Unit: 0.01
	Settings	0.00~600.00Hz		Factory Setting: 0.50
01-42	4th Output Voltage Setting 2			Unit: 0.1
	Settings	230V series	0.1 to 255.0V	Factory Setting: 5.0
		460V series	0.1 to 510.0V	Factory Setting: 10.0

 V/f curve setting is usually set by the motor's allowable loading characteristics. Pay special attention to the motor's heat dissipation, dynamic balance, and bearing lubricity, if the loading characteristics exceed the loading limit of the motor.

 For the V/f curve setting, it should be $Pr.01-01 \geq Pr.01-03 \geq Pr.01-05 \geq Pr.01-07$. There is no limit for the voltage setting, but a high voltage at the low frequency may cause motor damage, overheat, stall prevention or over-current protection. Therefore, please use the low voltage at the low frequency to prevent motor damage.

Pr.01-35 to Pr.01-42 is the V/f curve for the motor 2. When multi-function input terminals Pr.02-01 to Pr.02-14 is set to 14 and enabled or switch to the Δ -connection, the AC motor drive will act as the 2nd V/f curve.


01-09 Start Frequency

Unit: 0.01

Settings 0.00~600.00Hz

Factory Setting: 0.50

To distinguish which frequency should be start frequency, it needs to compare the value of min. output frequency and start frequency. The larger value will be start frequency.

**V/f Curve****01-10 Output Frequency Upper Limit**

Unit: 0.01

Settings 0.00~600.00Hz

Factory Setting: 60.00


01-11 Output Frequency Lower Limit

Unit: 0.01

Settings 0.00~600.00Hz

Factory Setting: 0.00

The upper/lower output frequency setting is used to limit the actual output frequency. If the frequency setting is lower than the start-up frequency, it will run with zero speed. If the frequency setting is higher than the upper limit, it will runs with the upper limit frequency. If output frequency lower limit > output frequency upper limit, this function is invalid.




01-12	✓ Accel. Time 1	Unit: 0.1/0.01
01-13	✓ Decel. Time 1	Unit: 0.1/0.01
01-14	✓ Accel. Time 2	Unit: 0.1/0.01
01-15	✓ Decel. Time 2	Unit: 0.1/0.01
01-16	✓ Accel. Time 3	Unit: 0.1/0.01
01-17	✓ Decel. Time 3	Unit: 0.1/0.01
01-18	✓ Accel. Time 4	Unit: 0.1/0.01
01-19	✓ Decel. Time 4	Unit: 0.1/0.01
Settings 0.00~600.00 sec/0.00~6000.0 sec		Factory Setting: 10.00/10.0

01-20	✓ JOG Acceleration Time	Unit: 0.1/0.01
01-21	✓ JOG Deceleration Time	Unit: 0.1/0.01
Settings 0.00~600.00 sec/0.00~6000.0 sec		Factory Setting: 1.00/1.0

- The Acceleration Time is used to determine the time required for the AC motor drive to ramp from 0Hz to Maximum Output Frequency (Pr.01-00).
- The Deceleration Time is used to determine the time require for the AC motor drive to decelerate from the Maximum Output Frequency (Pr.01-00) down to 0Hz.
- The Acceleration/Deceleration Time is invalid when using Pr.00-13 Optimal Acceleration/Deceleration Setting.
- The Acceleration/Deceleration Time 1, 2, 3, 4 are selected according to the Multi-function Input Terminals settings. See Pr.02-01 to Pr.02-30 for details.

- The larger against torque and inertia torque of the load and the accel./decel. time setting is less than the necessary value, it will enable torque limit and stall prevention function. When it happens, actual accel./decel. time will longer than the action above.



01-22	⚡ JOG Frequency	Unit: 0.01
Settings	0.00~600.00Hz	Factory Setting: 6.00

- Both external terminal JOG and key “JOG” on the keypad can be used. When the jog command is ON, the AC motor drive will accelerate from 0Hz to jog frequency (Pr.01-22). When the jog command is OFF, the AC motor drive will decelerate from Jog Frequency to zero. The used Accel./Decel. time is set by the Jog Accel./Decel. time (Pr.01-20, Pr.01-21).


01-23	⚡ 1st/4th Accel./decel. Frequency	Unit: 0.01
Settings	0.00~600.00Hz	Factory Setting: 0.00

- This function can be used without external terminal switch and switch acceleration time by this parameter setting. But the external multi-function terminals has the highest priority when using with external terminals.

01-24	⚡ S-curve for Acceleration Departure Time 1	Unit: 0.1/0.01
01-25	⚡ S-curve for Acceleration Arrival Time 2	Unit: 0.1/0.01
01-26	⚡ S-curve for Deceleration Departure Time 1	Unit: 0.1/0.01
01-27	⚡ S-curve for Deceleration Arrival Time 2	Unit: 0.1/0.01
Settings	0.00~25.00 sec / 0.00~250.0 sec	Factory Setting: 0.2/0.0

- It is used to give the smoothest transition between speed changes. The accel./decel. curve can adjust the S-curve of the accel./decel. When it is enabled, the drive will have different accel./decel. curve by the accel./decel. time.

-  The S-curve function is disabled when Pr.00-13 is set to 0.
-  The Actual Accel. Time = selected accel. Time + (Pr.01-24 + Pr.01-25)/2
- The Actual Decel. Time = selected decel. Time + (Pr.01-26 + Pr.01-27)/2



01-28	Skip Frequency 1 (upper limit)	Unit: 0.01
01-29	Skip Frequency 1 (lower limit)	Unit: 0.01
01-30	Skip Frequency 2 (upper limit)	Unit: 0.01
01-31	Skip Frequency 2 (lower limit)	Unit: 0.01
01-32	Skip Frequency 3 (upper limit)	Unit: 0.01
01-33	Skip Frequency 3 (lower limit)	Unit: 0.01
Settings 0.00~600.00Hz		Factory Setting: 0.00

-  These parameters are used to set the skip frequency of the AC drive. The skip frequencies are useful when a motor has vibration at a specific frequency bandwidth. By skipping this frequency, the vibration will be avoided.

01-34	Zero-speed Mode Selection		Factory Setting: 0
Settings	0	Output Waiting	
	1	Zero-speed operation	
	2	Fmin (4th output frequency setting)	

-  When the AC motor drive is at 0Hz, it will operate by this parameter.
-  When it is set to 1 or 2, the output voltage will be the corresponding Fmin value.




Group 2 Digital Input/Output Parameters

02-00 2-wire/3-wire Operation Control

Factory Setting: 0

Settings	0	FWD/STOP, REV/STOP
	1	FWD/STOP, REV/STOP (Line Start Lockout)
	2	RUN/STOP, REV/FWD
	3	RUN/STOP, REV/FWD (Line Start Lockout)
	4	3-wire (momentary push button)
	5	3-wire (momentary push button and Line Start Lockout)

Three of the six methods include a "Line Start Lockout" feature. When line start lockout is enabled, the drive will not run once applying the power. The Line Start Lockout feature doesn't guarantee the motor will never start under this condition. It is possible the motor may be set in motion by a malfunctioning switch.

02-00	Control Circuits of the External Terminal	
0, 1 2-wire operation control (1) FWD/STOP REV/STOP		
2, 3 2-wire operation control (2) RUN/STOP FWD/REV REV/FWD		
4, 5 3-wire operation control		

02-01 Multi-Function Input Command 1 (MI1)

Factory Setting: 1

02-02 Multi-Function Input Command 2 (MI2)

Factory Setting: 2

02-03 Multi-Function Input Command 3 (MI3)

Factory Setting: 3

02-04	Multi-Function Input Command 4 (MI4)	Factory Setting: 4
02-05	Multi-Function Input Command 5 (MI5)	Factory Setting: 0
02-06	Multi-Function Input Command 6 (MI6)	Factory Setting: 0
02-23	Multi-Function Input Command 7 (MI7)	Factory Setting: 0
02-24	Multi-Function Input Command 8 (MI8)	Factory Setting: 0
02-25	Multi-Function Input Command 9 (MI9)	Factory Setting: 0
02-26	Multi-Function Input Command 10 (MI10)	Factory Setting: 0
02-27	Multi-Function Input Command 11 (MI11)	Factory Setting: 0
02-28	Multi-Function Input Command 12 (MI12)	Factory Setting: 0
02-29	Multi-Function Input Command 13 (MI13)	Factory Setting: 0
02-30	Multi-Function Input Command 14 (MI14)	Factory Setting: 0
Settings		0-42



This parameter selects the functions for each multi-function terminal.



If Pr.02-00 is set to 3-wire operation control. Terminal MI1 is needed for the 3rd wire position. Therefore, MI1 is not allowed for any other operation.



Multi-function input commands 7-14 are the extension terminals of Pr.02-01 to Pr.02-06. There are 14 terminals but the terminals 7-14 are virtual terminals and you can set the status of bit 8-15 of Pr.02-10 to ON or OFF by KPV-CE01 or communication.

Settings	Functions	Descriptions
0	No Function	
1	Multi-step speed command 1/multi-step position command 1	15 step speeds could be conducted through the digital statuses of the 4 terminals, and 17 in total if the master speed and JOG are included. (Refer to Pr. 04-00~04-29)

Settings	Functions	Descriptions
2	Multi-step speed command 2/ multi-step position command 2	
3	Multi-step speed command 3/ multi-step position command 3	
4	Multi-step speed command 4/ multi-step position command 4	
5	Reset	After the error of the drive is eliminated, use this terminal to reset the drive.
6	JOG Command	JOG operation
7	Acceleration/deceleration Speed Inhibit	When this function is enabled, acceleration and deceleration is stopped and the AC motor drive start to accel./decel. from the inhibit point.
8	The 1 st , 2 nd acceleration or deceleration time selection	The acceleration/deceleration time of the drive could be selected from this function or the digital statuses of the terminals; there are 4 acceleration/deceleration speeds in total for selection.
9	The 3 rd , 4 th acceleration or deceleration time selection	
10	EF Input	External fault input terminal
11	B.B. Input	If the ON/OFF function of the terminal is pre-determined, output of the drive will be cut off immediately, and the motor will then be of the B.B. status. And once the ON/OFF function is restored, the drive will then trace from the bottom upward to catch up with its mutual rotation speed with the same frequency before B.B., then speed up to the pre-set frequency. Even if the motor is of a complete stop after B.B., as long as the ON/OFF status is restored, the speed-tracing function could still be operated.
12	Output Stop	If the ON/OFF function of the terminal is pre-determined, output of the drive will be cut off immediately, and the motor will then be free run. And once the ON/OFF function is restored, the drive will accelerate to the setting frequency.
13	Cancel the setting of the optimal accel./decel. time	Before using this function, Pr.00-13 should be set to 01/02/03/04 first. When this function is enabled, OFF is for auto mode and ON is for linear accel./decel.
14	Switch between drive settings 1 and 2	When this function is enabled, the drive will start to use motor 2 parameters.
15	Operation speed command form AVI	When this function is enabled, the source of the frequency will force to be AVI.

Settings	Functions	Descriptions
16	Operation speed command form ACI	When this function is enabled, the source of the frequency will force to be ACI.
17	Operation speed command form AUI	When this function is enabled, the source of the frequency will force to be AUI.
18	Emergency Stop (07-36)	When this function is enabled, the drive will ramp to stop by Pr.07-36 setting.
19	Digital Up command	When this function is enabled, the frequency will be increased and decreased. If this function keeps ON, the frequency will be increased/decreased by Pr.02-07/Pr.02-08. This function is the same as the ▲▼ key on the keypad.
20	Digital Down command	
21	PID function disabled	When this function is ON, the PID function is disabled.
22	Clear counter	When this function is enabled, it will clear current counter value and display "0". Only when this function is disabled, it will keep counting upward.
23	Input the counter value (multi-function input command 6)	When this function is enabled, the counter value will increase 1.
24	FWD JOG command	When this function is enabled, the drive will execute forward Jog command.
25	REV JOG command	When this function is enabled, the drive will execute reverse Jog command.
26	TQC+PG/FOC+PG model selection	OFF: FOC+PG speed control mode. ON: TQR+PG torque control mode.
27	ASR1/ASR2 selection	ON: speed will be adjusted by ASR 2 setting. OFF: speed will be adjusted by ASR 1 setting.
28	Emergency stop (EF1)	When it is ON, the drive will execute emergency stop. (it will have fault code record)
29	Signal confirmation for Y-connection	When it is ON, the drive will operate by 1st V/f.
30	Signal confirmation for Δ-connection	When it is ON, the drive will operate by 2nd V/f.
31	High torque bias (by Pr.07-29)	The high torque bias is according to the Pr.07-29 setting.
32	Middle torque bias (by Pr.07-30)	The middle torque bias is according to the Pr.07-30 setting.
33	Low torque bias (by Pr.07-31)	The low torque bias is according to the Pr.07-31 setting.
34	Enable multi-step position control	It is used to enable multi-step position control.

Settings	Functions	Descriptions																																																																																																																																																					
35	Enable position control	When this function is enabled, the pulse of PG card will change from speed command to position command.																																																																																																																																																					
36	Enable multi-step position input	When this function is enabled, the corresponding 15-step speed for the multi-function inputs 1-4 will be 15 positions. (Refer to Pr.04-15 to Pr.04-29)																																																																																																																																																					
37	Enable pulse position input command	When this function is enabled, current position will recorded to Pr.04-15 to Pr.04-29 in order.																																																																																																																																																					
38	Disable write EEPROM function	When this function is enabled, you can't write into EEPROM.																																																																																																																																																					
39	Torque command direction	When the torque command source is AVI or ACI, it can change torque direction by enabling this function.																																																																																																																																																					
40	Force stop	When this function is enabled, the drive will free run to stop.																																																																																																																																																					
41	Serial position clock	The position method of the main shaft:																																																																																																																																																					
42	Serial position input	When using setting 41 and setting 42, it needs to use with 2 input terminals for multi-position control. <table><tr><th colspan="2">test example</th><th></th><th>b11</th><th>b10</th><th>b9</th><th>b8</th><th>b7</th><th>b6</th><th>b5</th><th>b4</th><th>b3</th><th>b2</th><th>b1</th><th>b0</th></tr><tr><td rowspan="2">angle</td><td>Encoder</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr><tr><td>360</td><td>4096</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td></tr><tr><td></td><td>4095</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td></tr><tr><td>180</td><td>2048</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td></tr><tr><td>90</td><td>1024</td><td>0</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td></tr><tr><td>45</td><td>512</td><td>0</td><td>0</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td></tr><tr><td>137</td><td>1558</td><td>0</td><td>1</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td><td>0</td><td>1</td><td>1</td><td>0</td><td>0</td></tr><tr><td>308</td><td>3504</td><td>1</td><td>1</td><td>0</td><td>1</td><td>1</td><td>0</td><td>1</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td></tr><tr><td></td><td>3687</td><td>1</td><td>1</td><td>1</td><td>0</td><td>0</td><td>1</td><td>1</td><td>0</td><td>0</td><td>1</td><td>1</td><td>1</td><td>1</td></tr></table>	test example			b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0	angle	Encoder														360	4096	0	0	0	0	0	0	0	0	0	0	0	0		4095	1	1	1	1	1	1	1	1	1	1	1	1	1	180	2048	1	0	0	0	0	0	0	0	0	0	0	0	0	90	1024	0	1	0	0	0	0	0	0	0	0	0	0	0	45	512	0	0	1	0	0	0	0	0	0	0	0	0	0	137	1558	0	1	1	0	0	0	0	1	0	1	1	0	0	308	3504	1	1	0	1	1	0	1	1	0	0	0	0	0		3687	1	1	1	0	0	1	1	0	0	1	1	1	1
test example			b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0																																																																																																																																									
angle	Encoder																																																																																																																																																						
	360	4096	0	0	0	0	0	0	0	0	0	0	0	0																																																																																																																																									
	4095	1	1	1	1	1	1	1	1	1	1	1	1	1																																																																																																																																									
180	2048	1	0	0	0	0	0	0	0	0	0	0	0	0																																																																																																																																									
90	1024	0	1	0	0	0	0	0	0	0	0	0	0	0																																																																																																																																									
45	512	0	0	1	0	0	0	0	0	0	0	0	0	0																																																																																																																																									
137	1558	0	1	1	0	0	0	0	1	0	1	1	0	0																																																																																																																																									
308	3504	1	1	0	1	1	0	1	1	0	0	0	0	0																																																																																																																																									
	3687	1	1	1	0	0	1	1	0	0	1	1	1	1																																																																																																																																									
43	Analog input resolution selection																																																																																																																																																						

02-07 UP/DOWN Key Mode

Factory Setting: 0

- Settings 0 Up/down by the accel/decel time
 1 Up/down constant speed (Pr.02-08)

02-08 The Acceleration/Deceleration Speed of the UP/DOWN Key with Constant Speed

Unit: 0.01

Settings 0.01 ~ 1.00Hz/ms

Factory Setting: 0.01



These settings are used when multi-function input terminals are set to 19/20.

02-09 Digital Input Response Time

Unit: 0.001

Settings 0.001~ 30.000 sec

Factory Setting: 0.005



This parameter is used for digital input terminal signal delay and confirmation. The delay time is confirmation time to prevent some uncertain interferences that would result in error (except for the counter input) in the input of the digital terminals (FWD, REV and MI1~6). Under this condition, confirmation for this parameter could be improved effectively, but the response time will be somewhat delayed.

02-10 Digital Input Operation Direction

Unit: 1

Settings 0 ~ 65535

Factory Setting: 0



This parameter is used to set the input signal level and it won't be affected by the SINK/SOURCE status.



Bit0 is for FWD terminal, bit1 is for REV terminal and bit2 to bit15 is for MI1 to MI14.



User can change terminal status by communicating.

For example, MI1 is set to 1 (multi-step speed command 1), MI2 is set to 2 (multi-step speed command 2). Then the forward + 2nd step speed command=1001(binary)=9 (Decimal). Only need to set Pr.02-10=9 by communication and it can forward with 2nd step speed. It doesn't need to wire any multi-function terminal.

bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
MI14	MI13	MI12	MI11	MI10	MI9	MI8	MI7	MI6	MI5	MI4	MI3	MI2	MI1	REV	FWD

02-11	Multi-function Output 1 RA, RB, RC (Relay1)	Factory Setting: 11
02-12	Multi-function Output 2 MRA, MRC (Relay2)	Factory Setting: 1
02-13	Multi-function Output 3 (MO1)	Factory Setting: 0
02-14	Multi-function Output 4 (MO2)	Factory Setting: 0
Settings		0-40

Settings	Functions	Descriptions
0	No Function	
1	AC Derive Operational	Active when there is an output from the drive or RUN command is ON.
2	Master Frequency Attained	Active when the AC motor drive reaches the output frequency setting.
3	Desired Frequency Attained 1 (Pr.02-19)	Active when the desired frequency (Pr.02-19) is attained.
4	Desired Frequency Attained 2 (Pr.02-21)	Active when the desired frequency (Pr.02-21) is attained.
5	Zero Speed (frequency command)	Active when frequency command =0. (the drive should be at RUN mode)
6	Zero Speed with Stop (frequency command)	Active when frequency command =0 or stop.
7	Over Torque (OT1) (Pr.06-06~06-08)	Active when detecting over-torque. Refer to Pr.06-06 (over-torque detection selection-OT1), Pr.06-07 (over-torque detection level-OT1) and Pr.06-08 (over-torque detection time-OT1).
8	Over Torque (OT2) (Pr.06-09~06-11)	Active when detecting over-torque. Refer to Pr.06-09 (over-torque detection selection-OT2), Pr.06-10 (over-torque detection level-OT2) and Pr.06-11 (over-torque detection time-OT2).
9	Drive Ready	Active when the drive is ON and no abnormality detected.
10	User-defined Low-voltage Detection	Active when the DC Bus voltage is too low. (refer to Pr.06-00 low voltage level)
11	Malfunction Indication	Active when fault occurs (except Lv stop).

Settings	Functions	Descriptions
12	Mechanical Brake Release (Pr.02-31)	When drive runs after Pr.02-31, it will be ON. This function should be used with DC brake and it is recommended to use contact "b"(N.C).
13	Overheat	Active when IGBT or heat sink overheats to prevent OH turn off the drive. (refer to Pr.06-05)
14	Software Braking Signal	This function is used in conjunction with a VFDB Braking Unit. The output will be activated when the drive needs help braking the load. A smooth deceleration is achieved by using this function. (refer to Pr.07-00)
15	PID Feedback Error	Active when the feedback signal is abnormal.
16	Slip Error (oSL)	Active when the slip error is detected.
17	Terminal Count Value Attained	Active when the counter reaches Terminal Counter Value (Pr.02-16).
18	Preliminary Counter Value Attained	Active when the counter reaches Preliminary Counter Value (Pr.02-17).
19	Baseblock (B.B.) Indication	Active when the output of the AC motor drive is shut off during baseblock.
20	Warning Output	Active when the warning is detected.
21	Over-voltage Warning	Active when the over-voltage is detected.
22	Over-current Stall Prevention Warning	Active when the over-current stall prevention is detected.
23	Over-voltage Stall prevention Warning	Active when the over-voltage stall prevention is detected.
24	Operation Mode Indication	Active when the operation command is controlled by external terminal.
25	Forward Command	Active when the operation direction is forward.
26	Reverse Command	Active when the operation direction is reverse.
27	Output when Current $\geq$ Pr.02-32	Active when current is $\geq$ Pr.02-32.
28	Output when Current $<$ Pr.02-32	Active when current is $<$ Pr.02-32.
29	Output when frequency $\geq$ Pr.02-33	Active when frequency is $\geq$ Pr.02-33.

Settings	Functions	Descriptions
30	Output when Frequency < Pr.02-33	Active when frequency is < Pr.02-33.
31	Y-connection for the Motor Coil	Active when PR.05-12 is less than PR.05-11 and time is more than Pr.05-30.
32	Δ-connection for the Motor Coil	Active when PR.05-12 is higher than PR.05-11 and time is more than Pr.05-30.
33	Zero Speed (actual output frequency)	Active when the actual output frequency is 0. (the drive should be at RUN mode)
34	Zero Speed with Stop (actual output frequency)	Active when the actual output frequency is 0 or Stop. (the drive should be at RUN mode)
35	Error Output Selection 1 (Pr.06-23)	Active when Pr.06-23 is ON.
36	Error Output Selection 2 (Pr.06-24)	Active when Pr.06-24 is ON.
37	Error Output Selection 3 (Pr.06-25)	Active when Pr.06-25 is ON.
38	Error Output Selection 4 (Pr.06-26)	Active when Pr.06-26 is ON.
39	Position attained (Pr.10-19)	Active when the PG position control point reaches Pr.10-19.
40	Speed Attained (including zero speed)	Active when the output frequency reaches frequency setting.

02-15 ✓ Multi-output Direction

Unit:1

Settings 0 ~ 65535

Factory Setting: 0



This parameter is bit setting. If the bit is 1, the multi-function output terminal will be act with opposite direction. For example, if Pr.02-11 is set to 1 and forward bit is 0, Relay 1 will be ON when the drive is running and OFF when the drive is stop.

bit3	bit2	bit1	bit0
MO2	MO1	RA	MRA

02-16 ✓ Terminal Count Value

Unit:1



Settings 0 ~ 65535

Factory Setting: 0

The counter trigger can be set by the multi-function terminal MI6 (set Pr.02-06 to 23). Upon completion of counting, the specified output terminal will be activated (Pr.02-11 to Pt.02-14 is set to 17).

02-17	↗ Preliminary Count Value	Unit:1
Settings	0 ~ 65535	Factory Setting: 0

When the counter value reaches this value, the corresponding multi-function output terminal will be activated, provided one of Pr. 02-11 to 02-14 set to 18 (Preliminary Count Value Setting). This parameter can be used for the end of the counting to make the drive runs from the low speed to stop.



02-18	↗ Digital Output Gain	Unit:1
Settings	1 ~ 40	Factory Setting: 1

It is used to set the signal for the digital output terminals (DFM-DCM) and digital frequency output (pulse X work period=50%). Output pulse per second = output frequency X Pr.02-18.

02-19	↗ Desired Frequency Attained 1	Unit: 0.01
		Factory Setting: 60.00/50.00

02-20	↗ The Width of the Desired Frequency Attained 1	Unit: 0.01
		Factory Setting: 2.00

02-21	↗ Desired Frequency Attained 2	Unit: 0.01
		Factory Setting: 60.00/50.00


02-22	↗ The Width of the Desired Frequency Attained 2	Unit: 0.01
		Factory Setting: 2.00

Settings	0.00 ~ 600.00Hz	
----------	-----------------	--

Once output frequency reaches desired frequency and the corresponding multi-function output terminal is set to 2-7 or 24-27 (Pr.02-11~Pr.02-14), this multi-function output terminal will be ON.

02-31	Brake Delay Time	Unit:0.001
Settings	0.000~65.000 Sec	Factory Setting: 0

When the AC motor drive runs after Pr.02-31 delay time, the corresponding multi-function output terminal (12: mechanical brake release) will be ON. This function should be used with DC brake.



02-32	✓ Output Current Level Setting for External Terminals	Unit:1
Settings	0~100%	Factory Setting: 0

- When output current is higher than Pr.02-32, it will activate multi-function output terminal (Pr.02-11 to Pr.02-14 is set to 27).
- When output current is lower than Pr.02-32, it will activate multi-function output terminal (Pr.02-11 to Pr.02-14 is set to 28).

02-33	✓ Output Boundary for External Terminals	Unit:0.01
Settings	0.00~+60.00Hz	Factory Setting: 0.00

- When output frequency is higher than Pr.02-33, it will activate the multi-function terminal (Pr.02-11 to Pr.02-14 is set to 29).
- When output frequency is lower than Pr.02-33, it will activate the multi-function terminal (Pr.02-11 to Pr.02-14 is set to 30).

02-34 ⚡ External Operation Control Selection after Reset

Unit:1

Factory Setting: 0

Settings 0: Disable

1: Drive runs if run command exists after reset



After clearing fault once a fault is detected and the external terminal for RUN keeps ON, the drive can run after pressing RESET key.

Group 3 Analog Input/Output Parameters**03-00** **↗ Analog Input 1 (AVI)**

Factory Setting: 1

03-01 **↗ Analog Input 2 (ACI)**

Factory Setting: 0

03-02 **↗ Analog Input 3 (AUI)**


Factory Setting: 0

Settings	0: No function
	1: Frequency command (torque limit under TQR control mode)
	2: torque command (torque limit under speed mode)
	3: Torque compensation command
	4: PID target value (refer to group 8)
	5: PID feedback signal (refer to group 8)
	6: P.T.C. thermistor input value
	7: Positive torque limit
	8: Negative torque limit
	9: Regenerative torque limit
	10: Positive/negative torque limit

 When it is frequency command or TQR speed limit, the corresponding value for 0~±10V/4~20mA is 0 – max. output frequency(Pr.01-00)

 When it is torque command or torque limit, the corresponding value for 0~±10V/4~20mA is 0 – max. output torque (Pr.07-22).

 When it is torque compensation, the corresponding value for 0~±10V/4~20mA is 0 – rated torque.



03-03	 Analog Input Bias 1 (AVI)	Unit: 0.1
	Settings -100.0~100.0%	Factory Setting: 0

 It is used to set the corresponding AVI voltage of the external analog input 0.

03-04	 Analog Input Bias 1 (ACI)	Unit: 0.1
	Settings -100.0~100.0%	Factory Setting: 0

 It is used to set the corresponding ACI voltage of the external analog input 0.

03-05	 Analog Input Bias 1 (AUI)	Unit: 0.1
	Settings -100.0~100.0%	Factory Setting: 0

 It is used to set the corresponding AUI voltage of the external analog input 0.

03-06	 Positive/negative Bias Mode (AVI)	
03-07	 Positive/negative Bias Mode (ACI)	
03-08	 Positive/negative Bias Mode (AUI)	

Factory Setting: 0

Settings	0	Zero bias
	1	Lower than bias=bias
	2	Greater than bias=bias
	3	The absolute value of the bias voltage while serving as the center
	4	Serve bias as the center

 In a noisy environment, it is advantageous to use negative bias to provide a noise margin. It is recommended NOT to use less than 1V to set the operation frequency.

03-09	 Analog Input Gain 1 (AVI)	Unit: 1
03-10	 Analog Input Gain 1 (ACI)	Unit: 1
03-11	 Analog Input Gain 1 (AUI)	Unit: 1
	Settings -500.0~500.0%	Factory Setting: 100.0

 Parameters 03-03 to 03-11 are used when the source of frequency command is the analog voltage/current signal.

03-12 ✓ ACI/AVI2 Selection

Factory Setting: 0

Settings	0	ACI
	1	AVI 2

There are two AVI analog inputs can be used when this parameter is set to 1 and the jumper 1 on the control board is set to AVI2. At this moment, ACI is for voltage input.

03-13 ✓ Analog Input Delay Time (AVI)

Unit: 0.011

03-14 ✓ Analog Input Delay Time (ACI)

Unit: 0.01

03-15 ✓ Analog Input Delay Time (AUI)

Unit: 0.01

Settings 0.00 to 2.00 sec

Factory Setting: 0.01


These input delays can be used to filter noisy analog signal.

03-16 ✓ Addition Function of the Analog Input

Factory Setting: 0

Settings	0	Disable (AVI, ACI, AUI)
	1	Enable

When Pr.03-16 is set to 0 and the analog input setting is the same, the priority for AVI, ACI and AUI are AVI>ACI>AUI.



$$F_{\text{command}} = [(a_y \cdot \text{bias}) \cdot \text{gain}] \cdot \frac{F_{\text{max}}(01-00)}{10\text{V or }16\text{mA}}$$

Fcommand: the corresponding frequency for 10V or 20mA

ay : 10 or 16mA

bias : Pr.03-03, Pr. 03-04, Pr.03-05

gain : Pr.03-09, Pr.03-10, Pr.03-11

03-17 ✓ Loss of the ACI Signal

Factory Setting: 0

Settings	0	Disable
	1	Continue operation at the last frequency

- 2 Decelerate to stop
- 3 Stop immediately and display E.F.



This parameter determines the behavior when ACI is lost.

03-18 Analog Output Selection

Unit: 1

Settings 00 to 19

Factory Setting: 00

Settings	Functions	Descriptions
0	Output frequency (Hz)	Max. frequency Pr.01-00 is regarded as 100%.
1	Frequency command (Hz)	Max. frequency Pr.01-00 is regarded as 100%.
2	Motor speed (Hz)	600Hz is regarded as 100%
3	Output current (rms)	2.5 X rated current is regarded as 100%
4	Output voltage	2 X rated voltage is regarded as 100%
5	DC Bus Voltage	450V (900V)=100%
6	Power factor	-1.000~1.000=100%
7	Power	Rated power is regarded as 100%
8	Output torque	Full-load torque is regarded as 100%
9	AVI	0~10V=0~100%
10	ACI	0~20mA=0~100%
11	AUI	-10~10V=0~100%
12	q-axis current	(2.5 X rated current) is regarded as 100%
13	q-axis feedback value	(2.5 X rated current) is regarded as 100%
14	d-axis current	(2.5 X rated current) is regarded as 100%

Settings	Functions	Descriptions
15	d-axis feedback value	(2.5 X rated current) is regarded as 100%
16	q-axis voltage	250V (500V) =100%
17	d-axis voltage	250V (500V) =100%
18	Torque command	Rated torque is regarded as 100%
19	Pulse frequency command	Max. frequency Pr.01-00 is regarded as 100%.

03-19 ✓ Analog Output Gain

Unit: 0.1

Settings 0 to 200.0%

Factory Setting: 100.0


It is used to adjust the analog voltage level that terminal AFM outputs.

This parameter is set the corresponding voltage of the analog output 0.

03-20 ✓ Analog Output Value in REV Direction

Factory Setting: 0

- Settings
- 0 Absolute value in REV direction
 - 1 Output 0V in REV direction
 - 2 Output negative voltage in REV direction



Selection for the analog output direction

Group 4 Multi-Step Speed Parameters

04-00	↗ 1st Step Speed Frequency	Unit: 0.01
04-01	↗ 2nd Step Speed Frequency	Unit: 0.01
04-02	↗ 3rd Step Speed Frequency	Unit: 0.01
04-03	↗ 4th Step Speed Frequency	Unit: 0.01
04-04	↗ 5th Step Speed Frequency	Unit: 0.01
04-05	↗ 6th Step Speed Frequency	Unit: 0.01
04-06	↗ 7th Step Speed Frequency	Unit: 0.01
04-07	↗ 8th Step Speed Frequency	Unit: 0.01
04-08	↗ 9th Step Speed Frequency	Unit: 0.01
04-09	↗ 10th Step Speed Frequency	Unit: 0.01
04-10	↗ 11th Step Speed Frequency	Unit: 0.01
04-11	↗ 12th Step Speed Frequency	Unit: 0.01
04-12	↗ 13th Step Speed Frequency	Unit: 0.01
04-13	↗ 14th Step Speed Frequency	Unit: 0.01
04-14	↗ 15th Step Speed Frequency	Unit: 0.01

Factory Setting: 0.00

Settings 0.00 to 600.00 Hz



The Multi-Function Input Terminals (refer to Pr.02-01 to 02-06) are used to select one of the AC motor drive Multi-step speeds. The speeds (frequencies) are determined by Pr.04-00 to 04-14 as shown above.

04-15	↗ Multi-position 1	Unit: 0
04-16	↗ Multi-position 2	Unit: 0
04-17	↗ Multi-position 3	Unit: 0
04-18	↗ Multi-position 4	Unit: 0
04-19	↗ Multi-position 5	Unit: 0
04-20	↗ Multi-position 6	Unit: 0
04-21	↗ Multi-position 7	Unit: 0
04-22	↗ Multi-position 8	Unit: 0
04-23	↗ Multi-position 9	Unit: 0
04-24	↗ Multi-position 10	Unit: 0
04-25	↗ Multi-position 11	Unit: 0

04-26	↗ Multi-position 12	Unit: 0
04-27	↗ Multi-position 13	Unit: 0
04-28	↗ Multi-position 14	Unit: 0
04-29	↗ Multi-position 15	Unit: 0
Settings 0.00 to 65535		Factory Setting: 0

 The Multi-Function Input Terminals (refer to Pr.02-01 to 02-06) are used to select one of the multi-position 1-4 (set to 1-4), enable multi-position control function (set to 36) and enable multi-position input (set to 37). First, set the multi-function terminal to be ON by setting 36 and then set 37 to write different position into Pr.04-15 to Pr.04-29. After press RUN, the multi-position terminals 1-4 will be changed to control the position.

Group 5 Motor Parameters**05-00 Motor Auto Tuning**

Factory Setting: 0

Settings	0	No function
	1	Rolling test
	2	Static Test
	3	Reserved



Starting auto tuning by pressing RUN key and it will write the measure value into Pr.05-05 to Pr.05-09 for motor 1 and Pr.05-17 to Pr.05-21 for motor 2.



The steps to AUTO-Tuning are: (when setting to 1)

1. Make sure that all the parameters are set to factory settings and the motor wiring is correct.
2. Make sure the motor has no-load before executing auto-tuning and the shaft is not connected to any belt or gear motor. It is recommended to set to 2 or 3 if the motor can't separate from the load.
3. Motor 1: fill in Pr.01-02, Pr.01-01, Pr.05-01, Pr.05-02, Pr.05-03 and Pr.05-04 with correct values. Refer to motor capacity to set accel./decel. time.
Motor 2: fill in Pr.01-36, Pr.01-35, Pr.05-13, Pr.05-14, Pr.05-15 and Pr.05-16 with correct values. Refer to motor capacity to set accel./decel. time.
4. When Pr.05-00 is set to 1, the AC motor drive will execute auto-tuning immediately after receiving a "RUN" command. (NOTE: the motor will run!)
5. After executing, please check if there are values filled in Pr.05-05 to Pr.05-09 for motor 1 and Pr.05-17 to Pr.05-21 for motor 2.



If Pr.05-00 is set to 2, it needs to input Pr.05-05 for motor 1/Pr.05-17 for motor 2. If Pr.05-00 is set to 3, no need to input no-load current and only need to confirm that the shaft is locked.

**NOTE**

1. In torque/vector control mode, it is not recommended to have motors run in parallel.
2. It is not recommended to use torque/vector control mode if motor rated power exceeds the rated power of the AC motor drive.
3. When tuning 2 motors, it needs to set multi-function input terminals or change Pr.05-10 for motor 1/motor 2 selection.
4. The no-load current is usually 20~50% X rated current.
5. The rated speed can't be larger or equal to 120f/p.

05-01	Full-load Current of Motor 1	Unit: Amp
Settings	40 to 100%	Factory Setting: 90%

 This value should be set according to the rated frequency of the motor as indicated on the motor nameplate. The factory setting is 90% X rated current.

05-02	✓ Rated Power of Motor 1	Unit: kW
Settings	0 to 655.35	Factory Setting: ###

 It is used to set rated power of the motor 1. The factory setting is the power of the drive.

05-03	✓ Rated Speed of Motor 1 (rpm)	
Settings	0 to 65535	Factory Setting: 1710

 It is used to set the rated speed of the motor and need to set according to the value indicated on the motor nameplate.

05-04	Number of Motor Poles 1	Unit: 1
Settings	2 to 20	Factory Setting: 4

 It is used to set the number of motor poles (must be an even number).

05-05	No-load Current of Motor 1	Unit: 1
Settings	0 to 100%	Factory Setting: 40%

 The factory setting is 40% X rated current.

05-06	Rotor Resistance R1 of Motor 1	Unit: 1
05-07	Rr of Motor 1	Unit: 1
Settings	0~65.535Ω	Factory Setting: 0

05-08	Lm of Motor 1	
05-09	Lx of Motor 1	
Settings	0~6553.5mH	Factory Setting: 0

05-10 Motor 1/Motor 2 Selection

Factory Setting: 0

Settings	1	Motor 1
	2	Motor 2

It is used to set the motor that driven by the AC motor drive.

**05-11** Frequency for Y-connection/ Δ-connection Switch

Unit: 0.01

Settings	0.00 to 600.00Hz	Factory Setting: 60.00
----------	------------------	------------------------

05-12 Y-connection /Δ-connection Switch

Factory Setting: 0


Settings	0	Disable
	1	Enable

It is used to enable/disable Y-connection/ Δ-connection Switch.



When Pr.05-12 is set to 1, the drive will select by Pr.05-11 setting and current motor frequency to switch motor to Y-connection or Δ-connection. AT the same time, it will also affect motor parameters (Pr.05-01 to 05-10/Pr.05-13 to Pr.05-21).

Y-Δ connection switch: can be used for wide range motor
 Y connection for low speed: higher torque can be used for rigid tapping
 Δconnection for high speed: higher torque can be used for high-speed drilling

**05-30** Delay Time for Y-connection/Δ -connection


Unit: 0.001


Settings	0 to 60.00	Factory Setting: 0.200
----------	------------	------------------------



It is used to set the switch delay time of Y-connection/Δ -connection.

When output frequency reaches Y-connection/ Δ -connection switch frequency, drive will delay by Pr.05-30 before multi-function output terminals are active.



**05-13** Full-load Current of Motor 2

Unit: 1%

Settings 40 to 100%

Factory Setting: 90%



This value should be set according to the rated frequency of the motor as indicated on the motor nameplate. The factory setting is 90% X rated current.

05-14 Rated Power of Motor 2

Unit: kW

Settings 0 to 655.35

Factory Setting: #.##



It is used to set rated power of the motor 2. The factory setting is the power of the drive.

05-15 Rated Speed of Motor 2 (rpm)

Settings 0 to 65535

Factory Setting: 1710



It is used to set the rated speed of the motor and need to set according to the value indicated on the motor nameplate.

05-16 Number of Motor Poles 2

Unit: 1

Settings 2 to 20

Factory Setting: 4



It is used to set the number of motor poles (must be an even number).

05-17	No-load Current of Motor 2	Unit: 1
Settings	0 to 100%	Factory Setting: 40%

 The factory setting is 40% X rated current.

05-18	Rotor Resistance R1 of Motor 2	Unit: 1
05-19	Rr of Motor 2	Unit: 1
Settings	0~65.535Ω	Factory Setting: 0

05-20	Lm of Motor 2	
05-21	Lx of Motor 2	
Settings	0~6553.5mH	Factory Setting: 0

 It will have different setting by the rated current.

05-22	✓ Torque Compensation Time Constant	Unit: 0.001
Settings	0.001 to 10.000 sec	Factory Setting: 0.020
05-23	✓ Slip Compensation Time Constant	Unit: 0.001
Settings	0.001 to 10.000 sec	Factory Setting: 0.100

 Setting Pr.05-22 and Pr.05-23 change the response time for the compensation.

 When Pr.05-22 and Pr.05-23 are set to 10.00 seconds, its response time for the compensation will be the longest. But if the settings are too short, unstable system may occur.

05-24	✓ Torque Compensation Gain	Unit: 1
Settings	0 to 10	Factory Setting: 0

 This parameter may be set so that the AC motor drive will increase its voltage output to obtain a higher torque. Only to be used for SVC control mode.

 Too high torque compensation can overheat the motor.

05-25	✓ Slip Compensation Gain	Unit: 0.01
Settings	0.00 to 10.00	Factory Setting: 0.00

 When the asynchronous motor is driven by the drive, the load and slip will be increased. This parameter can be used to correct frequency and lower the slip to make the motor can run near the synchronous speed under rated current. When the output current is larger than the motor

no-load current, the drive will compensate the frequency by Pr.05-25 setting. If the actual speed is slower than expectation, please increase the setting and vice versa.



It is only valid in SVC mode.

05-26	Slip Deviation Level	Unit: 1
Settings	0 to 1000% (0: disable)	Factory Setting: 0
05-27	Detection time of Slip Deviation	Unit: 0.1
Settings	0.0 to 10.0 sec	Factory Setting: 1.0
05-28	Over Slip Treatment	Factory Setting: 0
Settings	0 Warn and keep operation	
	1 Warn and ramp to stop	
	2 Warn and coast to stop	



Pr.05-26 to Pr.05-28 are used to set allowable slip level/time and over slip treatment when the drive is running.

05-29	Hunting Gain	Unit: 1
Settings	0 to 10000 (0: disable)	Factory Setting: 2000



The motor will have current wave motion in some specific area. It can improve this situation by setting this parameter. (When it is high frequency or run with PG, Pr.05-29 can be set to 0. when the current wave motion happens in the low frequency, please increase Pr.05-29.)

05-31	Accumulative Motor Operation Time (Min.)	Unit: 1
Settings	00 to 1439	Factory Setting: 00

05-32	Accumulative Motor Operation Time (Day)	Unit: 1
Settings	0 to 65535	Factory Setting: 0



Pr. 05-31 and Pr.05-32 are used to record the motor operation time. They can be cleared by setting to 00 and time is less than 60 seconds is not recorded.

Group 6 Protection Parameters**06-00 Low Voltage Level**

Unit: 0.1

Settings 230V series 160.0~220.0Vdc


Factory Setting: 180.0

460V series 320.0~440.0Vdc

Factory Setting: 360.0



It is used to set the Lv level.

**06-01 Over-Voltage Stall Prevention**

Unit: 0.1

Settings 230V series 350.0~450.0Vdc


Factory Setting: 380.0

460V series 700.0~900.0Vdc

Factory Setting: 760.0



During deceleration, the DC bus voltage may exceed its Maximum Allowable Value due to motor regeneration. When this function is enabled, the AC motor drive will not decelerate further and keep the output frequency constant until the voltage drops below the preset value again.

**06-02 Phase-loss Protection**

Factory Setting: 0

Settings 0 Warn and keep operation
 1 Warn and ramp to stop
 2 Warn and coast to stop



It is used to set the phase-loss treatment. The phase-loss will effect driver's control characteristic and life.

06-03**Over-Current Stall Prevention during Acceleration**


Unit: 1

Settings 00~250%

Factory Setting: 170



During acceleration, the AC drive output current may increase abruptly and exceed the value specified by Pr.06-03 due to rapid acceleration or excessive load on the motor. When this function is enabled, the AC drive will stop accelerating and keep the output frequency constant until the current drops below the maximum value.

**06-04****Over-current Stall Prevention during Operation**


Unit: 1

Settings 00 to 250%

Factory Setting: 170



If the output current exceeds the setting specified in Pr.06-04 when the drive is operating, the drive will decrease its output frequency to prevent the motor stall. If the output current is lower than the setting specified in Pr.06-04, the drive will accelerate again to catch up with the set frequency command value.



over-current stall prevention during operation

06-05

✓ Accel./Decel. Time Selection of Stall Prevention at constant speed

Factory Setting: 0

Settings	0	by current accel/decel time
	1	by the 1st accel/decel time
	2	by the 2nd accel/decel time
	3	by the 3rd accel/decel time
	4	by the 4th accel/decel time
	5	by auto accel/decel time



It is used to set the accel./decel. time selection when stall prevention occurs at constant speed.

06-06

✓ Over-torque Detection Selection (OT1)

Factory Setting: 0

Settings	0	Over-Torque detection disabled.
	1	Over-torque detection during constant speed operation, continue to operate after detection
	2	Over-torque detection during constant speed operation, stop operation after detection
	3	Over-torque detection during operation, continue to operate after detection
	4	Over-torque detection during operation, stop operation after detection

06-07

✓ Over-torque Detection Level (OT1)

Unit: 1

Settings	10 to 250%	Factory Setting: 150
----------	------------	----------------------

06-08

✓ Over-torque Detection Time (OT1)

Unit: 0.1

Settings	0.0 to 60.0 sec	Factory Setting: 0.1
----------	-----------------	----------------------

06-09 Over-torque Detection Selection (OT2)

Factory Setting: 0

Settings	0	Over-Torque detection disabled.
	1	Over-torque detection during constant speed operation, continue to operate after detection
	2	Over-torque detection during constant speed operation, stop operation after detection
	3	Over-torque detection during operation, continue to operate after detection
	4	Over-torque detection during operation, stop operation after detection

06-10 Over-torque Detection Level (OT2)

Unit: 1

Settings 10 to 250%

Factory Setting: 150

06-11 Over-torque Detection Time (OT2)


Unit: 0.1

Settings 0.0 to 60.0 sec

Factory Setting: 0.1



Pr.06-06 and Pr.06-09 determine the operation mode of the drive after the over-torque is detected via the following method: if the output current exceeds the over-torque level (Pr.06-19) and also exceeds the Pr.06-08 Over-Torque Detection Time, the fault code "OT1/OT2" is displayed. If a Multi-Functional Output Terminal is to over-torque detection, the output is on. Please refer to Pr.02-11~02-14 for details.

**06-12** Current Limit

Unit: 1

Settings 0 to 250%

Factory Setting: 150



It is used to set the current limit.

06-13 ✓ Electronic Thermal Relay Selection (Motor 1)

Factory Setting: 2

Settings	0	Inverter motor
	1	Special motor
	2	Disabled

06-27 ✓ Electronic Thermal Relay Selection (Motor 2)

Factory Setting: 2

Settings	0	Inverter motor
	1	Special motor
	2	Disabled

It is used to prevent self-cooled motor overheats under low speed. User can use electrical thermal relay to limit driver's output power.

06-14 ✓ Electronic Thermal Characteristic for Motor 1

Unit: 0.1

Settings 30.0 to 600.0 sec

Factory Setting: 60.0


06-28 ✓ Electronic Thermal Characteristic for Motor 2

Unit: 0.1

Settings 30.0 to 600.0 sec

Factory Setting: 60.0

The parameter is set by the output frequency, current and operation time of the drive for activating the I^2t electronic thermal protection function. The graph below shows I^2t curves for 150% output power for 1 minute.

**06-15** ✓ Heat Sink Over-heat (OH) Warning

Unit: 0.1

Settings 0.0 to 110.0 °C

Factory Setting: 85.0

06-16	↗ Stall Prevention Limit Level	Unit: 1
Settings	0 to 100% (refer to Pr.06-03, Pr.06-04)	Factory Setting: 50



When operation frequency is larger than Pr.01-01, Pr06-03=150%, Pr. 06-04=100% and Pr. 06-28=80%:

Stall Prevention Level during acceleration = $06-03 \times 06-28 = 150 \times 80\% = 120\%$.

Stall Prevention Level at constant speed = $06-03 \times 06-28 = 100 \times 80\% = 80\%$.

06-17	Present Fault Record
06-18	Second Most Recent Fault Record
06-19	Third Most Recent Fault Record
06-20	Fourth Recent Fault Record
06-21	Fifth Most Recent Fault Record
06-22	Sixth Most Recent Fault Record

Factory Setting: 0

Readings	0	No fault
	1	Over-current during acceleration (ocA)
	2	Over-current during deceleration (ocd)
	3	Over-current during constant speed (ocn)
	4	Ground fault (GFF)
	5	IGBT short-circuit (occ)
	6	Over-current at stop (ocS)
	7	Over-voltage during acceleration (ovA)
	8	Over-voltage during deceleration (ovd)
	9	Over-voltage during constant speed (ovn)
	10	Over-voltage at stop (ovS)
	11	Low-voltage during acceleration (LvA)
	12	Low-voltage during deceleration (Lvd)
	13	Low-voltage during constant speed (Lvn)
	14	Low-voltage at stop (LvS)
	15	Phase loss (PHL)
	16	IGBT heat sink over-heat (oH1)
	17	Heat sink over-heat (oH2)(for 40HP above)
	18	TH1 open loop error (tH1o)
	19	TH2 open loop error (tH2o)
	20	Fan error signal output
	21	Over-load (oL) (150% 1Min)

22	Motor 1 over-load (EoL1)
23	Motor 2 over-load (EoL2)
24	Motor PTC overheat (oH3)
25	Fuse error (FuSE)
26	Over-torque 1 (ot1)
27	over-torque 1 (ot2)
28	Insufficient torque 1
29	Insufficient torque 2
30	Memory write-in error (cF1)
31	Memory read-out error (cF2)
32	Isum current detection error (cd0)
33	U-phase current detection error (cd1)
34	V-phase current detection error (cd2)
35	W-phase current detection error (cd3)
36	Clamp current detection error (Hd0)
37	Over-current detection error (Hd1)
38	Over-voltage detection error (Hd2)
39	Ground current detection error (Hd3)
40	Auto tuning error (AuE)
41	PID feedback loss (AFE)
42	PG feedback error (PGF1)
43	PG feedback loss (PGF2)
44	PG feedback stall (PGF3)
45	PG slip error (PGF4)
46	PG ref input error (PGr1)
47	PG ref loss (PGr2)
48	Analog current input loss (ACE)
49	External fault input (EF)
50	Emergency stop (EF1)
51	External Base Block (B.B.)
52	Password error (PcodE)

53	Software error (ccodE)
54	Communication error (cE1)
55	Communication error (cE2)
56	Communication error (cE3)
57	Communication error (cE4)
58	Communication Time-out (cE10)
59	PU time-out (cP10)
60	Brake transistor error (bF)
61	Y-connection/ Δ -connection switch error (ydc)
62	Decel. Energy Backup Error (dEb)

 It will record when the fault occurs and force stopping. For the Lv, it will record when it is operation, or it will warn without record.

 Setting 62: when DEB function is enabled, the drive will execute DEB and record to the Pr.06-07 to Pr.06-22 simultaneously.

06-23	 Fault Output Option 1	Unit: 1
06-24	 Fault Output Option 2	Unit: 1
06-25	 Fault Output Option 3	Unit: 1
06-26	 Fault Output Option 4	Unit: 1
Settings 0 to 65535 sec (refer to bit table for fault code)		Factory Setting: 0

 These parameters can be used with multi-function output (set Pr.02-11 to Pr.02-14 to 35-38) for the specific requirement. When the fault occurs, the corresponding terminals will be activated (It needs to convert binary value to decimal value to fill in Pr.06-23 to Pr.06-26).

Fault code	Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6
	current	Volt.	OL	SYS	FBK	EXI	CE
0: No fault							
1: Over-current during acceleration (ocA)	●						
2: Over-current during deceleration (ocd)	●						
3: Over-current during constant speed (ocn)	●						
4: Ground fault (GFF)						●	
5: IGBT short-circuit (occ)	●						

Fault code	Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6
	current	Volt.	OL	SYS	FBK	EXI	CE
6: Over-current at stop (ocS)	●						
7: Over-voltage during acceleration (ovA)		●					
8: Over-voltage during deceleration (ovd)		●					
9: Over-voltage during constant speed (ovn)		●					
10: Over-voltage at stop (ovS)		●					
11: Low-voltage during acceleration (LvA)		●					
12: Low-voltage during deceleration (Lvd)		●					
13: Low-voltage during constant speed (Lvn)		●					
14: Low-voltage at stop (LvS)		●					
15: Phase loss (PHL)						●	
16: IGBT heat sink over-heat (oH1)			●				
17: Heat sink over-heat (oH2)(for 40HP above)			●				
18: TH1 open loop error (tH1o)			●				
19: TH2 open loop error (tH2o)			●				
20: Fan error signal output						●	
21: over-load (oL) (150% 1Min)			●				
22: Motor 1 over-load (EoL1)			●				
23: Motor 2 over-load (EoL2)			●				
24: Motor PTC overheat (oH3)			●				
25: Fuse error (FuSE)						●	
26: over-torque 1 (ot1)			●				
27: over-torque 1 (ot2)			●				
28: Insufficient torque 1	●						
29: Insufficient torque 2	●						

Fault code	Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6
	current	Volt.	OL	SYS	FBK	EXI	CE
30: Memory write-in error (cF1)				●			
31: Memory read-out error (cF2)				●			
32: Isum current detection error (cd0)				●			
33: U-phase current detection error (cd1)				●			
34: V-phase current detection error (cd2)				●			
35: W-phase current detection error (cd3)				●			
36: Clamp current detection error (Hd0)				●			
37: Over-current detection error (Hd1)				●			
38: Over-voltage detection error (Hd2)				●			
39: Ground current detection error (Hd3)				●			
40: Auto tuning error (AuE)				●			
41: PID feedback loss (AFE)					●		
42: PG feedback error (PGF1)					●		
43: PG feedback loss (PGF2)					●		
44: PG feedback stall (PGF3)					●		
45: PG slip error (PGF4)					●		
46: PG ref input error (PGr1)					●		
47: PG ref loss (PGr2)					●		
48: Analog current input loss (ACE)					●		
49: External fault input (EF)						●	
50: Emergency stop (EF1)						●	
51: External Base Block (B.B.)						●	
52: Password error (PcodE)				●			

Fault code	Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6
	current	Volt.	OL	SYS	FBK	EXI	CE
53: Software error (ccodE)				●			
54: Communication error (cE1)							●
55: Communication error (cE2)							●
56: Communication error (cE3)							●
57: Communication error (cE4)							●
58: Communication Time-out (cE10)							●
59: PU time-out (cP10)							●
60: Brake transistor error (bF)						●	
61: Y-connection/ Δ -connection switch error (ydc)						●	
62: Decel. Energy Backup Error (dEb)		●					

06-29 ✓ PTC (Positive Temperature Coefficient) Detection Selection

Factory Setting: 0

Settings	0	Warn and keep operating
	1	Warn and ramp to stop
	2	Warn and coast to stop

 It is used to set the treatment after detecting PTC.

06-30 ✓ PTC Level

Unit: 0.1

Settings 0.0 to 100.0%

Factory Setting: 50.0

 It is used to set the PTC level, and the corresponding value for 100% is max. analog input value.

06-31 ✓ Filter Time for PTC Detection

Unit: 0.01

Settings 0.00 to 10.00 秒

Factory Setting: 0.20

Group 7 Special Parameters

07-00	 Software Braking Level	Unit: 0.1
Settings	230V series 350.0~450.0Vdc	Factory Setting: 380.0
	460V series 700.0~900.0Vdc	Factory Setting: 760.0

 This parameter sets the DC-bus voltage at which the brake chopper is activated.

07-01	 DC Braking Current Level	Unit: 1
Settings	0 to 100%	Factory Setting: 0

 This parameter sets the level of DC Braking Current output to the motor during start-up and stopping. When setting DC Braking Current, the Rated Current (Pr.00-01) is regarded as 100%. It is recommended to start with a low DC Braking Current Level and then increase until proper holding torque has been attained.

 When it is in FOC PG/TQRPG mode, it can enable DC braking function by setting to any value.

07-02	 DC Braking Time during Start-up	Unit: 0.1
Settings	0.0 to 60.0 sec	Factory Setting: 0.0


 This parameter determines the duration of the DC Braking current after a RUN command. When the time has elapsed, the AC motor drive will start accelerating from the Minimum Frequency (Pr.01-05).

07-03	 DC Braking Time during Stopping	Unit: 0.1
Settings	0.0 to 60.0 sec	Factory Setting: 0.0

 This parameter determines the duration of the DC Braking current during stopping.

07-04	 Start-Point for DC Braking	Unit: 0.01
Settings	0.00 to 600.00Hz	Factory Setting: 0.00

 This parameter determines the frequency when DC Braking will begin during deceleration.



- DC Braking during Start-up is used for loads that may move before the AC drive starts, such as fans and pumps. Under such circumstances, DC Braking can be used to hold the load in position before setting it in motion.
- DC Braking during stopping is used to shorten the stopping time and also to hold a stopped load in position. For high inertia loads, a dynamic braking resistor may also be needed for fast decelerations.

07-05	DC Braking Proportional Gain	Unit: 1
Settings	1 to 500Hz	Factory Setting: 50

- It is used to set the output voltage gain when DC braking.

07-06	✓ Momentary Power Loss Operation Selection	Factory Setting: 0
Settings	0 Operation stops after momentary power loss.	
	1 Operation continues after momentary power loss, speed search starts with the Master Frequency reference value.	
	2 Operation continues after momentary power loss, speed search starts with the minimum frequency.	

- This parameter determines the operation mode when the AC motor drive restarts from a momentary power loss.
- In PG control mode, the AC motor drive will execute the speed search function automatically by the PG speed when this setting isn't set to 0.

07-07	✓ Maximum Allowable Power Loss Time	Unit: 0.1
Settings	0.1 to 5.0 sec	Factory Setting: 2.0

- If the duration of a power loss is less than this parameter setting, the AC motor drive will resume operation. If it exceeds the Maximum Allowable Power Loss Time, the AC motor drive output is then turned off (coast stop).
- The selected operation after power loss in Pr.07-06 is only executed when the maximum allowable power loss time is ≤ 5 seconds and the AC motor drive displays "Lu".
- But if the AC motor drive is powered off due to overload, even if the maximum allowable power loss time is ≤ 5 seconds, the operation mode as set in Pr.07-06 is not executed. In that case it starts up normally.


07-08 **Baseblock Time for Speed Search (BB)**


Unit: 0.1

Settings 0.1 to 5.0 sec

Factory Setting: 0.5

- When momentary power loss is detected, the AC drive will block its output and then wait for a specified period of time (determined by Pr.07-08, called Base-Block Time) before resuming operation. This parameter should be set at a value to ensure that any residual regeneration voltage from the motor on the output has disappeared before the drive is activated again.





B.B. Search with minimum output frequency upward timing chart

07-09 **✓** Current Limit for Speed Search

Unit: 1

Settings 20 to 200%

Factory Setting: 150

Following a momentary power loss, the AC motor drive will start its speed search operation only if the output current is greater than the value set by Pr.8-07. When the output current is less than the value of Pr.8-07, the AC motor drive output frequency is at "speed synchronization point". The drive will start to accelerate or decelerate back to the operating frequency at which it was running prior to the power loss.

When executing speed search, the V/f curve is operated by group 1 setting. The maximum current for the optimum accel./decel. and start speed search is set by Pr.07-09.

07-10 **✓** Base Block Speed Search

Factory Setting: 0

Settings	0	Stop operation
	1	Speed search starts with last frequency command
	2	Speed search starts with minimum output frequency

This parameter determines the AC motor drive restart method after External Base Block is enabled.

In PG control mode, the AC motor drive will execute the speed search function automatically by the PG speed when this setting isn't set to 0.

07-11 **✓** Auto Restart After Fault

Unit: 1

Settings 0 to 10

Factory Setting: 0

-  Only after an over-current OC or over-voltage OV fault occurs, the AC motor drive can be reset/restarted automatically up to 10 times.
-  Setting this parameter to 0 will disable the reset/restart operation after any fault has occurred. When enabled, the AC motor drive will restart with speed search, which starts at the frequency before the fault. To set the waiting time before restart after a fault, please set Pr. 07-08 Base Block Time for Speed Search.

07-12 Speed Search during Start-up

Factory Setting: 0

Settings	0	Disable
	1	Speed search from maximum frequency
	2	Speed search from start-up frequency
	3	Speed search from minimum frequency

-  This parameter is used for starting and stopping a motor with high inertia. A motor with high inertia will take a long time to stop completely. By setting this parameter, the user does not need to wait for the motor to come to a complete stop before restarting the AC motor drive. If a PG card and encoder is used on the drive and motor, then the speed search will start from the speed that is detected by the encoder and accelerate quickly to the commanded frequency. The output current is set by the Pr.07-09.
-  In PG control mode, the AC motor drive will execute the speed search function automatically by the PG speed when this setting isn't set to 0.

07-13 Decel. Time Selection for Momentary Power Loss (DEB function)


Factory Setting: 0

Settings	0	Disable
	1	1st decel. time
	2	2 nd decel. time
	3	3 rd decel. time
	4	4 th decel. time
	5	Current decel. time
	6	Auto decel. Time

-  This parameter is used for the decel. time selection for momentary power loss.


The DEB (Deceleration Energy Backup) function is the AC motor drive decelerates to stop after momentary power loss. When the momentary power loss occurs, this function can be used for the motor to decelerate to 0 speed with deceleration stop method. When the power is on again, motor will run again after DEB return time.

Status 1: Insufficient power supply due to momentary power-loss/unstable power (due to low voltage)/sudden heavy-load

**NOTE**

When Pr.07-14 is set to 0, the AC motor drive will be stopped and won't re-start at the power-on again.

Status 2: unexpected power off, such as momentary power loss






For VFD-VE series, the DEB function can be used by deceleration time via EF without using external terminals. For example, in textile machinery, you will hope that all the machines can be decelerated to stop to prevent broken stitching when power loss. In this case, the host controller will send a message to the AC motor drive to use DEB function with deceleration time via EF.

07-15	↗ Dwell Time at Accel.	Unit: 0.01
Settings	0.00 to 600.00 sec	Factory Setting: 0.00
07-16	↗ Dwell Frequency at Accel.	Unit: 0.01
Settings	0.00 to 600.00 Hz	Factory Setting: 0.00
07-17	↗ Dwell Time at Decel.	Unit: 0.01
Settings	0.00 to 600.00 sec	Factory Setting: 0.00
07-18	↗ Dwell Frequency at Decel.	Unit: 0.01
Settings	0.00 to 600.00 Hz	Factory Setting: 0.00

In the heavy load situation, Dwell can make stable output frequency temporarily.

Pr.07-15 to Pr.07-18 is for heavy load to prevent OV or OC occurs.



07-19	↗ Fan Control	Factory Setting: 0
Settings	0 Fan always ON	
	1 1 minute after AC motor drive stops, fan will be OFF	
	2 AC motor drive runs and fan ON, AC motor drive stops and fan OFF	
	3 Fan ON to run when preliminary heat sink temperature attained	
	4 Fan always OFF	

This parameter is used for the fan control.

07-20	✓ Torque Command	Unit: 0.1
Settings	-100.0 to 100.0% (Pr. 07-22 setting=100%)	Factory Setting: 0.0

 This parameter is torque command. When Pr.07-22 is 250% and Pr.07-20 is 100%, the actual torque command = 250X100% X motor rated torque.

07-21	✓ Torque Command Source	Factory Setting: 0
Settings	0 Digital keypad	
	1 RS485 serial communication (RJ-11)	
	2 Analog signal (Pr.03-00)	

 This parameter is torque command source and the torque command is in Pr.07-20.


07-22	✓ Maximum Torque Command	Unit: 1
Settings	0 to 500%	Factory Setting: 100

 This parameter is for the max. torque command (motor rated torque is 100%).


07-23	✓ Filter Time of Torque Command	Unit: 0.001
Settings	0.000 to 1.000 sec	Factory Setting: 0.000

 When the setting is too long, the control will be stable but the control response will be delay.
When the setting is too short, the response will be quickly but the control maybe unstable.
User can adjust the setting by the control and response situation.

07-24	Speed Limit Selection	Factory Setting: 0
Settings	0 By Pr.07-25 and Pr.07-26	
	1 Frequency command source (Pr.00-20)	



07-26 07-25
Pr.07-24=0
Running/opposite running
direction are
limited by Pr.07-25
and Pr.07-26.



07-26 00-20
07-24=1
When it is forward running,
running direction is limited
by Pr.00-20
opposite running direction
is limited by Pr.07-26.



00-20 07-25
07-24=1
When it is reverse running,
running direction is limited
by Pr.07-25
opposite running direction
is limited by Pr.00-20.

07-25	⚡ Torque Mode +Speed Limit	Unit: 1
07-26	⚡ Torque Mode-Speed Limit	Unit: 1
Settings	0 to 120%	Factory Setting: 10

These parameters are used in the torque mode to limit the running direction and opposite direction. (Pr.01-00 max. output frequency=100%)

07-27	⚡ Source of Torque Offset	Factory Setting: 0
Settings	0 Disable 1 Analog input (Pr.03-00) 2 Torque offset setting 3 Control by external terminal (by Pr.07-29 to Pr.07-31)	

This parameter is the source of torque offset.

When it is set to 3, the source of torque offset will decide to Pr.07-29, Pr.07-30 and Pr.07-31 by the multi-function input terminals setting (31, 32 or 33).

02-01~02-06 is set to 31	02-01~02-06 is set to 32	02-01~02-06 is set to 33	Torque offset
OFF	OFF	OFF	None
OFF	OFF	ON	07-33
OFF	ON	OFF	07-32
OFF	ON	ON	07-33+07-32
ON	OFF	OFF	07-31
ON	OFF	ON	07-31+07-33
ON	ON	OFF	07-31+07-32
ON	ON	ON	07-31+07-32+07-33

07-28	✓ Torque Offset Setting	Unit: 0.1
Settings	0.0 to 100.0%	Factory Setting: 0.0

This parameter is torque offset. The motor rated torque is 100%.

07-29	✓ High Torque Offset	Unit: 0.1
Settings	0.0 to 100.0%	Factory Setting: 30.0


07-30	✓ Middle Torque Offset	Unit: 0.1
Settings	0.0 to 100.0%	Factory Setting: 20.0


07-31	✓ Low Torque Offset	Unit: 0.1
Settings	0.0 to 100.0%	Factory Setting: 10.0

When it is set to 3, the source of torque offset will decide to Pr.07-29, Pr.07-30 and Pr.07-31 by the multi-function input terminals setting (31, 32 or 33). The motor rated torque is 100%.

07-32	✓ Forward Motor Torque Limit	Unit: 1
07-33	✓ Forward Regenerative Torque Limit	Unit: 1
07-34	✓ Reverse Motor Torque Limit	Unit: 1
07-35	✓ Reverse Regenerative Torque Limit	Unit: 1
Settings	0 to 500%	Factory Setting: 200

The motor rated torque is 100%. The settings for Pr.07-32 to Pr.07-35 will compare with Pr.03-00=7, 8, 9, 10. The minimum of the comparison result will be torque limit.





07-36 Emergency Stop (EF) & Forced Stop Selection

Factory Setting: 0

Settings	0	Coast stop
	1	By deceleration Time 1
	2	By deceleration Time 2
	3	By deceleration Time 3
	4	By deceleration Time 4
	5	System Deceleration
	6	Automatic Deceleration



When the multi-function input terminal is set to 10 or 18 and it is ON, the AC motor drive will be operated by Pr.07-36.

Group 8 High-function PID Parameters**08-00** ✓ Input Terminal for PID Feedback

Factory Setting: 0

Settings	0	No function
	1	Positive PID feedback from external terminal AVI (Pr.03-00)
	2	Positive PID feedback from PG card (Pr.10-15, skip direction)
	3	Positive PID feedback from PG card (Pr.10-15)
	4	Negative PID feedback from external terminal AVI (Pr.03-00)
	5	Negative PID feedback from PG card (Pr.10-15, skip direction)
	6	Negative PID feedback from PG card (Pr.10-15)

 Negative feedback means: +target value – feedback. It is used for the detection value will be increased by increasing the output frequency.

 Positive feedback means: -target value + feedback. It is used for the detection value will be decreased by increasing the output frequency.

08-01 ✓ Proportional Gain (P)

Unit: 0.1

Settings	0.0 to 500.0%	Factory Setting: 80.0
----------	---------------	-----------------------

 This parameter determinates the gain of the feedback loop. If the gain is large, the response will be strong and immediate (if the gain is too large, vibration may occur). If the gain is small, the response will weak and slow.

08-02 ✓ Integral Gain (I)

Unit: 0.01

Settings	0.0 to 100.0 sec	Factory Setting: 1.00
----------	------------------	-----------------------

 This parameter determines the speed of response for the PID feedback loop. If the integral time is long, the response will be slow. If the integral time is short, the response will be quick. Be careful not to set(I) too small, since a rapid response may cause oscillation in the PID loop.

 If the integral time is set as 0.00, Pr.08-02 will be disabled.

08-03 ✓ Derivative Control (D)

Unit: 0.01

Settings	0.00 to 1.00 sec	Factory Setting: 0.00
----------	------------------	-----------------------

 This parameter determines the damping effect for the PID feedback loop. If the differential time is long, any oscillation will quickly subside. If the differential time is short, the oscillation will subside slowly.

08-04 Upper limit for Integral Control

Unit: 0.1

Settings 0.0 to 100.0%

Factory Setting: 0.0

This parameter defines an upper bound or limit for the integral gain (I) and therefore limits the Master Frequency.

The formula is: Integral upper bound = Maximum Output Frequency (Pr.01-00) x (Pr.08-04).

08-05 PID Output Frequency Limit

Unit: 0.1

Settings 0.0 to 110.0%

Factory Setting: 100.0

This parameter defines the percentage of output frequency limit during the PID control. The formula is Output Frequency Limit = Maximum Output Frequency (Pr.01-00) X Pr.08-05 %.

This parameter will limit the Maximum Output Frequency.

08-06 PID Offset

Unit: 0.1

Settings -100.0 to 100.0%


Factory Setting: 0.0

08-07 PID Delay Time

Unit: 0.1

Settings 0.0 to 2.5%

Factory Setting: 0.0



PI Control: controlled by the P action only, and thus, the deviation cannot be eliminated entirely. To eliminate residual deviations, the P + I control will generally be utilized. And when the PI control is utilized, it could eliminate the deviation incurred by the targeted value changes and the constant external interferences. However, if the I action is excessively powerful, it will delay the responding toward the swift variation. The P action could be used solely on the loading system that possesses the integral components.

 **PD Control:** when deviation occurred, the system will immediately generate some operation load that is greater than the load generated single handedly by the D action to restrain the increment of the deviation. If the deviation is small, the effectiveness of the P action will be decreasing as well. The control objects include occasions with integral component loads, which are controlled by the P action only, and sometimes, if the integral component is functioning, the whole system will be vibrating. On such occasions, in order to make the P action's vibration subsiding and the system stabilizing, the PD control could be utilized. In other words, this control is good for use with loadings with no braking functions over the processes.

 **PID Control:** Utilize the I action to eliminate the deviation and the D action to restrain the vibration, thereafter, combine with the P action to construct the PID control. Use of the PID method could obtain a control process with no deviations, high accuracies and a stable system.

08-08	 Feedback Signal Detection Time	Unit: 0.1
	Settings 0.0 to 3600.0%	Factory Setting: 0.0

 This parameter defines the time during which the PID feedback must be abnormal before a warning is given. It also can be modified according to the system feedback signal time.

 If this parameter is set to 0.0, the system would not detect any abnormality signal.

08-09	 Feedback Fault Treatment	Factory Setting: 0
	Settings 0 Warn and keep operating	
	1 Warn and RAMP to stop	
	2 Warn and COAST to stop	
	3 Warn and keep at last frequency	

 AC motor drive acts when the feedback signals (analog PID feedback or PG (encoder) feedback) are abnormal.

08-10	 Sleep Frequency	Unit: 0.01
	Settings 0.0 to 600.0Hz	Factory Setting: 0.00

08-11	 Wake-up Frequency	Unit: 0.01
	Settings 0.0 to 600.0Hz	Factory Setting: 0.00

08-12 ⚡ Sleep Time


Unit: 0.1

Settings 0.0 to 6000.0sec

Factory Setting: 0.0



These parameters determine sleep functions of the AC drive. If the command frequency falls below the sleep frequency, for the specified time in Pr. 08-12, then the drive will shut off the output and wait until the command frequency rises above Pr. 08-11. Please see the below diagram.

**08-13** ⚡ PID Deviation Level

Unit: 0.1

Settings 1.0 to 50.0%

Factory Setting: 10.0

08-14 ⚡ PID Deviation Time

Unit: 0.1

Settings 0.1 to 300.0 sec

Factory Setting: 5.0

08-15 ⚡ Filter Time for PID Feedback


Unit: 0.1

Settings 0.1 to 300.0 sec

Factory Setting: 5.0

Group 9: Communication Parameters

There is a built-in RS-485 serial interface, marked RJ-11 near to the control terminals. The pins are defined below:



Each VFD-VE AC drive has a pre-assigned communication address specified by Pr.09-00. The RS485 master then controls each AC motor drive according to its communication address.

09-00 ✓ Communication Address

Settings 1 to 254

Factory Setting: 1

If the AC motor drive is controlled by RS-485 serial communication, the communication address for this drive must be set via this parameter. And the communication address for each AC motor drive must be different and unique.

09-01 ✓ COM1 Transmission Speed

Settings 4.8 to 115.2kbps

Factory Setting: 9.6

This parameter is used to set the transmission speed between the RS485 master (PLC, PC, etc.) and AC motor drive.

09-02 ✓ COM1 Transmission Fault Treatment

Factory Setting: 3

- | | | |
|----------|---|-------------------------------|
| Settings | 0 | Warn and keep operating |
| | 1 | Warn and RAMP to stop |
| | 2 | Warn and COAST to stop |
| | 3 | No warning and keep operating |

This parameter is set to how to react if transmission errors occur.

09-03 ✓ COM1 Time-out Detection

Unit: 0.1

Settings 0.0 ~ 100.0 sec

Factory Setting: 0.0

If Pr.09-03 is not set to 0.0, Pr.09-02=0~2, and there is no communication on the bus during the Time Out detection period (set by Pr.09-03), "cE10" will be shown on the keypad.

09-04 COM1 Communication Protocol

Factory Setting: 1

Settings	0	Modbus ASCII mode, protocol <7,N,1>
	1	Modbus ASCII mode, protocol <7,N,2>
	2	Modbus ASCII mode, protocol <7,E,1>
	3	Modbus ASCII mode, protocol <7,O,1>
	4	Modbus ASCII mode, protocol <7,E,2>
	5	Modbus ASCII mode, protocol <7,O,2>
	6	Modbus ASCII mode, protocol <8,N,1>
	7	Modbus ASCII mode, protocol <8,N,2>
	8	Modbus ASCII mode, protocol <8,E,1>
	9	Modbus ASCII mode, protocol <8,O,1>
	10	Modbus ASCII mode, protocol <8,E,2>
	11	Modbus ASCII mode, protocol <8,O,2>
	12	Modbus RTU mode, protocol <8,N,1>
	13	Modbus RTU mode, protocol <8,N,2>
	14	Modbus RTU mode, protocol <8,E,1>
	15	Modbus RTU mode, protocol <8,O,1>
	16	Modbus RTU mode, protocol <8,E,2>
	17	Modbus RTU mode, protocol <8,O,2>



1. Control by PC or PLC

- ★ A VFD-VE can be set up to communicate on Modbus networks using one of the following modes: ASCII (American Standard Code for Information Interchange) or RTU (Remote Terminal Unit). Users can select the desired mode along with the serial port communication protocol in Pr.09-04.

★ Code Description:

ASCII mode:

Each 8-bit data is the combination of two ASCII characters. For example, a 1-byte data:

64 Hex, shown as '64' in ASCII, consists of '6' (36Hex) and '4' (34Hex).

Character	'0'	'1'	'2'	'3'	'4'	'5'	'6'	'7'
ASCII code	30H	31H	32H	33H	34H	35H	36H	37H


Character	'8'	'9'	'A'	'B'	'C'	'D'	'E'	'F'
ASCII code	38H	39H	41H	42H	43H	44H	45H	46H

RTU mode:


Each 8-bit data is the combination of two 4-bit hexadecimal characters. For example, 64 Hex.

2. Data Format

10-bit character frame (For ASCII):



11-bit character frame (For RTU):



3. Communication Protocol

3.1 Communication Data Frame:

ASCII mode:

STX	Start character ':' (3AH)
Address Hi	Communication address:
Address Lo	8-bit address consists of 2 ASCII codes
Function Hi	Command code:
Function Lo	8-bit command consists of 2 ASCII codes
DATA (n-1) to DATA 0	Contents of data: Nx8-bit data consist of 2n ASCII codes n<=16, maximum of 32 ASCII codes
LRC CHK Hi	LRC check sum:

LRC CHK Lo	8-bit check sum consists of 2 ASCII codes
END Hi	End characters:
END Lo	END1= CR (0DH), END0= LF(0AH)

RTU mode:

START	A silent interval of more than 10 ms
Address	Communication address: 8-bit address
Function	Command code: 8-bit command
DATA (n-1) to DATA 0	Contents of data: n×8-bit data, n≤16
CRC CHK Low	CRC check sum: 16-bit check sum consists of 2 8-bit characters
CRC CHK High	
END	A silent interval of more than 10 ms

3.2 Address (Communication Address)

Valid communication addresses are in the range of 0 to 254. A communication address equal to 0, means broadcast to all AC drives (AMD). In this case, the AMD will not reply any message to the master device.

00H: broadcast to all AC drives

01H: AC drive of address 01

0FH: AC drive of address 15

10H: AC drive of address 16

:

FEH: AC drive of address 254

For example, communication to AMD with address 16 decimal (10H):

ASCII mode: Address='1','0' => '1'=31H, '0'=30H

RTU mode: Address=10H

3.3 Function (Function code) and DATA (data characters)

The format of data characters depends on the function code.

03H: read data from register

06H: write single register

08H: loop detection

10H: write multiple registers

The available function codes and examples for VFD-VE are described as follows:

(1) 03H: multi read, read data from registers.

Example: reading continuous 2 data from register address 2102H, AMD address is 01H.

ASCII mode:

Command message:

STX	':'
Address	'0'
	'1'
Function	'0'
	'3'
Starting data address	'2'
	'1'

Response message:

STX	':'
Address	'0'
	'1'
Function	'0'
	'3'
Number of data (Count by byte)	'0'
	'4'

Command message:

Number of data (count by word)	'0'
	'2'
	'0'
	'0'
	'2'
LRC Check	'D'
	'7'
END	CR
	LF

Response message:

Content of starting address 2102H	'1'
	'7'
	'7'
Content of address 2103H	'0'
	'0'
	'0'
LRC Check	'7'
	'1'
END	CR
	LF

RTU mode:

Command message:

Address	01H
Function	03H
Starting data address	21H
	02H
Number of data (count by word)	00H
	02H
CRC CHK Low	6FH
CRC CHK High	F7H

Response message:

Address	01H
Function	03H
Number of data (count by byte)	04H
Content of address 2102H	17H
	70H
Content of address 2103H	00H
	00H
CRC CHK Low	FEH
CRC CHK High	5CH

(2) 06H: single write, write single data to register.

Example: writing data 6000(1770H) to register 0100H. AMD address is 01H.

ASCII mode:

Command message:

STX	0x02
Address	'0'
	'1'
Function	'0'
	'6'
Data address	'0'
	'1'
	'0'
	'0'
Data content	'1'
	'7'
	'7'
	'0'
LRC Check	'7'
	'1'
END	CR
	LF

Response message:

STX	0x02
Address	'0'
	'1'
Function	'0'
	'6'
Data address	'0'
	'1'
	'0'
	'0'
Data content	'1'
	'7'
	'7'
	'0'
LRC Check	'7'
	'1'
END	CR
	LF

RTU mode:

Command message:

Address	01H
Function	06H
Data address	01H
	00H
Data content	17H
	70H
CRC CHK Low	86H
CRC CHK High	22H

Response message:

Address	01H
Function	06H
Data address	01H
	00H
Data content	17H
	70H
CRC CHK Low	86H
CRC CHK High	22H

(3) 10H: write multiple registers (write multiple data to registers)

Example: Set the multi-step speed,

Pr.05-00=50.00 (1388H), Pr.05-01=40.00 (0FA0H). AC drive address is 01H.

ASCII Mode:

Command message:

STX	‘.’
Address 1	‘0’
	Address 0
Function 1	‘1’
	Function 0
Starting data address	‘0’
	‘5’
	‘0’
Number of data (count by word)	‘0’
	‘0’
	‘0’
	‘2’
Number of data (count by byte)	‘0’
	‘4’
	‘1’
The first data content	‘3’
	‘8’
	‘8’
	‘0’
The second data content	‘F’
	‘A’
	‘0’
	‘0’
LRC Check	‘9’
	‘A’
END	CR
	LF

Response message:

STX	‘.’
Address 1	‘0’
	Address 0
Function 1	‘1’
	Function 0
Starting data address	‘0’
	‘5’
	‘0’
Number of data (count by word)	‘0’
	‘0’
	‘0’
	‘2’
LRC Check	‘E’
	‘8’
END	CR
	LF

RTU mode:

Command message:

Address	01H
Function	10H

Response message:

Address	01H
Function	10H

Starting data address	05H
	00H
	00H'
	02H
Number of data (count by word)	04
The first data content	13H
	88H
The second data content	0FH
	A0H
CRC Check Low	'9'
CRC Check High	'A'

Starting data address	05H
	00H
Number of data (count by word)	02H
CRC Check Low	41H
CRC Check High	04H

3.4 Check sum

ASCII mode:

LRC (Longitudinal Redundancy Check) is calculated by summing up, module 256, the values of the bytes from ADR1 to last data character then calculating the hexadecimal representation of the 2's-complement negation of the sum.

For example, reading 1 word from address 0401H of the AC drive with address 01H.

STX	':'
Address 1	'0'
Address 0	'1'
Function 1	'0'
Function 0	'3'
Starting data address	'0'
	'4'
	'0'
	'1'
Number of data	'0'
	'0'
	'0'
	'1'
LRC Check 1	'F'
LRC Check 0	'6'
END 1	CR
END 0	LF

01H+03H+04H+01H+00H+01H=0AH, the 2's-complement negation of 0AH is **F6H**.

RTU mode:

Address	01H
Function	03H
Starting data address	21H
	02H
Number of data (count by word)	00H
	02H
CRC CHK Low	6FH
CRC CHK High	F7H

CRC (Cyclical Redundancy Check) is calculated by the following steps:

Step 1: Load a 16-bit register (called CRC register) with FFFFH.

Step 2: Exclusive OR the first 8-bit byte of the command message with the low order byte of the 16-bit CRC register, putting the result in the CRC register.

Step 3: Examine the LSB of CRC register.

Step 4: If the LSB of CRC register is 0, shift the CRC register one bit to the right with MSB zero filling, then repeat step 3. If the LSB of CRC register is 1, shift the CRC register one bit to the right with MSB zero filling, Exclusive OR the CRC register with the polynomial value A001H, then repeat step 3.

Step 5: Repeat step 3 and 4 until eight shifts have been performed. When this is done, a complete 8-bit byte will have been processed.

Step 6: Repeat step 2 to 5 for the next 8-bit byte of the command message. Continue doing this until all bytes have been processed. The final contents of the CRC register are the CRC value. When transmitting the CRC value in the message, the upper and lower bytes of the CRC value must be swapped, i.e. the lower order byte will be transmitted first.

The following is an example of CRC generation using C language. The function takes two arguments:

Unsigned char* data ← a pointer to the message buffer

Unsigned char length ← the quantity of bytes in the message buffer

The function returns the CRC value as a type of unsigned integer.

```
Unsigned int crc_chk(unsigned char* data, unsigned char length){
    int j;
    unsigned int reg_crc=0xFFFF;
    while(length--){
        reg_crc ^= *data++;
        for(j=0;j<8;j++){
            if(reg_crc & 0x01){ /* LSB(b0)=1 */
                reg_crc=(reg_crc>>1) ^ 0xA001;
            }else{
                reg_crc=reg_crc >>1;
            }
        }
    }
    return reg_crc;
}
```

3.5 Address list

The contents of available addresses are shown as below:

Content	Address	Function
AC drive Parameters	GGnnH	GG means parameter group, nn means parameter number, for example, the address of Pr 4-01 is 0401H. Referencing to chapter 5 for the function of each parameter. When reading parameter by command code 03H, only one parameter can

Content	Address	Function	
		be read at one time.	
Command Write only	2000H	Bit 0-3	0: No function 1: Stop 2: Run 3: Jog + Run
Command Write only	2000H	Bit 4-5	00B: No function 01B: FWD 10B: REV 11B: Change direction
		Bit 6-7	00B: 1st accel/decel 01B: 2nd accel/decel 10B: 3rd accel/decel 11B: 4th accel/decel
		Bit 8-11	Represented 16 step speeds.
		Bit 12	0: No comm. multi step speed or accel/decel time 1: Comm. multi step speed or accel/decel time
		Bit 13~14	00B: No function
			01B: operated by digital keypad
			02B: operated by Pr.00-21 setting
			03B: change operation source
	Bit 15	Reserved	
	2001H	Frequency command	
	2002H	Bit 0	1: EF (external fault) on
		Bit 1	1: Reset
		Bit 2	1: B.B. ON
		Bit 3-15	Reserved
Status monitor Read only	2100H	Error code: refer to Pr.06-17 to Pr.06-22	
	2119H	Bit 0	1: FWD command
Bit 1		1: Operation status	
Bit 2		1: Jog command	
Bit 3		1: REV command	
Bit 4		1: REV command	
Bit 8		1: Master frequency Controlled by communication interface	
	Bit 9	1: Master frequency controlled by analog signal	
	Bit 10	1: Operation command controlled by communication interface	
	Bit 11	1: Parameters have been locked	
	Bit 12	1: enable to copy parameter from keypad	
	Bit 13-15	Reserved	
	2102H	Frequency command (F)	
	2103H	Output frequency (H)	
	2104H	Output current (AXXX.X)	
	2105H	DC-BUS Voltage (UXXX.X)	
	2106H	Output voltage (EXXX.X)	
	2107H	Current step number of Multi-Step Speed Operation	
	2109H	Counter value	
	2116H	Multi-function display (Pr.00-04)	
	211AH	Setting frequency (F)	
	211BH	Max. setting frequency	

Content	Address	Function
	211CH	Max. output frequency
	2200H	Feedback Signal (XXX.XX %)
	2203H	AVI analog input (XXX.XX %)
	2204H	ACI analog input (XXX.XX %)
	2205H	AUI analog input (XXX.XX %)
	2206H	Display temperature of IGBT (°C)
	2207H	Display temperature of heatsink (°C)

3.6 Exception response:

The AC motor drive is expected to return a normal response after receiving command messages from the master device. The following depicts the conditions when no normal response is replied to the master device.

The AC motor drive does not receive the messages due to a communication error; thus, the AC motor drive has no response. The master device will eventually process a timeout condition.

The AC motor drive receives the messages without a communication error, but cannot handle them. An exception response will be returned to the master device and an error message "CExx" will be displayed on the keypad of AC motor drive. The xx of "CExx" is a decimal code equal to the exception code that is described below.

In the exception response, the most significant bit of the original command code is set to 1, and an exception code which explains the condition that caused the exception is returned.

Example of an exception response of command code 06H and exception code 02H:

ASCII mode:

STX	':'
Address Low	'0'
Address High	'1'
Function Low	'8'
Function High	'6'
Exception code	'0'
	'2'
LRC CHK Low	'7'
LRC CHK High	'7'
END 1	CR
END 0	LF

RTU mode:

Address	01H
Function	86H
Exception code	02H
CRC CHK Low	C3H
CRC CHK High	A1H

The explanation of exception codes:

Exception code	Explanation
01	Illegal function code: The function code received in the command message is not available for the AC motor drive.
02	Illegal data address: The data address received in the command message is not available for the AC motor drive.
03	Illegal data value: The data value received in the command message is not available for the AC drive.

Exception code	Explanation
04	Slave device failure: The AC motor drive is unable to perform the requested action.
10	Communication time-out: If Pr.09-03 is not equal to 0.0, Pr.09-02=0~2, and there is no communication on the bus during the Time Out detection period (set by Pr.09-03), "cE10" will be shown on the keypad.

3.7 Communication program of PC:

The following is a simple example of how to write a communication program for Modbus ASCII mode on a PC by C language.

```
#include<stdio.h>
#include<dos.h>
#include<conio.h>
#include<process.h>
#define PORT 0x03F8 /* the address of COM1 */
/* the address offset value relative to COM1 */
#define THR 0x0000
#define RDR 0x0000
#define BRDL 0x0000
#define IER 0x0001
#define BRDH 0x0001
#define LCR 0x0003
#define MCR 0x0004
#define LSR 0x0005
#define MSR 0x0006
unsigned char rdat[60];
/* read 2 data from address 2102H of AC drive with address 1 */
unsigned char tdat[60]={'.','0','1','0','3','2','1','0','2',' ','0','0','0','2','D','7','r','\n'};
void main(){
    int i;
    outputb(PORT+MCR,0x08);          /* interrupt enable */
    outputb(PORT+IER,0x01);          /* interrupt as data in */
    outputb(PORT+LCR,(inportb(PORT+LCR) | 0x80));
    /* the BRDL/BRDH can be access as LCR.b7==1 */
    outputb(PORT+BRDL,12);           /* set baudrate=9600, 12=115200/9600*/
    outputb(PORT+BRDH,0x00);
    outputb(PORT+LCR,0x06);          /* set protocol, <7,N,2>=06H, <7,E,1>=1AH, <7,O,1>=0AH,
    <8,N,2>=07H, <8,E,1>=1BH, <8,O,1>=0BH */
    for(i=0;i<=16;i++){
        while(!(inportb(PORT+LSR) & 0x20)); /* wait until THR empty */
        outputb(PORT+THR,tdat[i]);      /* send data to THR */ } }
```

```

i=0;
while(!kbhit()){
if(inportb(PORT+LSR) & 0x01){ /* b0==1, read data ready */
rdat[i++]=inportb(PORT+RDR); /* read data form RDR */
} } }

```

09-05 COM2 Transmission Speed (Keypad)

Settings	4.8 to 115.2kbps	Factory Setting: 9.6
----------	------------------	----------------------

 This parameter is used to set the transmission speed between the RS485 master (PLC, PC, etc.) and AC motor drive.

09-06 COM2 Transmission Fault Treatment (Keypad)

Factory Setting: 0

Settings	0	Warn and keep operating
	1	Warn and RAMP to stop
	2	Warn and COAST to stop
	3	No warning and keep operating

 This parameter is set to how to react if transmission errors occur.

09-07 COM2 Time-out Detection (Keypad)

Unit: 0.1

Settings	0.0 ~ 100.0 sec	Factory Setting: 0.0
----------	-----------------	----------------------

 If Pr.09-03 is not equal to 0.0, Pr.09-02=0~2, and there is no communication on the bus during the Time Out detection period (set by Pr.09-03), "cE10" will be shown on the keypad.

09-08 COM2 Communication Protocol (Keypad)

Factory Setting: 13

Settings	0	Modbus ASCII mode, protocol <7,N,1>
	1	Modbus ASCII mode, protocol <7,N,2>
	2	Modbus ASCII mode, protocol <7,E,1>
	3	Modbus ASCII mode, protocol <7,O,1>
	4	Modbus ASCII mode, protocol <7,E,2>
	5	Modbus ASCII mode, protocol <7,O,2>
	6	Modbus ASCII mode, protocol <8,N,1>
	7	Modbus ASCII mode, protocol <8,N,2>
	8	Modbus ASCII mode, protocol <8,E,1>

9	Modbus ASCII mode, protocol <8,O,1>
10	Modbus ASCII mode, protocol <8,E,2>
11	Modbus ASCII mode, protocol <8,O,2>
12	Modbus RTU mode, protocol <8,N,1>
13	Modbus RTU mode, protocol <8,N,2>
14	Modbus RTU mode, protocol <8,E,1>
15	Modbus RTU mode, protocol <8,O,1>
16	Modbus RTU mode, protocol <8,E,2>
17	Modbus RTU mode, protocol <8,O,2>


09-09 ✓ Response Delay Time

Unit: 0.1

Settings 0.0 ~ 200.0 msec

Factory Setting: 2.0

 This parameter is the response delay time after AC drive receives communication command as shown in the following.

**09-10** ✓ Transmission Master Frequency

Unit: 0.01

Settings 0.00 ~ 600.00 Hz

Factory Setting: 60.00

 When Pr.00-20 is set to 1 (RS485 communication). The AC motor drive will save the last frequency command into Pr.09-10 when abnormal turn-off or momentary power loss. After re-power on, it will with the frequency set in Pr.09-10 if there is no new frequency command.

09-11 ✓ Block Transfer 1

Unit: 1

09-12 ✓ Block Transfer 2

Unit: 1

09-13 ✓ Block Transfer 3

Unit: 1

09-14 ✓ Block Transfer 4

Unit: 1

09-15 ✓ Block Transfer 5

Unit: 1

09-16 ✓ Block Transfer 6

Unit: 1

09-17 ✓ Block Transfer 7

Unit: 1

09-18 ✓ Block Transfer 8

Unit: 1

09-19 ✓ Block Transfer 9

Unit: 1

09-20 ✓ Block Transfer 10

Unit: 1

Settings 0 to 65535

Factory Setting: 0



There is a group of block transfer parameter available in the AC motor drive (Pr.09-11 to Pr.09-20). User can use them (Pr.09-11 to Pr.09-20) to save those parameters that you want to read.

Group 10 PID Control


10-00	Encoder Pulse	Unit: 1
Settings	1 to 20000 (Max=20000 for 2-pole motor)	Factory Setting: 600

 A Pulse Generator (PG) or encoder is used as a sensor that provides a feedback signal of the motor speed. This parameter defines the number of pulses for each cycle of the PG control.


10-01	Encoder Input Type Setting	Factory Setting: 0
-------	----------------------------	--------------------

Settings 0 Disable


Phase A leads in a forward run command and phase B leads in a reverse run command





Phase B leads in a forward run command and phase A leads in a reverse run command



Phase A is a pulse input and phase B is a direction input. (low input=reverse direction, high input=forward direction)



Phase A is a pulse input and phase B is a direction input. (low input=forward direction, high input=reverse direction)



 It is helpful for the stable control by inputting correct pulse type.

10-02	PG Feedback Fault Treatment	Factory Setting: 2
-------	-----------------------------	--------------------

Settings 0 Warn and keep operating


 1 Warn and RAMP to stop

2 Warn and COAST to stop

10-03	↗ Detection Time for PG Feedback Fault	Unit: 0.1
Settings	0.0 to 10.0 sec	Factory Setting: 1.0
When PG loss, encoder signal error, pulse signal setting error or signal error, if time exceeds the detection time for PG feedback fault (Pr.10-03), the PG signal error will occur. Refer to the Pr.10-02 for PG feedback fault treatment.		
10-04	↗ ASR (Auto Speed Regulation) control (P) 1	Unit: 0.1
Settings	0.0 to 1000.0%	Factory Setting: 100.0
10-05	↗ ASR (Auto Speed Regulation) control (I) 1	Unit: 0.001
Settings	0.000 to 10.000 sec	Factory Setting: 0.100
10-06	↗ ASR (Auto Speed Regulation) control (P) 2	Unit: 0.1
Settings	0.0 to 1000.0%	Factory Setting: 100.0
10-07	↗ ASR (Auto Speed Regulation) control (I) 2	Unit: 0.001
Settings	0.000 to 10.000 sec	Factory Setting: 0.100
10-08	↗ ASR 1/ASR2 Switch Frequency	Unit: 0.01
Settings	0.00 to 600.00Hz	Factory Setting: 7.00
	0.00: disable	


ASR P determines Proportional control and associated gain (P). ASR I determines integral control and associated gain (I).

When integral time is set to 0, it is disabled. Pr.10-08 defines the switch frequency for the ASR1 (Pr.10-04, Pr.10-05) and ASR2 (Pr.10-06, Pr.10-07).



When using multi-function input terminals to switch ASR1/ASR2, the diagram will be shown as follows.

Setting multi-function input terminal to 27
(ASR1/ASR2 switch)



10-09 ✓ ASR Primary Low Pass Filter Gain Unit: 0.001

Settings 0.000 to 0.350 sec Factory Setting: 0.008

It defines the filter time of the ASR command.

10-10 ✓ PG Stall Level Unit: 1

Settings 0 to 120% (0: disable) Factory Setting: 115

This parameter determines the maximum PG feedback signal allowed before a fault occurs.
(max. output frequency Pr.01-00 =100%)

10-11 ✓ PG Stall Detection Time Unit: 0.1

Settings 0.0 to 2.0 sec Factory Setting: 0.1

10-12 ✓ PG Slip Range Unit: 1

Settings 0 to 50% (0: disable) Factory Setting: 10

10-13 ✓ PG Slip Detection Time Unit: 0.1

Settings 0.0 to 10.0 sec Factory Setting: 0.5

10-14 ✓ PG Stall and Slip Error Treatment

Factory Setting: 2

Settings 0 Warn and keep operating
1 Warn and RAMP to stop
2 Warn and COAST to stop


When the value of (rotation speed – motor frequency) exceeds Pr.10-12 setting, detection time exceeds Pr.10-13 or motor frequency exceeds Pr.10-10 setting, it will start to accumulate time. If detection time exceeds Pr.10-11, the PG feedback signal error will occur. Refer to Pr.10-14 PG stall and slip error treatment.

10-15 ✓ Pulse Input Type Setting

Factory Setting: 0

Settings 0 Disable


Phase A leads in a forward run command and phase B leads in a reverse run command




Phase B leads in a forward run command and phase A leads in a reverse run command



Phase A is a pulse input and phase B is a direction input. (low input=reverse direction, high input=forward direction)



Phase A is a pulse input and phase B is a direction input. (low input=forward direction, high input=reverse direction)



10-16 Output Setting for Frequency Division (denominator)

Unit: 1

Settings 1 to 255 sec

Factory Setting: 1



When |PID reference source-feedback| > Pr.10-16 in PID feedback control and continuous time exceeds Pr.10-08 setting, the AC motor drive will handle by Pr.10-09.

10-17 PG Electrical Gear A (Channel 1 of PG card)

Unit: 1

Settings 1 to 5000

Factory Setting: 100

10-18 PG Electrical Gear B (Channel 2 of PG card)

Unit: 1

Settings 1 to 5000

Factory Setting: 100



Rotation speed = pulse frequency/encoder pulse (Pr.10-00) * PG Electrical Gear A / PG Electrical Gear B.

10-19	✓ PG Position Control Point (Home)	Unit: 1
Settings	0 to 20000	Factory Setting: 0

 This parameter determines the home position in the position control.

10-20	✓ Range for PG Position Attained (Home range)	Unit: 1
Settings	0 to 20000	Factory Setting: 10

 This parameter determines the Home position attained in the position control mode.

10-21	✓ P Gain of Zero Speed	Unit: 0.1
Settings	0.0 to 1000.0%	Factory Setting: 100.0

10-22	✓ I Gain of Zero Speed	Unit: 0.0001
Settings	0.000 to 10.000 sec	Factory Setting: 0.1000


 This parameter determines zero speed command gain in speed control.

10-23	✓ Feed Forward Gain of APR	Unit: 1
Settings	0 to 100	Factory Setting: 30

10-24	✓ Decelerate Time of Position	Unit: 0.01/0.1
Settings	0.00 to 600.00 sec/00 to 6000.0 sec	Factory Setting: 3.00/3.0

10-25	✓ Max. Frequency for Resolution Switch	Unit: 0.01
Settings	50.00 to 600.00Hz	Factory Setting: 50.00

 This function is used to enhance the function of unstable speed/position due to insufficient resolution of analog simulation value. It needs to use with external input terminals (one of Pr.02-01 to Pr.02-06/Pr.02-23 to Pr.02-30 should be set to 43).



10-26 Reserved

10-27 PG Mechanical Gear A


Unit: 1

10-28 PG Mechanical Gear B

Unit: 1

Settings 1 to 5000

Factory Setting: 100



Control Diagram for the Vector + Torque



Group 11 Advanced Parameters

11-00 System Control

Factory Setting: 0

Settings	Bit 0	ASR Auto tuning
	Bit 1	Inertia estimate
	Bit 2	Zero Servo
	Bit 3	Invalid deadline compensation





Bit 0=1: system will generate an ASR setting and Pr. 10-04~10-07, 10-21~10-22 will be invalid.

Bit 1=1: Inertia estimate function is enabled.

Bit 2=1: when frequency command is less than F_{min} (Pr.01-07), it will use zero servo function.

Bit3=1: Invalid deadline compensation.



**11-01** ✓ Per Unit of System Inertia

Unit: 1

Settings 1 to 65535 (256=1PU)

Factory Setting: 400

📖 To get the system inertia from Pr.11-01, user need to set Pr.11-00 to 2 and execute continuous forward/reverse running.

11-02 ✓ Low-speed Bandwidth

Unit: 1

Settings 0 to 40Hz

Factory Setting: 10

11-03 ✓ High-speed Bandwidth

Unit: 1

Settings 0 to 40Hz

Factory Setting: 10

11-11 ✓ Zero-speed Bandwidth

Unit: 1

Settings 0 to 40Hz

Factory Setting: 10

📖 After estimating inertia and set Pr.11-00 to 1 (auto tuning), user can adjust parameters Pr.11-02, 11-03 and 11-11 separately by speed response. The larger number you set, the faster response you will get. Pr.10-08 is the switch frequency for low-speed/high-speed bandwidth.

11-04 ✓ PDFF Gain Value

Unit: 1

Settings 0 to 200%


Factory Setting: 30

📖 After finishing estimating and set Pr.11-00=1 (auto tuning), using Pr.11-04 to reduce overshoot. Please adjust PDFF gain value by actual situation.

📖 Besides traditional PI control, it also provides PDFF function to reduce overshoot for speed control.

1. Get Pr.11-01 value
2. Set Pr.11-00 to 1

3. Adjust Pr.11-04 (the larger number is set and the suppressed overshoot function will be better. But it needs to be used by the actual condition)



11-05 Gain Value of Flux Weakening Curve for Motor 1

Unit: 1

Settings 0 to 200%

Factory Setting: 90




It is used to adjust the output voltage of flux weakening curve.



For the spindle application, the adjustment method is

1. It is used to adjust the output voltage when exceeding rated frequency.
2. Monitor the output voltage
3. Adjust Pr.11-05 (motor 1) or Pr.11-06 (motor 2) setting to make the output voltage reach motor rated voltage.
4. The larger number it is set, the larger output voltage you will get.



11-06 Gain Value of Flux Weakening Curve for Motor 2

Unit: 1

Settings 0 to 200%

Factory Setting: 90

11-07	✓ Detection Time for Phase-loss	Unit: 0.01
Settings	0.00 to 600.00 sec	Factory Setting: 0.20

-  When the phase-loss occurs and exceeds this detection time, the fault code "PHL" will be displayed. The AC motor drive will record the operation time during phase-loss.
-  When phase-loss occurs and Pr.11-07 is set to 0, it won't display PHL and won't execute Pr.06-02.
-  When user sets this parameter to 0 or not factory setting, we won't promise that all characteristics will be the same as the 3-phase input.
-  If it is set to 0 or a larger number, it will short the life of rectifier and capacitors in the AC motor drive.

11-08	Reserved	
--------------	----------	--

11-09	✓ IGBT Overheat Level for 1-15hp	Unit: 0.1
Settings	20.0 to 110.0°C	Factory Setting: 90.0

11-10	✓ IGBT Overheat Level for 20-100hp	Unit: 0.1
Settings	20.0 to 110.0°C	Factory Setting: 100.0

-  When IGBT temperature exceeds this setting, it will alarm and stop AC motor drive by stop method.

11-12	✓ Speed Feed Forward	Unit: 1
Settings	10 to 150%	Factory Setting: 65

-  It is used to control the response speed for the flux weakening area. The larger number you set, the faster response you will get.

11-13	✓ Notch Filter Depth	Unit: 1
Settings	0 to 20 db	Factory Setting: 0

11-14	✓ Notch Filter Frequency	Unit: 0.01
Settings	0.00 to 200.00	Factory Setting: 0.00

-  This parameter is used to set resonance frequency of mechanical system. It can be used to suppress the resonance of mechanical system.
-  The larger number you set Pr.11-13, the better suppression resonance function you will get.



The notch filter frequency is the resonance of mechanical frequency.

11-15	 Gain Value of Slip Compensation	Unit: 0.01
Settings	0.00 to 1.00	Factory Setting: 1.00



It is only valid in SVC mode.



When the AC motor drive drives the asynchronous motor, slip will increase when the load is added. This parameter can be used to change frequency, lower slip and make the motor be synchronous when running under rated current. When the output current is higher than no-load current, the AC motor drive will adjust frequency by this parameter. If the actual speed is slower than expected, please increase the setting or decrease the setting.

11-16	 Low-pass Filter Time of Keypad Display	Unit: 0.001
Settings	0.001 to 65.535 Sec	Factory Setting: 0.100



It is used to lower the blinking frequency of LCD display.


11-17	 Low-pass Filter Time of PG2 Pulse Input	Unit: 0.001
Settings	0.001 to 65.535 Sec	Factory Setting: 0.100

11-18	Reserved	
11-28		
11-30	Reserved	


11-29	 Accumulative Operation Time of Phase-loss	Unit: 1
Settings	0 to 65535 (hour)	Factory Setting: 0

This page intentionally left blank


5.1 Over Current (OC)




5.2 Ground Fault




5.3 Over Voltage (OV)




5.4 Low Voltage (Lv)




5.5 Over Heat (OH)




5.6 Overload




5.7 Display of KPV-CE01 is Abnormal




5.8 Phase Loss (PHL)




5.9 Motor cannot Run




5.10 Motor Speed cannot be Changed



5.11 Motor Stalls during Acceleration



5.12 The Motor does not Run as Expected



5.13 Electromagnetic/Induction Noise

There are many noises surround the AC motor drives and invade it by radiation or power circuit. It may cause the misoperation of control circuit and even damage the AC motor drive. Of course, that is a solution to increase the noise tolerance of AC motor drive. But it is not the best one due to the limit. Therefore, solve it from the outside as following will be the best.

1. Add surge killer on the relay or contact to suppress switching surge between ON/OFF.
2. Shorten the wiring length of the control circuit or serial circuit and separate from the main circuit wiring.
3. Comply with the wiring regulation for those shielded wire and use isolation amplifier for long wire.
4. The grounding terminal should comply with the local regulation and ground independently, i.e. not to have common ground with electric welding machine and power equipment.
5. Connect a noise filter at the input terminal of the AC motor drive to prevent noise from power circuit.

In a word, three-level solutions for electromagnetic noise are “no product”, “no spread” and “no receive”.

5.14 Environmental Condition

Since AC motor drive is an electronic device, you should comply with the environmental condition stated in the appendix A. Following are the remedial measures for necessary.

1. To prevent vibration, anti-vibration spacer is the last choice. The vibration tolerance must be within the specification. The vibration effect is equal to the mechanical stress and it cannot occur frequently, continuously or repeatedly to prevent damaging AC motor drive.
2. Store in a clean and dry location free from corrosive fumes/dust to prevent rustiness, poor contact. It also may cause short by low insulation in a humid location. The solution is to use both paint and dust-proof. For particular occasion, use the enclosure with whole-seal structure.
3. The surrounding temperature should be within the specification. Too high or low temperature will affect the lifetime and reliability. For semiconductor components, damage will occur once any specification is out of range. Therefore, it is necessary to clean and periodical check for the air cleaner and cooling fan besides having cooler and sunshade.

In addition, the microcomputer may not work in extreme low temperature and needs to have heater.

4. Store within a relative humidity range of 0% to 90% and non-condensing environment. Do not turn off the air conditioner and have exsiccator for it.


5.15 Affecting Other Machines

AC motor drive may affect the operation of other machine due to many reasons. The solutions are as follows.

■ High Harmonic at Power Side

If there is high harmonic at power side during running, the improved methods are:

1. Separate power system: use transformer for AC motor drive.
2. Use reactor at the power input terminal of AC motor drive or decrease high harmonic by multiple circuit.
3. If there is phase lead capacitor, it should use serial reactor to prevent capacitor damage from high harmonic.



■ Motor Temperature Rises

When the motor is induction motor with ventilation-cooling-type used in variety speed operation, bad cooling will happen in the low speed. Therefore, it may overheat. Besides, high harmonic is in output waveform to increase copper loss and iron loss. Following measures should be used by load situation and operation range when necessary.

1. Use the motor with independent power ventilation or increase the horsepower.
2. Use inverter duty motor.
3. Do NOT run in the low speed

Chapter 6 Fault Code Information and Maintenance

6.1 Fault Code Information

The AC motor drive has a comprehensive fault diagnostic system that includes several different alarms and fault messages. Once a fault is detected, the corresponding protective functions will be activated. The following faults are displayed as shown on the AC motor drive digital keypad display. The six most recent faults can be read from the digital keypad or communication.



Wait 5 seconds after a fault has been cleared before performing reset via keypad or input terminal.

6.1.1 Common Problems and Solutions

Fault Name	Fault Descriptions	Corrective Actions
ocA	Over-current during acceleration (Output current exceeds triple rated current during acceleration.)	1. Short-circuit at motor output: Check for possible poor insulation at the output lines. 2. Acceleration Time too short: Increase the Acceleration Time. 3. AC motor drive output power is too small: Replace the AC motor drive with the next higher power model.
ocd	Over-current during deceleration (Output current exceeds triple rated current during deceleration.)	1. Short-circuit at motor output: Check for possible poor insulation at the output line. 2. Deceleration Time too short: Increase the Deceleration Time. 3. AC motor drive output power is too small: Replace the AC motor drive with the next higher power model.
ocn	Over-current during steady state operation (Output current exceeds triple rated current during constant speed.)	1. Short-circuit at motor output: Check for possible poor insulation at the output line. 2. Sudden increase in motor loading: Check for possible motor stall. 3. AC motor drive output power is too small: Replace the AC motor drive with the next higher power model.
ocS	Hardware failure in current detection	Return to the factory

Fault Name	Fault Descriptions	Corrective Actions
OFF	Ground fault	When (one of) the output terminal(s) is grounded, short circuit current is more than 50% of AC motor drive rated current, the AC motor drive power module may be damaged. NOTE: The short circuit protection is provided for AC motor drive protection, not for protection of the user. 1. Check the wiring connections between the AC motor drive and motor for possible short circuits, also to ground. 2. Check whether the IGBT power module is damaged. 3. Check for possible poor insulation at the output line.
OC C	Short-circuit is detected between upper bridge and lower bridge of the IGBT module	Return to the factory
ovR	DC BUS over-voltage during acceleration (230V: DC 450V; 460V: DC 900V)	1. Check if the input voltage falls within the rated AC motor drive input voltage range. 2. Check for possible voltage transients. 3. If DC BUS over-voltage due to regenerative voltage, please increase the Deceleration Time or add an optional brake resistor.
ovd	DC BUS over-voltage during deceleration (230V: DC 450V; 460V: DC 900V)	
ovn	DC BUS over-voltage in constant speed (230V: DC 450V; 460V: DC 900V)	
ovS	Hardware failure in voltage detection	Check if input voltage is within specification range and monitor if there is surge voltage.
LuR	DC BUS voltage is less than Pr.06-00 during acceleration	1. Check if the input voltage is normal 2. Check for possible sudden load
Lud	DC BUS voltage is less than Pr.06-00 during deceleration	
Lun	DC BUS voltage is less than Pr.06-00 in constant speed	
PHL	Phase Loss	Check Power Source Input if all 3 input phases are connected without loose contacts. For models 40hp and above, please check if the fuse for the AC input circuit is blown.

Fault Name	Fault Descriptions	Corrective Actions
OH1	IGBT overheating IGBT temperature exceeds protection level 1 to 15HP: 90 °C 20 to 100HP: 100 °C	1. Ensure that the ambient temperature falls within the specified temperature range. 2. Make sure that the ventilation holes are not obstructed. 3. Remove any foreign objects from the heatsinks and check for possible dirty heat sink fins. 4. Check the fan and clean it. 5. Provide enough spacing for adequate ventilation.
OH2	Heatsink overheating Heat sink temperature exceeds 90°C	1. Ensure that the ambient temperature falls within the specified temperature range. 2. Make sure that the ventilation holes are not obstructed. 3. Remove any foreign objects from the heatsinks and check for possible dirty heat sink fins. 4. Check the fan and clean it. 5. Provide enough spacing for adequate ventilation.
OH3	Motor overheating The AC motor drive detects that the internal temperature exceeds Pr.06-30 (PTC level)	1. Make sure that the motor is not obstructed. 2. Ensure that the ambient temperature falls within the specified temperature range. 3. Take the next higher power AC motor drive model.
EH10	OH1 hardware failure	Return to the factory
EH20	OH2 hardware failure	Return to the factory
FA_n	Fan failure	1. Make sure that the fan is not obstructed. 2. Return to the factory
OL	Overload The AC motor drive detects excessive drive output current. NOTE: The AC motor drive can withstand up to 150% of the rated current for a maximum of 60 seconds.	1. Check whether the motor is overloaded. 2. Take the next higher power AC motor drive model.
EO11	Motor 1 overload	1. Check whether the motor 1 is overloaded. 2. Check whether the rated current of motor 1 (Pr.05-01) is suitable 3. Take the next higher power AC motor drive model.
EO12	Motor 2 overload	1. Check whether the motor 2 is overloaded. 2. Check whether the rated current of motor 2 (Pr.05-13) is suitable 3. Take the next higher power AC motor drive model.

Fault Name	Fault Descriptions	Corrective Actions
FUSE	Broken fuse The fuse at DC side is broken for 30hp and below	1. Check whether the fuse of the transistor module is functioning well 2. Check whether the loading side is short-circuit
ot1	Electronic Thermal Relay 1 Protection	1. Check whether the motor is overloaded. 2. Check whether motor rated current setting (Pr.05-01) is suitable
ot2	Electronic Thermal Relay 2 Protection	3. Check electronic thermal relay function 4. Take the next higher power AC motor drive model.
CF1	Internal EEPROM can not be programmed.	1. Press "RESET" key to the factory setting 2. Return to the factory.
CF2	Internal EEPROM can not be read.	1. Press "RESET" key to the factory setting 2. Return to the factory.
cd0	Hardware failure in current detection	Re-power on to try it. If fault code is still displayed on the keypad please return to the factory
cd1	U-phase error	
cd2	V-phase error	
cd3	W-phase error	
Hd0	CC (current clamp)	Re-power on to try it. If fault code is still displayed on the keypad please return to the factory
Hd1	OC hardware error	
Hd2	OV hardware error	
Hd3	GFF hardware error	
AE	Auto tuning error	1. Check cabling between drive and motor 2. Retry again
AFE	PID loss (ACI)	1. Check the wiring of the PID feedback 2. Check the PID parameters settings
PGF1	PG feedback error	Check if Pr.10-01 is set to 0 when it is PG feedback control
PGF2	PG feedback loss	Check the wiring of the PG feedback
PGF3	PG feedback stall	1. Check the wiring of the PG feedback 2. Check if the setting of PI gain and deceleration is suitable 3. Return to the factory
PGF4	PG slip error	
PGF1	Pulse input error	1. Check the pulse wiring
PGF2	Pulse input loss	2. Return to the factory
ACE	ACI loss	1. Check the ACI wiring 2. Check if the ACI signal is less than 4mA
EF	External Fault	1. Input EF (N.O.) on external terminal is closed to GND. Output U, V, W will be turned off. 2. Give RESET command after fault has been cleared.
EF1	Emergency stop	1. When the multi-function input terminals MI1 to MI6 are set to emergency stop, the AC motor drive stops output U, V, W and the motor coasts to stop. 2. Press RESET after fault has been cleared.

Fault Name	Fault Descriptions	Corrective Actions
bb	External Base Block	- When the external input terminal (B.B) is active, the AC motor drive output will be turned off. - Deactivate the external input terminal (B.B) to operate the AC motor drive again.
PcodE	Password is locked.	Keypad will be locked. Turn the power ON after power OFF to re-enter the correct password. See Pr.00-07 and 00-08.
cE1	Illegal function code	Check if the function code is correct (function code must be 03, 06, 10, 63)
cE2	Illegal data address	Check if the communication address is correct
cE3	Illegal data value	Check if the data value exceeds max./min. value
cE4	Slave device failure	Check the connection of the Slave device
cE10	Communication time-out	Check if the wiring for the communication is correct
cP10	Keypad (KPV-CE01) communication time-out	- Check if the wiring for the communication is correct - Check if there is any wrong with the keypad
bF	Braking resistor fault	If the fault code is still displayed on the keypad after pressing "RESET" key, please return to the factory.
Ydc	Y-connection/ Δ -connection switch error	- Check the wiring of the Y-connection/Δ-connection - Check the parameters settings

6.1.2 Reset

There are three methods to reset the AC motor drive after solving the fault:

- Press  key on KPV-CE01.
- Set external terminal to "RESET" (set one of Pr.02-01~Pr.02-06/ Pr.02-23~Pr.02-30 to 5) and then set to be ON.
- Send "RESET" command by communication.



NOTE

Make sure that RUN command or signal is OFF before executing RESET to prevent damage or personal injury due to immediate operation.

6.2 Maintenance and Inspections

Modern AC motor drives are based on solid state electronics technology. Preventive maintenance is required to operate this AC motor drive in its optimal condition, and to ensure a long life. It is recommended to have a check-up of the AC motor drive performed by a qualified technician.

Daily Inspection:

Basic check-up items to detect if there were any abnormalities during operation are:

1. Whether the motors are operating as expected.
2. Whether the installation environment is abnormal.
3. Whether the cooling system is operating as expected.
4. Whether any irregular vibration or sound occurred during operation.
5. Whether the motors are overheating during operation.
6. Always check the input voltage of the AC drive with a Voltmeter.

Periodic Inspection:

Before the check-up, always turn off the AC input power and remove the cover. Wait at least 10 minutes after all display lamps have gone out, and then confirm that the capacitors have fully discharged by measuring the voltage between +1/+2 and -. The voltage between +1/+2 and - should be less than 25VDC.

**DANGER!**

-
1. Disconnect AC power before processing!
 2. Only qualified personnel can install, wire and maintain AC motor drives. Please take off any metal objects, such as watches and rings, before operation. And only insulated tools are allowed.
 3. Never reassemble internal components or wiring.
 4. Prevent static electricity.

Periodical Maintenance■ **Ambient environment**

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
Check the ambient temperature, humidity, vibration and see if there are any dust, gas, oil or water drops	Visual inspection and measurement with equipment with standard specification	○		
If there are any dangerous objects	Visual inspection	○		

■ **Voltage**

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
Check if the voltage of main circuit and control circuit is correct	Measure with multimeter with standard specification	○		

■ **Keypad**

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
Is the display clear for reading	Visual inspection	○		
Any missing characters	Visual inspection	○		

■ **Mechanical parts**

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If there is any abnormal sound or vibration	Visual and aural inspection		○	
If there are any loose screws	Tighten the screws		○	

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If any part is deformed or damaged	Visual inspection		○	
If there is any color change by overheating	Visual inspection		○	
If there is any dust or dirt	Visual inspection		○	

■ Main circuit

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If there are any loose or missing screws	Tighten or replace the screw		○	
If machine or insulator is deformed, cracked, damaged or with color change due to overheating or ageing	Visual inspection NOTE: Please ignore the color change of copper plate		○	
If there is any dust or dirt	Visual inspection		○	

■ Terminals and wiring of main circuit

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If the terminal or the plate is color change or deformation due to overheat	Visual inspection		○	
If the insulator of wiring is damaged or color change	Visual inspection		○	
If there is any damage	Visual inspection		○	

■ **DC capacity of main circuit**

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If there is any leak of liquid, color change, crack or deformation	Visual inspection	○		
Measure static capacity when required	Static capacity $\geq$ initial value X 0.85		○	

■ **Resistor of main circuit**

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If there is any peculiar smell or insulator cracks due to overheat	Visual inspection, smell		○	
If there is any disconnection	Visual inspection or measure with multimeter after removing wiring between +1/+2 ~ - Resistor value should be within $\pm 10\%$		○	

■ **Transformer and reactor of main circuit**

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If there is any abnormal vibration or peculiar smell	Visual, aural inspection and smell		○	

■ **Magnetic contactor and relay of main circuit**

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If there are any loose screws	Visual and aural inspection	○		
If the contact works correctly	Visual inspection	○		

■ Printed circuit board and connector of main circuit

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If there are any loose screws and connectors	Tighten the screws and press the connectors firmly in place.		○	
If there is any peculiar smell and color change	Visual inspection		○	
If there is any crack, damage, deformation or corrosion	Visual inspection		○	
If there is any liquid is leaked or deformation in capacity	Visual inspection		○	

■ Cooling fan of cooling system

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If there is any abnormal sound or vibration	Visual, aural inspection and turn the fan with hand (turn off the power before operation) to see if it rotates smoothly			○
If there is any loose screw	Tighten the screw			○
If there is any color change due to overheat	Change fan			○

■ Ventilation channel of cooling system

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If there is any obstruction in the heat sink, air intake or air outlet	Visual inspection	○		

Appendix A Specifications

Voltage Class		230V Class											
Model Number VFD-XXXV		007	015	022	037	055	075	110	150	185	220	300	370
Max. Applicable Motor Output (kW)		0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37
Max. Applicable Motor Output (hp)		1.0	2.0	3.0	5.0	7.5	10	15	20	25	30	40	50
Output Rating	Rated Output Capacity (kVA)	1.9	2.7	4.2	6.5	9.5	13	19	25	29	34	46	55
	Rated Output Current for Constant Torque (A)	5.0	7.5	11	17	25	33	49	65	75	90	120	146
	Rated Output Current for Variable Torque (A)	6.25	9.4	13	21	31	41	61	81	93	112	150	182
	Maximum Output Voltage (V)	3-Phase Proportional to Input Voltage											
Input Rating	Output Frequency (Hz)	0.00~600.00 Hz											
	Carrier Frequency (kHz)	15				9				6			
	Rated Input Current (A)	6.4	9.9	15	21	25	33	52	63	68	79	106	126
	Rated Voltage/Frequency	3-phase 200-240V, 50/60Hz											
Voltage Tolerance		± 10%(180~264 V)											
Frequency Tolerance		± 5%(47~63 Hz)											
Cooling Method		Natural		Fan Cooled									
Weight (kg)		2.7	3.2	4.5	6.8	8	10	13	13	13	13	36	36

Voltage Class		460V Class														
Model Number VFD-XXXV		007	015	022	037	055	075	110	150	185	220	300	370	450	550	750
Max. Applicable Motor Output (kW)		0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75
Max. Applicable Motor Output (hp)		1.0	2.0	3.0	5.0	7.5	10	15	20	25	30	40	50	60	75	100
Output Rating	Rated Output Capacity (kVA)	2.3	3.2	4.2	6.3	9.9	14	18	24	29	34	46	56	69	80	100
	Rated Output Current for Constant Torque (A)	3.0	4.2	6.0	8.5	13	18	24	32	38	45	60	73	91	110	150
	Rated Output Current for Variable Torque (A)	3.8	5.3	7.5	10	16	22	30	40	47	56	75	91	113	138	188
	Maximum Output Voltage (V)	3-phase Proportional to Input Voltage														
	Output Frequency (Hz)	0.00~600.00 Hz														
	Carrier Frequency (kHz)	15					9					6				
Input Rating	Rated Input Current (A)	3-phase 380~480V														
		4.0	5.8	7.4	9.9	12	17	25	27	35	42	56	67	87	101	122
	Rated Voltage	3-phase 380 to 480 V														
	Voltage Tolerance	± 10%(342~528 V)														
	Frequency Tolerance	± 5%(47~63 Hz)														
Cooling Method		Natural			Fan Cooled											
Weight (kg)		2.7	3.2	4.5	6.8	8	10	13	13	13	13	36	36	36	50	50

General Specifications		
Control Characteristics	Control System	SPWM(Sinusoidal Pulse Width Modulation) selections: 1 V/f curve; 2 V/f+PG; 3 SVC; 4 FOC+PG; 5 TQR+PG
	Start Torque	Starting torque is 150% at 0.5Hz and 0Hz with FOC + PG control mode
	Speed Control Range	1:100 Sensorless vector (up to 1:1000 when using PG card)
	Speed Control Resolution	$\pm 0.5\%$ Sensorless vector (up to $\pm 0.02\%$ when using PG card)
	Speed Response Ability	5Hz (up to 30Hz for vector control)
	Max. Output Frequency	0.00 to 600.00Hz
	Output Frequency Accuracy	Digital command $\pm 0.005\%$, analog command $\pm 0.5\%$
	Frequency Setting Resolution	Digital command $\pm 0.01\text{Hz}$, analog command: 1/1000(10bit) of the max. output frequency
	Torque Limit	Max. is 200% torque current
	Torque Accuracy	$\pm 5\%$
	Accel/Decel Time	0.00 to 600.00/0.0 to 6000.0 seconds
	V/f Curve	Adjustable V/f curve using 4 independent points and square curve
	Frequency Setting Signal	$\pm 10\text{V}$, 4~20mA, pulse input
	Braking Torque	About 20%
Protection Characteristics	Motor Protection	Electronic thermal relay protection
	Over-current Protection	The current forces 220% of the over-current protection and 300% of the rated current
	Ground Leakage Current Protection	Higher than 50% X rated current
	Overload Ability	Constant torque: 150% for 60 seconds, variable torque: 200% for 2 seconds
	Over-voltage Protection	Over-voltage level: Vdc > 400/800V; low-voltage level: Vdc < 200/400V
	Over-voltage Protection for the Input Power	Varistor (MOV)
	Over-temperature Protection	Built-in temperature sensor
Environmental Conditions	Compensation for the Momentary Power Loss	Up to 5 seconds for parameter setting
	Protection Level	NEMA 1/IP21
	Operation Temperature	-10°C to 40°C for 15hp and above & -10°C to 50°C for 10hp and below
	Storage Temperature	-20 °C to 60 °C
	Ambient Humidity	Below 90% RH (non-condensing)
	Vibration	9.80665m/s ² (1G) less than 20Hz, 5.88m/s ² (0.6G) at 20 to 50Hz
Approvals	Installation Location	Altitude 1,000 m or lower, keep from corrosive gasses, liquid and dust
	     	

Appendix B Accessories

B.1 All Braking Resistors & Braking Units Used in AC Motor Drives


Note: Please only use DELTA resistors and recommended values. Other resistors and values will void Delta's warranty. Please contact your nearest Delta representative for use of special resistors. For instance, in 460V series, 100hp/75kW, the AC motor drive needs 2 braking units with total of 16 braking resistors, so each braking unit uses 8 braking resistors. The braking unit should be at least 10 cm away from AC motor drive to avoid possible interference. Refer to the "Braking Unit Module User Manual" for further details.

Voltage	Applicable Motor		Full Load Torque Nm	Resistor value spec for each AC Motor Drive	Braking Unit Model VFDB No. of Units Used		Braking Resistors Model and No. of Units Used		Braking Torque 10%ED	Min. Equivalent Resistor Value for each AC Motor Drive
	hp	kW								
230V Series	1	0.75	0.427	80W 200Ω			BR080W200	1	125	82Ω
	2	1.5	0.849	300W 100Ω			BR300W100	1	125	82Ω
	3	2.2	1.262	300W 100Ω			BR300W100	1	125	82Ω
	5	3.7	2.080	400W 40Ω			BR400W040	1	125	33Ω
	7.5	5.5	3.111	500W 30Ω			BR500W030	1	125	30Ω
	10	7.5	4.148	1000W 20Ω			BR1K0W020	1	125	20Ω
	15	11	6.186	2400W 13.6Ω	2015	1	BR1K2W6P8	2	125	13.6Ω
	20	15	8.248	3000W 10Ω	2015	1	BR1K5W005	2	125	10Ω
	25	18.5	10.281	4800W 8Ω	2022	1	BR1K2W008	4	125	8Ω
	30	22	12.338	4800W 6.8Ω	2022	1	BR1K2W6P8	4	125	6.8Ω
	40	30	16.497	6000W 5Ω	2015	2	BR1K5W005	4	125	5Ω
	50	37	20.6	9600W 4Ω	2015	2	BR1K2W008	8	125	4Ω
460V Series	1	0.75	0.427	80W 750Ω			BR080W750	1	125	160Ω
	2	1.5	0.849	300W 400Ω			BR300W400	1	125	160Ω
	3	2.2	1.262	300W 250Ω			BR300W250	1	125	160Ω
	5	3.7	2.080	400W 150Ω			BR400W150	1	125	130Ω
	7.5	5.5	3.111	500W 100Ω			BR500W100	1	125	91Ω
	10	7.5	4.148	1000W 75Ω			BR1K0W075	1	125	62Ω
	15	11	6.186	1000W 50Ω	4030	1	BR1K0W050	1	125	39Ω
	20	15	8.248	1500W 40Ω	4030	1	BR1K5W040	1	125	40Ω
	25	18.5	10.281	4800W 32Ω	4030	1	BR1K2W008	4	125	32Ω
	30	22	12.338	4800W 27.2Ω	4030	1	BR1K2W6P8	4	125	27.2Ω
	40	30	16.497	6000W 20Ω	4030	1	BR1K5W005	4	125	20Ω
	50	37	20.6	9600W 16Ω	4045	1	BR1K2W008	8	125	16Ω
	60	45	24.745	9600W 13.6Ω	4045	1	BR1K2W6P8	8	125	13.6Ω
	75	55	31.11	12000W 10Ω	4030	2	BR1K5W005	8	125	10Ω
	100	75	42.7	19200W 6.8Ω	4045	2	BR1K2W6P8	16	125	6.8Ω



1. Please select the factory setting resistance value (Watt) and the duty-cycle value (ED%).
2. If damage to the drive or other equipment are due to the fact that the braking resistors and the braking modules in use are not provided by Delta, the warranty will be void.
3. Take into consideration the safety of the environment when installing the braking resistors.
4. If the minimum resistance value is to be utilized, consult local dealers for the calculation of the Watt figures.
5. Please select thermal relay trip contact to prevent resistor over load. Use the contact to switch power off to the AC motor drive!
6. When using more than 2 braking units, equivalent resistor value of parallel braking unit can't be less than the value in the column "Minimum Equivalent Resistor Value for Each AC Drive" (the right-most column in the table). An example of 575V 100HP, the min. equivalent resistor value for each AC motor drive is 12.5Ω with 2 brake units connection. Therefore, the equivalent resistor value for each brake unit should be 25Ω.
7. Please read the wiring information in the user manual of braking unit thoroughly prior to taking into operation.
8. Definition for Braking Usage ED%

Explanation: The definition of the braking usage ED(%) is for assurance of enough time for the braking unit and braking resistor to dissipate away heat generated by braking. When the braking resistor heats up, the resistance would increase with temperature, and braking torque would decrease accordingly. Suggest cycle time is one minute




9. For safety consideration, install an overload relay between the braking unit and the braking resistor. In conjunction with the magnetic contactor (MC) prior to the drive, it can perform complete protection against abnormality. The purpose of installing the thermal overload relay is to protect the braking resistor from damage due to frequent braking, or due to braking unit keeping operating resulted from unusual high input voltage. Under such circumstance, just turn off the power to prevent damaging the braking resistor.

B.1.1 Dimensions and Weights for Braking Resistors


(Dimensions are in millimeter)

Order P/N: BR080W200, BR080W750, BR300W070, BR300W100, BR300W250, BR300W400, BR400W150, BR400W040




Model no.	L1	L2	H	D	W	Max. Weight (g)
BR080W200	140	125	20	5.3	60	160
BR080W750						
BR300W070	215	200	30	5.3	60	750
BR300W100						
BR300W250						
BR300W400						
BR400W150	265	250	30	5.3	60	930
BR400W040						

Order P/N: BR500W030, BR500W100, BR1KW020, BR1KW075



Model no.	L1	L2	H	D	W	Max. Weight (g)
BR500W030	335	320	30	5.3	60	1100
BR500W100						
BR1KW020	400	385	50	5.3	100	2800
BR1KW075						

Order P/N: BR1K0W050, BR1K2W008, BR1K2W6P8, BR1K5W005, BR1K5W040




B.1.2 Specifications for Braking Unit

		230V Series		460V Series	
		2015	2022	4030	4045
Max. Motor Power (KW)		15	22	30	45
Output Rating	Max. Peak Discharge Current (A) 10%ED	40	60	40	60
	Continuous Discharge Current (A)	15	20	15	18
	Braking Start-up Voltage (DC)	330/345/360/380/400/415 ±3V		660/690/720/760/800/830 ±6V	
Input Rating	DC Voltage	200~400VDC		400~800VDC	
Protection	Heat Sink Overheat	Temperature over +95°C (203 °F)			
	Alarm Output	Relay contact 5A 120VAC/28VDC (RA, RB, RC)			
	Power Charge Display	Blackout until bus (+~-) voltage is below 50VDC			
Environment	Installation Location	Indoor (no corrosive gases, metallic dust)			
	Operating Temperature	-10°C ~ +50°C (14°F to 122°F)			
	Storage Temperature	-20°C ~ +60°C (-4°F to 140°F)			
	Humidity	90% Non-condensing			
	Vibration	9.8m/s ² (1G) under 20Hz 2m/s ² (0.2G) at 20~50Hz			
Mechanical Configuration		Wall-mounted enclosed type IP50			

B.1.3 Dimensions for Braking Unit

(Dimensions are in millimeter[inch])



B.2 Non-fuse Circuit Breaker Chart

Per UL 508C, paragraph 45.8.4, part a:

For 3-phase drives, the current rating of the breaker shall be 4 times maximum output current rating.
(Refer to Appendix A for rated input/output current)

3-phase			
Model	Recommended non-fuse breaker (A)	Model	Recommended non-fuse breaker (A)
VFD007V23A-2	10	VFD150V23A-2	125
VFD007V43A-2	5	VFD150V43A-2	60
VFD015V23A-2	15	VFD185V23A-2	150
VFD015V43A-2	10	VFD185V43A-2	75
VFD022V23A-2	30	VFD220V23A-2	175
VFD022V43A-2	15	VFD220V43A-2	100
VFD037V23A-2	40	VFD300V23A-2	225
VFD037V43A-2	20	VFD300V43A-2	125
VFD055V23A-2	50	VFD370V23A-2	250
VFD055V43A-2	30	VFD370V43A-2	150
VFD075V23A-2	60	VFD450V43A-2	175
VFD075V43A-2	40	VFD550V43C-2	250
VFD110V23A-2	100	VFD750V43C-2	300
VFD110V43A-2	50		

B.3 Fuse Specification Chart

Smaller fuses than those shown in the table are permitted.

Model	I (A) Input	I (A) Output	Line Fuse	
			I (A)	Bussmann P/N
VFD007V23A-2	5.7	5.0	10	JJN-10
VFD007V43A-2	3.2	2.7	5	JJN-6
VFD015V23A-2	7.6	7.0	15	JJN-15
VFD015V43A-2	4.3	4.2	10	JJN-10
VFD022V23A-2	15.5	11	30	JJN-30
VFD022V43A-2	5.9	5.5	15	JJN-15
VFD037V23A-2	20.6	17	40	JJN-40
VFD037V43A-2	11.2	8.5	20	JJN-20
VFD055V23A-2	26	25	50	JJN-50
VFD055V43A-2	14	13	30	JJN-30
VFD075V23A-2	34	33	60	JJN-60
VFD075V43A-2	19	18	40	JJN-40
VFD110V23A-2	50	49	100	JJN-100
VFD110V43A-2	25	24	50	JJN-50
VFD150V23A-2	60	65	125	JJN-125
VFD150V43A-2	32	32	60	JJN-60
VFD185V23A-2	75	75	150	JJN-150
VFD185V43A-2	39	38	75	JJN-70
VFD220V23A-2	90	90	175	JJN-175
VFD220V43A-2	49	45	100	JJN-100
VFD300V23A-2	110	120	225	JJN-225
VFD300V43A-2	60	60	125	JJN-125
VFD370V23A-2	142	145	250	JJN-250
VFD370V43A-2	63	73	150	JJN-150
VFD450V43A-2	90	91	175	JJN-175
VFD550V43C-2	130	110	250	JJN-250
VFD750V43C-2	160	150	300	JJN-300

B.4 AC Reactor

B.4.1 AC Input Reactor Recommended Value

460V, 50/60Hz, 3-Phase

kW	HP	Fundamental Amps	Max. continuous Amps	Inductance (mH)	
				3% impedance	5% impedance
0.75	1	4	6	9	12
1.5	2	4	6	6.5	9
2.2	3	8	12	5	7.5
3.7	5	8	12	3	5
5.5	7.5	12	18	2.5	4.2
7.5	10	18	27	1.5	2.5
11	15	25	37.5	1.2	2
15	20	35	52.5	0.8	1.2
18.5	25	35	52.5	0.8	1.2
22	30	45	67.5	0.7	1.2
30	40	55	82.5	0.5	0.85
37	50	80	120	0.4	0.7
45	60	80	120	0.4	0.7
55	75	100	150	0.3	0.45
75	100	130	195	0.2	0.3

B.4.2 AC Output Reactor Recommended Value

230V, 50/60Hz, 3-Phase

kW	HP	Fundamental Amps	Max. continuous Amps	Inductance (mH)	
				3% impedance	5% impedance
0.75	1	8	12	3	5
1.5	2	8	12	1.5	3
2.2	3	12	18	1.25	2.5
3.7	5	18	27	0.8	1.5
5.5	7.5	25	37.5	0.5	1.2
7.5	10	35	52.5	0.4	0.8
11	15	55	82.5	0.25	0.5

kW	HP	Fundamental Amps	Max. continuous Amps	Inductance (mH)	
				3% impedance	5% impedance
15	20	80	120	0.2	0.4
18.5	25	80	120	0.2	0.4
22	30	100	150	0.15	0.3
30	40	130	195	0.1	0.2
37	50	160	240	0.075	0.15

460V, 50/60Hz, 3-Phase


kW	HP	Fundamental Amps	Max. continuous Amps	Inductance (mH)	
				3% impedance	5% impedance
0.75	1	4	6	9	12
1.5	2	4	6	6.5	9
2.2	3	8	12	5	7.5
3.7	5	12	18	2.5	4.2
5.5	7.5	18	27	1.5	2.5
7.5	10	18	27	1.5	2.5
11	15	25	37.5	1.2	2
15	20	35	52.5	0.8	1.2
18.5	25	45	67.5	0.7	1.2
22	30	45	67.5	0.7	1.2
30	40	80	120	0.4	0.7
37	50	80	120	0.4	0.7
45	60	100	150	0.3	0.45
55	75	130	195	0.2	0.3
75	100	160	240	0.15	0.23

B.4.3 Applications for AC Reactor

Connected in input circuit


Application 1	Question
When more than one AC motor drive is connected to the same power, one of them is ON during operation.	When applying to one of the AC motor drive, the charge current of capacity may cause voltage ripple. The AC motor drive may damage when over current occurs during operation.

Correct wiring




Application 2	Question
Silicon rectifier and AC motor drive is connected to the same power.	Surges will be generated at the instant of silicon rectifier switching on/off. These surges may damage the mains circuit.

Correct wiring




Application 3	Question
Used to improve the input power factor, to reduce harmonics and provide protection from AC line disturbances (surges, switching spikes, short interruptions, etc.). AC line reactor should be installed when the power supply capacity is 500kVA or more and exceeds 6 times the inverter capacity, or the mains wiring distance $\leq 10\text{m}$.	When power capacity is too large, line impedance will be small and the charge current will be too large. That may damage AC motor drive due to higher rectifier temperature.

Correct wiring



B.5 Zero Phase Reactor (RF220X00A)

Dimensions are in millimeter and (inch)



	Motor		Qty.	Recommend ed Wire Size (mm ²)	Wiring Method
	HP	kW			
230 V Series	1/4	0.2	1	0.5-5.5	Diagram A
	1/2	0.5			
	1	0.75			
	2	1.5			
	3	2.2		3.5-5.5	
	5	3.7	4	5.5	Diagram B
	7.5	5.5		8	
	10	7.5		22	
	15	11		30	
	20	15		38	
	25	18.5		38-100	
	30	22			
	40	30			
	50	37			
460 V Series	1/4	0.2	1	0.5-5.5	Diagram A
	1/2	0.5			
	1	0.75			
	2	1.5			
	3	2.2			
	5	3.7	4	3.5-5.5	Diagram B
	7.5	5.5		5.5	
	10	7.5		8-14	
	15	11		14	
	20	15		22	
	25	18.5		30	
	30	22		50	
	40	30		38-100	
	50	37			
	60	45			
	75	55			
	100	75			

Diagram A

Please wind each wire 4 times around the core. The reactor must be put at inverter output as close as possible.





Diagram B

Please put all wires through 4 cores in series without winding.



B.6 DC Choke Recommended Values

230V DC Choke


Input voltage	kW	HP	DC Amps	Inductance (mh)
230Vac 50/60Hz 3-Phase	0.75	1	9	7.50
	1.5	2	12	4.00
	2.2	3	18	2.75
	3.7	5	25	1.75
	5.5	7.5	32	0.85
	7.5	10	40	0.75
	11	15	62	Built-in
	15	20	92	Built-in
	18.5	25	110	Built-in
	22	30	125	Built-in
	30	40	--	Built-in
	37	50	--	Built-in

460V DC Choke

Input voltage	kW	HP	DC Amps	Inductance (mh)
460Vac 50/60Hz 3-Phase	0.75	1	4	25.00
	1.5	2	9	11.50
	2.2	3	9	11.50
	3.7	5	12	6.00
	5.5	7.5	18	3.75
	7.5	10	25	4.00
	11	15	32	Built-in
	15	20	50	Built-in
	18.5	25	62	Built-in
	22	30	80	Built-in
	30	40	92	Built-in
	37	50	110	Built-in
	45	60	125	Built-in
	55	75	200	Built-in
	75	100	240	Built-in

B.7 Remote Controller RC-01

Dimensions are in millimeter



VFD-VE Programming:

Pr.00-20 set to 2


Pr.00-21 set to 1 (external controls)

Pr.02-00 set to 1 (setting Run/Stop and Fwd/Rev controls)

Pr.02-05 (MI5) set to 5 (External reset)

B.8 PG Card (for Encoder)

B.8.1 EMV-PG01X



1. Terminals descriptions

Terminal Symbols	Descriptions
VP	Power source of EMV-PG01X (use FSW3 to switch 12V/5V) Output Voltage: +5V/+12V±5% 200mA
DCM	Power source and input signal common
A1, $\overline{A1}$ B1, $\overline{B1}$ Z1, $\overline{Z1}$	Input signal. Input type is selected by FSW1. It can be 1-phase or 2-phase input. Maximum 300KP/sec
A2, $\overline{A2}$ B2, $\overline{B2}$	Input signal. Input type is selected by FSW2. It can be 1-phase or 2-phase input. Maximum 300KP/sec
$\oplus$	Grounding

2. Wiring Notes


- Please use a shielded cable to prevent interference. Do not run control wires parallel to any high voltage AC power line (200 V and above).
- Recommended wire size 0.21 to 0.81mm² (AWG24 to AWG18).

3. Wire length (wire length and signal frequency are in inverse proportion)


Types of Pulse Generators	Maximum Wire Length	Wire Gauge
Output Voltage	50m	1.25mm ² (AWG16) or above
Open Collector	50m	
Line Driver	300m	
Complementary	70m	

4. Basic Wiring Diagram

wiring 1




wiring 2




5. Types of Pulse Generators (Encoders)

Types of Pulse Generators	FSW1+ FSW3		FSW2+ FSW3	
	5V	12V	5V	12V
VOLTAGE				
Open collector				

Types of Pulse Generators	FSW1+ FSW3		FSW2+ FSW3	
	5V	12V	5V	12V
Line driver 				
Complementary 				

B.8.2 EMV-PG010



1. Terminals descriptions

Terminal Symbols	Descriptions
VP	Power source of EMV-PG010 (use FSW3 to switch 12V/5V) Output Voltage: +5V/+12V±5% 200mA

Terminal Symbols	Descriptions
DCM	Power source and input signal common
A1, $\overline{A1}$ B1, $\overline{B1}$ Z1, $\overline{Z1}$	Input signal from encoder. Input type is selected by FSW1. It can be 1-phase or 2-phase input. Maximum 300KP/sec
A2, $\overline{A2}$ B2, $\overline{B2}$	Input signal from encoder. Input type is selected by FSW2. It can be 1-phase or 2-phase input. Maximum 300KP/sec
A/O, B/O, Z/O	Output signal. It has division frequency function (Pr.10-16), open collector: max. output DC20V 50mA
	Grounding

2. Wiring Notes


- Please use a shielded cable to prevent interference. Do not run control wires parallel to any high voltage AC power line (200 V and above).
- Recommended wire size 0.21 to 0.81mm² (AWG24 to AWG18).

3. Wire length: (wire length and signal frequency are in inverse proportion)


Types of Pulse Generators	Maximum Wire Length	Wire Gauge
Output Voltage	50m	1.25mm ² (AWG16) or above
Open Collector	50m	
Line Driver	300m	
Complementary	70m	

4. Basic Wiring Diagram




wiring 1




wiring 2



5. Types of Pulse Generators (Encoders)

Types of Pulse Generators	FSW1+ FSW3		FSW2+ FSW3	
	5V	12V	5V	12V
VOLTAGE 	 	 	 	 
Open collector 	 	 	 	 
Line driver 	 	 	 	 
Complementary 	 	 	 	 

B.8.3 EMV-PG01L



1. Terminals descriptions

Terminal Symbols	Descriptions
VP	Power source of EMV-PG01L Output Voltage: +5V±5% 200mA
DCM	Power source and input signal common
A1, $\overline{A1}$ B1, $\overline{B1}$ Z1, $\overline{Z1}$	Input signal. Input type is selected by FSW1. It can be 1-phase or 2-phase input. Maximum 300KP/sec
A2, $\overline{A2}$ B2, $\overline{B2}$	Input signal. Input type is selected by FSW2. It can be 1-phase or 2-phase input. Maximum 300KP/sec
A/O, B/O, Z/O	Output signal. It has division frequency function (Pr.10-16), Line driver: max. output DC5V 50mA
⊕	Grounding

2. Wiring Notes


- Please use a shielded cable to prevent interference. Do not run control wires parallel to any high voltage AC power line (200 V and above).
- Recommended wire size 0.21 to 0.81mm² (AWG24 to AWG18).

3. Wire length: (wire length and signal frequency are in inverse proportion)


Types of Pulse Generators	Maximum Wire Length	Wire Gauge
Output Voltage	50m	1.25mm ² (AWG16) or above
Open Collector	50m	
Line Driver	300m	
Complementary	70m	

4. Basic Wiring Diagram

wiring 1





wiring 2



5. Types of Pulse Generators (Encoders)

Types of Pulse Generators	FSW1	FSW2
	5V	5V
VOLTAGE 		
Open collector 		

Types of Pulse Generators	FSW1	FSW2
	5V	5V
Line driver 		
Complementary 		

B.9 AMD-EMI Filter Cross Reference

AC Drives	Model Number	FootPrint
VFD007V43A-2, VFD015V43A-2, VFD022V43A-2	RF022B43AA	Y
VFD037V43A-2	RF037B43BA	Y
VFD055V43A-2, VFD075V43A-2, VFD110V43A-2, VFD110V43B-2	RF110B43CA	Y
VFD007V23A-2, VFD015V23A-2	10TDT1W4C	N
VFD022V23A-2, VFD037V23A-2	26TDT1W4C	N
VFD055V23A-2, VFD075V23A-2, VFD150V43A-2, VFD185V43A-2	50TDS4W4C	N
VFD110V23A-2, VFD150V23A-2, VFD220V43A-2, VFD300V43A-2, VFD370V43A-2	100TDS84C	N
VFD550V43A-2, VFD750V43A-2, VFD550V43C-2, VFD750V43C-2	200TDDS84C	N
VFD185V23A-2, VFD220V23A-2, VFD300V23A-2, VFD450V43A-2	150TDS84C	N
VFD370V23A-2	180TDS84C	N

Installation

All electrical equipment, including AC motor drives, will generate high-frequency/low-frequency noise and will interfere with peripheral equipment by radiation or conduction when in operation. By using an EMI filter with correct installation, much interference can be eliminated. It is recommended to use DELTA EMI filter to have the best interference elimination performance.

We assure that it can comply with following rules when AC motor drive and EMI filter are installed and wired according to user manual:

- **EN61000-6-4**
- **EN61800-3: 1996 + A11: 2000**
- **EN55011 (1991) Class A Group 1 (1st Environment, restricted distribution)**

General precaution


1. EMI filter and AC motor drive should be installed on the same metal plate.
2. Please install AC motor drive on footprint EMI filter or install EMI filter as close as possible to the AC motor drive.

3. Please wire as short as possible.
4. Metal plate should be grounded.
5. The cover of EMI filter and AC motor drive or grounding should be fixed on the metal plate and the contact area should be as large as possible.

Choose suitable motor cable and precautions

Improper installation and choice of motor cable will affect the performance of EMI filter. Be sure to observe the following precautions when selecting motor cable.

1. Use the cable with shielding (double shielding is the best).
2. The shielding on both ends of the motor cable should be grounded with the minimum length and maximum contact area.
3. Remove any paint on metal saddle for good ground contact with the plate and shielding.



The length of motor cable

When motor is driven by an AC motor drive of PWM type, the motor terminals will experience surge voltages easily due to components conversion of AC motor drive and cable capacitance. When the motor cable is very long (especially for the 460V series), surge voltages may reduce insulation quality. To prevent this situation, please follow the rules below:

- Use a motor with enhanced insulation.
- Connect an output reactor (optional) to the output terminals of the AC motor drive
- The length of the cable between AC motor drive and motor should be as short as possible (10 to 20 m or less)
- For models 7.5hp/5.5kW and above:

Insulation level of motor	1000V	1300V	1600V
460VAC input voltage	66 ft (20m)	328 ft (100m)	1312 ft (400m)
230VAC input voltage	1312 ft (400m)	1312 ft (400m)	1312 ft (400m)

- For models 5hp/3.7kW and less:

Insulation level of motor	1000V	1300V	1600V
460VAC input voltage	66 ft (20m)	165 ft (50m)	165 ft (50m)
230VAC input voltage	328 ft (100m)	328 ft (100m)	328 ft (100m)

 NOTE

When a thermal O/L relay protected by motor is used between AC motor drive and motor, it may malfunction (especially for 460V series), even if the length of motor cable is only 165 ft (50m) or less. To prevent it, please use AC reactor and/or lower the carrier frequency (Pr. 00-17 PWM carrier frequency).

 NOTE

Never connect phase lead capacitors or surge absorbers to the output terminals of the AC motor drive.

- If the length is too long, the stray capacitance between cables will increase and may cause leakage current. It will activate the protection of over current, increase leakage



current or not insure the correction of current display. The worst case is that AC motor drive may damage.

- If more than one motor is connected to the AC motor drive, the total wiring length is the sum of the wiring length from AC motor drive to each motor.


B.9.1 Dimensions




Dimensions are in millimeter and (inch)

Order P/N: RF015B21AA / RF022B43AA




Order P/N: RF022B21BA / RF037B43BA







Order P/N: 10TDT1W4C




Order P/N: 26TDT1W4C




Order P/N: 50TDS4W4C




Order P/N: 100TDS84C




Order P/N: 200TDDS84C



Order P/N: 150TDS84C



Order P/N: 180TDS84C



Appendix C How to Select the Right AC Motor Drive

The choice of the right AC motor drive for the application is very important and has great influence on its lifetime. If the capacity of AC motor drive is too large, it cannot offer complete protection to the motor and motor maybe damaged. If the capacity of AC motor drive is too small, it cannot offer the required performance and the AC motor drive maybe damaged due to overloading.

But by simply selecting the AC motor drive of the same capacity as the motor, user application requirements cannot be met completely. Therefore, a designer should consider all the conditions, including load type, load speed, load characteristic, operation method, rated output, rated speed, power and the change of load capacity. The following table lists the factors you need to consider, depending on your requirements.

Item		Related Specification			
		Speed and torque characteristics	Time ratings	Overload capacity	Starting torque
Load type	Friction load and weight load				
	Liquid (viscous) load	●			●
	Inertia load				
	Load with power transmission				
Load speed and torque characteristics	Constant torque				
	Constant output	●	●		
	Decreasing torque				
	Decreasing output				
Load characteristics	Constant load				
	Shock load	●	●	●	●
	Repetitive load				
	High starting torque				
	Low starting torque				
Continuous operation, Short-time operation			●	●	
Long-time operation at medium/low speeds					
Maximum output current (instantaneous)		●		●	
Constant output current (continuous)					
Maximum frequency, Base frequency		●			
Power supply transformer capacity or percentage impedance					
Voltage fluctuations and unbalance				●	●
Number of phases, single phase protection					
Frequency					
Mechanical friction, losses in wiring				●	●
Duty cycle modification			●		

C.1 Capacity Formulas

1. When one AC motor drive operates one motor

The starting capacity should be less than 1.5x rated capacity of AC motor drive

The starting capacity=

$$\frac{k \times N}{973 \times \eta \times \cos \varphi} \left(T_L + \frac{GD^2}{375} \times \frac{N}{t_A} \right) \leq 1.5 \times \text{the_capacity_of_AC_motor_drive(kVA)}$$

2. When one AC motor drive operates more than one motor

2.1 The starting capacity should be less than the rated capacity of AC motor drive

- Acceleration time ≤ 60 seconds

The starting capacity=

$$\frac{k \times N}{\eta \times \cos \varphi} [n_r + n_s(k_s - 1)] = P_{Cl} \left[1 + \frac{n_s}{n_r} (k_s - 1) \right] \leq 1.5 \times \text{the_capacity_of_AC_motor_drive(kVA)}$$

- Acceleration time ≥ 60 seconds

The starting capacity=

$$\frac{k \times N}{\eta \times \cos \varphi} [n_r + n_s(k_s - 1)] = P_{Cl} \left[1 + \frac{n_s}{n_r} (k_s - 1) \right] \leq \text{the_capacity_of_AC_motor_drive(kVA)}$$

2.2 The current should be less than the rated current of AC motor drive(A)

- Acceleration time ≤ 60 seconds

$$n_r + I_M \left[1 + \frac{n_s}{n_r} (k_s - 1) \right] \leq 1.5 \times \text{the_rated_current_of_AC_motor_drive(A)}$$

- Acceleration time ≥ 60 seconds

$$n_r + I_M \left[1 + \frac{n_s}{n_r} (k_s - 1) \right] \leq \text{the_rated_current_of_AC_motor_drive(A)}$$

2.3 When it is running continuously

- The *requirement* of load capacity should be less than the capacity of AC motor drive(kVA)

The requirement of load capacity=

$$\frac{k \times P_M}{\eta \times \cos \varphi} \leq \text{the_capacity_of_AC_motor_drive(kVA)}$$

- *The motor capacity should be less than the capacity of AC motor drive*

$$k \times \sqrt{3} \times V_M \times I_M \times 10^{-3} \leq \text{the_capacity_of_AC_motor_drive(kVA)}$$

- *The current should be less than the rated current of AC motor drive(A)*

$$k \times I_M \leq \text{the_rated_current_of_AC_motor_drive(A)}$$

Symbol explanation

P_M	: Motor shaft output for load (kW)
η	: Motor efficiency (normally, approx. 0.85)
$\cos \varphi$	: Motor power factor (normally, approx. 0.75)
V_M	: Motor rated voltage(V)
I_M	: Motor rated current(A), for commercial power
k	: Correction factor calculated from current distortion factor (1.05-1.1, depending on PWM method)
P_{C1}	: Continuous motor capacity (kVA)
k_s	: Starting current/rated current of motor
n_T	: Number of motors in parallel
n_s	: Number of simultaneously started motors
GD^2	: Total inertia (GD^2) calculated back to motor shaft (kg m^2)
T_L	: Load torque
t_A	: Motor acceleration time
N	: Motor speed

C.2 General Precaution

Selection Note

1. When the AC Motor Drive is connected directly to a large-capacity power transformer (600kVA or above) or when a phase lead capacitor is switched, excess peak currents may occur in the power input circuit and the converter section may be damaged. To avoid this, use an AC input reactor (optional) before AC Motor Drive mains input to reduce the current and improve the input power efficiency.
2. When a special motor is used or more than one motor is driven in parallel with a single AC Motor Drive, select the AC Motor Drive current $\geq 1.25 \times$ (Sum of the motor rated currents).
3. The starting and accel./decel. characteristics of a motor are limited by the rated current and the overload protection of the AC Motor Drive. Compared to running the motor D.O.L. (Direct On-Line), a lower starting torque output with AC Motor Drive can be expected. If higher starting torque is required (such as for elevators, mixers, tooling machines, etc.) use an AC Motor Drive of higher capacity or increase the capacities for both the motor and the AC Motor Drive.
4. When an error occurs on the drive, a protective circuit will be activated and the AC Motor Drive output is turned off. Then the motor will coast to stop. For an emergency stop, an external mechanical brake is needed to quickly stop the motor.

Parameter Settings Note

1. The AC Motor Drive can be driven at an output frequency up to 400Hz (less for some models) with the digital keypad. Setting errors may create a dangerous situation. For safety, the use of the upper limit frequency function is strongly recommended.
2. High DC braking operating voltages and long operation time (at low frequencies) may cause overheating of the motor. In that case, forced external motor cooling is recommended.
3. Motor accel./decel. time is determined by motor rated torque, load torque, and load inertia.
4. If the stall prevention function is activated, the accel./decel. time is automatically extended to a length that the AC Motor Drive can handle. If the motor needs to decelerate within a certain time with high load inertia that can't be handled by the AC Motor Drive in the


required time, either use an external braking resistor and/or brake unit, depending on the model, (to shorten deceleration time only) or increase the capacity for both the motor and the AC Motor Drive.

C.3 How to Choose a Suitable Motor

Standard motor

When using the AC Motor Drive to operate a standard 3-phase induction motor, take the following precautions:

1. The energy loss is greater than for an inverter duty motor.
2. Avoid running motor at low speed for a long time. Under this condition, the motor temperature may rise above the motor rating due to limited airflow produced by the motor's fan. Consider external forced motor cooling.
3. When the standard motor operates at low speed for long time, the output load must be decreased.
4. The load tolerance of a standard motor is as follows:



5. If 100% continuous torque is required at low speed, it may be necessary to use a special inverter duty motor.
6. Motor dynamic balance and rotor endurance should be considered once the operating speed exceeds the rated speed (60Hz) of a standard motor.

7. Motor torque characteristics vary when an AC Motor Drive instead of commercial power supply drives the motor. Check the load torque characteristics of the machine to be connected.
8. Because of the high carrier frequency PWM control of the VFD series, pay attention to the following motor vibration problems:
 - *Resonant mechanical vibration: anti-vibration (damping) rubbers should be used to mount equipment that runs at varying speed.*
 - *Motor imbalance: special care is required for operation at 50 or 60 Hz and higher frequency.*
 - *To avoid resonances, use the Skip frequencies.*
9. The motor fan will be very noisy when the motor speed exceeds 50 or 60Hz.

Special motors:

1. Pole-changing (Dahlander) motor:

The rated current is differs from that of a standard motor. Please check before operation and select the capacity of the AC motor drive carefully. When changing the pole number the motor needs to be stopped first. If over current occurs during operation or regenerative voltage is too high, please let the motor free run to stop (coast).
2. Submersible motor:

The rated current is higher than that of a standard motor. Please check before operation and choose the capacity of the AC motor drive carefully. With long motor cable between AC motor drive and motor, available motor torque is reduced.
3. Explosion-proof (Ex) motor:

Needs to be installed in a safe place and the wiring should comply with the (Ex) requirements. Delta AC Motor Drives are not suitable for (Ex) areas with special precautions.
4. Gear reduction motor:

The lubricating method of reduction gearbox and speed range for continuous operation will be different and depending on brand. The lubricating function for operating long time at low speed and for high-speed operation needs to be considered carefully.
5. Synchronous motor:

The rated current and starting current are higher than for standard motors. Please check before operation and choose the capacity of the AC motor drive carefully. When the AC

motor drive operates more than one motor, please pay attention to starting and changing the motor.





Power Transmission Mechanism

Pay attention to reduced lubrication when operating gear reduction motors, gearboxes, belts and chains, etc. over longer periods at low speeds. At high speeds of 50/60Hz and above, lifetime reducing noises and vibrations may occur.

Motor torque

The torque characteristics of a motor operated by an AC motor drive and commercial mains power are different.

Below you'll find the torque-speed characteristics of a standard motor (4-pole, 15kW):



This page intentionally left blank.